UGREEN 50747

UGREEN Adjustable Foldable Cell Phone Stand Holder (Model 50747) Instruction Manual

Brand: UGREEN | Model: 50747

1. Introduction

Thank you for choosing the UGREEN Adjustable Foldable Cell Phone Stand Holder. This versatile accessory is designed to provide a stable and adjustable viewing experience for your smartphone or small tablet. Its compact and foldable design makes it ideal for use at home, in the office, or while traveling. This manual will guide you through the product's features, setup, operation, and maintenance to ensure optimal performance.



Figure 1: UGREEN Adjustable Foldable Cell Phone Stand Holder.

2. Product Features

- **Collapsible & Portable:** Designed for easy folding, measuring 3.74" by 3.35" and weighing 2.2 oz, making it convenient for storage and travel.
- **Super Sturdy:** Features a stable triangle structure for excellent stability, even with larger phones.
- **Multi-Angle Adjustable:** The stand can be adjusted from 0° to 100° degrees, with an automatic lock mechanism to maintain your desired viewing angle.
- **Anti-Slip & Anti-Scratches:** Equipped with upgraded silicone mats on the base and cradle to prevent sliding and protect your device from scratches.
- **Broad Compatibility:** Universally designed to fit smartphones, cellphones, small tablets, and e-readers ranging from 4 to 7.9 inches.



Figure 2: Key design features for stability and protection.

3. Setup and Assembly

The UGREEN Cell Phone Stand Holder requires minimal assembly. It arrives in a folded, compact state. To set it up:

1. Gently unfold the stand by pulling the two main sections apart.
2. Adjust the angle of the back support to your preferred viewing position. The stand features an automatic lock mechanism

that will hold the angle securely.

3. Ensure the stand is placed on a flat, stable surface before placing your device.




Figure 3: Adjusting the viewing angle of the stand.

4. Operating Instructions

Using your UGREEN Cell Phone Stand Holder is straightforward:

- **Placing Your Device:** Position your smartphone or small tablet onto the front cradle of the stand. The silicone pads will secure your device and prevent scratches.
- **Adjusting the Angle:** Gently push or pull the back support to achieve your desired viewing angle. The stand supports

angles from 0° to 100°.

- **Orientation:** The stand supports both vertical (portrait) and horizontal (landscape) orientations for your device, depending on your viewing needs.



Figure 4: Device in vertical orientation on the stand.




Figure 5: Broad compatibility with different device sizes.

Your browser does not support the video tag.

Video 1: Official UGREEN video demonstrating the stand's features and usage.

5. Maintenance

To ensure the longevity and optimal appearance of your UGREEN Cell Phone Stand Holder:

- Clean the stand with a soft, dry cloth.
- Avoid using abrasive cleaners or solvents, as these may damage the finish or silicone pads.
- Periodically check the hinge mechanism for smooth operation.

6. Troubleshooting

If you encounter any issues with your UGREEN Cell Phone Stand Holder, consider the following:

- **Stand not holding angle:** Ensure the hinge mechanism is clean and free of debris. The automatic lock should engage firmly.
- **Device slipping:** Verify that the silicone pads on the cradle and base are clean and intact. Clean them with a damp cloth if necessary.
- **Stand unstable:** Make sure the stand is placed on a flat, level surface. The triangle structure is designed for stability on even surfaces.

7. Specifications

Product Dimensions:	0.79 x 0.79 x 0.39 inches (folded)
Item Weight:	0.353 ounces
Model Number:	50747
Brand:	UGREEN
Color:	Black
Compatible Devices:	Smartphones, small tablets, and e-readers (4 to 7.9 inches)
Material:	Aluminum Alloy Hinge, Silicone Pads

8. Safety Information

Please keep the product away from high temperatures.

9. Warranty and Support

UGREEN products come with a standard warranty. For detailed warranty information, technical support, or any inquiries regarding your product, please visit the official UGREEN website or contact their customer service directly. Contact information can typically be found on the product packaging or the UGREEN official website.
For more information, visit the UGREEN Store on Amazon.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question