VASAGLE LBC03WT

VASAGLE LBC03WT Shoe Cabinet Instruction Manual

Model: LBC03WT | Brand: VASAGLE

1. Product Overview

The VASAGLE LBC03WT Shoe Cabinet is a functional and space-saving storage solution designed to organize your footwear. This white cabinet features three tilt-out drawers, each equipped with adjustable partitions to accommodate various shoe sizes and types.

Key Features:

- **Three Tilt-Out Drawers:** Provides ample storage for multiple pairs of shoes.
- **Adjustable Partitions:** Removable and extractable dividers allow for flexible storage, fitting shoes up to EU size 43, including heels and boots.
- **Durable Construction:** Made from high-quality particleboard with a scratch-resistant melamine veneer surface.
- **Anti-Tipping Protection:** Includes a safety kit to secure the cabinet to the wall, enhancing stability.
- **Easy Maintenance:** The surface is designed for easy cleaning with a damp cloth.
- **Thoughtful Design:** Features a rear panel to prevent shoes from touching the wall and floor protectors to prevent scratches. Hidden screw holes ensure a clean aesthetic.





Figure 1: VASAGLE LBC03WT Shoe Cabinet, front view, closed.

This image displays the front view of the VASAGLE LBC03WT Shoe Cabinet in its closed position, showcasing its minimalist white design and three distinct tilt-out drawer panels.



Figure 2: VASAGLE LBC03WT Shoe Cabinet in an entryway.

The shoe cabinet is shown in an entryway setting, with the top tilt-out drawer open, revealing neatly stored shoes. A small plant and basket are placed on top of the cabinet.

2. Safety Information

Please read and understand all safety instructions before assembly and use. Failure to follow these instructions may result in injury or damage to the product.

- **Anti-Tipping Device:** Always install the included anti-tipping device to secure the cabinet to a wall. This is crucial to prevent the cabinet from tipping over, especially when drawers are open or if children are present.
- **Weight Capacity:** Do not overload the cabinet. Each compartment has a maximum load capacity of 10 kg. The top surface has a maximum load capacity of 20 kg. Exceeding these limits can compromise stability and cause damage.
- **Correct Assembly:** Ensure all parts are correctly assembled and fasteners are tightened according to the instructions. Loose connections can lead to instability.

- **Placement:** Place the cabinet on a flat, stable surface. Avoid placing it on uneven ground.
- **Children Safety:** Keep small parts and packaging materials away from children during assembly. Do not allow children to climb on or play with the cabinet.



Figure 3: Safety and Design Details.

This image provides a close-up of the cabinet's features, including the anti-tipping strap attachment point at the top, the sleek metal handles on each drawer, and the sturdy base.

3. Setup and Assembly

Assembly of the VASAGLE LBC03WT Shoe Cabinet requires basic tools and adherence to the provided instructions. All parts are numbered for easy identification.

Included Components:

- 1 x Shoe Cabinet (disassembled parts)
- 1 x Assembly Instruction Manual (FR, DE, EN, ES, IT)
- 1 x Accessory Bag (containing screws, dowels, and other hardware, including a spare screw)

Recommended Tools (Not Included):

- Hammer
- Phillips Head Screwdriver

Assembly Steps:

1. **Unpack and Verify:** Carefully unpack all components and lay them out on a clean, soft surface (e.g., a blanket or cardboard) to prevent scratches. Verify that all numbered parts and accessories listed in the manual are present.
2. **Follow Instructions:** Refer to the detailed, illustrated assembly instructions provided in the package. Each step is clearly outlined.
3. **Assemble Frame:** Begin by assembling the main frame of the cabinet, connecting the side panels, top, and bottom using the designated hardware.
4. **Install Drawers:** Assemble the tilt-out drawers and install them into the cabinet frame. Ensure the tilting mechanism operates smoothly.
5. **Attach Handles:** Secure the metal handles to the front of each drawer.
6. **Install Back Panel:** Attach the back panel to the cabinet. This panel helps prevent shoes from touching the wall.
7. **Apply Floor Protectors:** Attach the provided floor protectors to the bottom of the cabinet to prevent scratching your floor.
8. **Secure Anti-Tipping Device:** Crucially, install the anti-tipping device by securing one end to the top rear of the cabinet and the other end to a solid wall stud or appropriate wall anchor.

Note: The manufacturer recommends laying the cabinet on its side when installing the tilt-out drawer mechanisms if assembling alone.

4. Operating Instructions

Using your VASAGLE LBC03WT Shoe Cabinet is straightforward. Follow these guidelines for optimal use and organization.

Storing Shoes:

1. **Open Drawers:** Gently pull the handle of a drawer to tilt it open. The drawer will pivot outwards and downwards.
2. **Place Shoes:** Arrange your shoes within the compartments. The cabinet can hold approximately 18 pairs of women's shoes or 12 pairs of men's shoes.
3. **Adjust Partitions:** If you need to store taller footwear like boots or high heels, the internal partitions within each drawer can be removed or adjusted to create larger spaces. Simply slide them out or reposition them as needed.
4. **Close Drawers:** Push the drawer back into the cabinet until it is fully closed and flush with the cabinet front.

Top Surface Use:

The top surface of the cabinet can be used for decorative items or small essentials. Ensure the weight placed on top does not exceed 20 kg.



Figure 4: Shoe Storage Versatility.

This image illustrates the interior of the tilt-out drawers, showing how different types of shoes, from flats to boots, can be stored by utilizing the adjustable partitions.



Figure 5: Top Surface Load Capacity.

The top of the cabinet is shown holding a potted plant and a small storage basket, with an icon indicating a maximum load capacity of 20 kg for the surface.



Figure 6: Adjustable Partition Detail.

A close-up view of an open tilt-out drawer highlights the adjustable partition, demonstrating its flexibility to create different storage heights for various shoe types.

5. Maintenance

Proper care and maintenance will ensure the longevity and appearance of your shoe cabinet.

- **Cleaning:** The melamine veneer surface is scratch-resistant and easy to clean. Wipe the cabinet regularly with a soft, damp cloth. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, which can damage the finish.
- **Spills:** Immediately wipe up any spills to prevent staining or moisture damage.
- **Inspection:** Periodically check all screws and fasteners to ensure they remain tight. Retighten if necessary to maintain structural integrity.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration of the

finish.

- **Heat and Moisture:** Keep the cabinet away from direct heat sources and areas of high humidity.

6. Troubleshooting

If you encounter any issues with your shoe cabinet, refer to the following common troubleshooting tips:

Issue: Cabinet feels unstable or wobbly.

- **Solution 1:** Ensure the cabinet is placed on a level surface. Adjust floor protectors if necessary to compensate for uneven floors.
- **Solution 2:** Verify that all assembly screws and fasteners are securely tightened. Refer to the assembly manual to check each connection point.
- **Solution 3:** Confirm the anti-tipping device is correctly installed and securely anchored to the wall.

Issue: Drawers do not open or close smoothly.

- **Solution 1:** Check for any obstructions inside the drawer or along the tilting mechanism. Remove any shoes or debris that might be blocking movement.
- **Solution 2:** Ensure the drawer components were assembled correctly. Refer to the assembly manual for the tilt-out mechanism steps.
- **Solution 3:** Verify that the cabinet itself is not warped or uneven, which could affect drawer alignment.

Issue: Shoes do not fit in compartments.

- **Solution:** Utilize the adjustable and removable partitions. Remove a partition entirely or reposition it to create more space for taller shoes like boots or high heels.

7. Specifications

Attribute	Specification
Brand	VASAGLE
Model Number	LBC03WT (Manufacturer's Model: 6955880334865)
Color	White
Material	Particleboard
Product Dimensions (L x W x H)	60 x 24 x 120 cm
Item Weight	21 Kilograms
Maximum Load Capacity (per compartment)	10 Kilograms
Maximum Load Capacity (top surface)	20 Kilograms
Special Feature	Adjustable Partitions

Recommended Use	Shoe Storage



Figure 7: Product Dimensions.

This diagram clearly labels the dimensions of the shoe cabinet: 60 cm in width, 24 cm in depth, and 120 cm in height, along with the height of each drawer section and the base.

8. Warranty and Support

For any questions regarding assembly, missing parts, or product functionality, please refer to the contact information provided by your retailer or the VASAGLE official website.
Information regarding the availability of spare parts for this product is currently unavailable.

© 2025 VASAGLE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question