

Coleman 2000033053

Coleman RoadTrip 225 Portable Propane Grill User Manual

Model: 2000033053

Brand: Coleman

INTRODUCTION

This manual provides essential instructions for the safe and efficient operation, setup, maintenance, and troubleshooting of your Coleman RoadTrip 225 Portable Propane Grill. Please read this manual thoroughly before using the grill.

SAFETY INFORMATION

- **FOR OUTDOOR USE ONLY:** Never operate this appliance indoors.
- **PROPANE GAS ONLY:** Use only propane gas as fuel.
- **VENTILATION:** Ensure adequate ventilation. Do not obstruct airflow around the grill.
- **CLEARANCE:** Maintain minimum clearances from combustible materials.
- **LEAK TEST:** Perform a leak test on all gas connections before initial use and after any cylinder change.
- **CHILDREN AND PETS:** Keep children and pets away from the grill at all times.
- **HOT SURFACES:** Grill surfaces become extremely hot. Use heat-resistant gloves and appropriate tools.
- **FUEL CYLINDER:** Connect and disconnect the propane cylinder outdoors, away from ignition sources.
- **CLEANING:** Clean the grill regularly to prevent grease fires.
- **STORAGE:** Store the grill in a cool, dry place. Disconnect the propane cylinder before storage.

PRODUCT OVERVIEW

The Coleman RoadTrip 225 Portable Propane Grill is designed for versatile outdoor cooking, offering convenience and performance for various activities such as camping, tailgating, and backyard use. It features dual burners with adjustable temperature control and a matchless ignition system.

Key Features:

- Up to 11,000 BTUs of cooking power.
- Two adjustable gas grills for precise temperature control.
- Ample 225 square inch grilling area.
- InstaStart push-button ignition for matchless lighting.
- Quick-fold legs and wheels for easy setup, transport, and storage.
- Operates on one 16.4 oz. propane cylinder (sold separately).
- Integrated side tables for food preparation and tool placement.



Figure 1: Coleman RoadTrip 225 Portable Propane Grill (Red) in its closed, ready-to-transport state.



Figure 2: Top-down view of the Coleman RoadTrip 225 grill with the lid open, revealing the two cooking grates and underlying burners.

SETUP INSTRUCTIONS

1. **Unpacking:** Carefully remove the grill from its packaging. Ensure all components are present.
2. **Unfolding Legs:** Place the grill on a flat, stable surface. Release the leg lock mechanism and extend the legs until they fully lock into place. The wheels should be on one side, and the stable feet on the other.
3. **Attaching Side Tables:** Extend the side tables from the main body of the grill until they click securely into position. These provide convenient space for utensils and ingredients.



Figure 3: The Coleman RoadTrip 225 grill with both side tables extended, ready for use.

4. **Connecting Propane Cylinder:** Ensure both burner control knobs are in the "OFF" position. Screw a 16.4 oz. propane cylinder (sold separately) clockwise into the regulator until hand-tight. Do not overtighten.
5. **Leak Test:** Apply a soapy water solution to all gas connections. If bubbles appear, there is a leak. Tighten connections or replace parts as necessary. Do not operate the grill if a leak is detected.

Folding for Storage/Transport:

1. Ensure the grill is completely cool and the propane cylinder is disconnected.
2. Retract the side tables.
3. Release the leg lock mechanism and fold the legs inward. Secure the legs with the locking latch.
4. The grill can then be wheeled using its integrated wheels or stored vertically to save space.



Figure 4: A person easily transporting the folded Coleman RoadTrip 225 grill using its wheels.

OPERATING INSTRUCTIONS

1. **Opening the Lid:** Unlatch the lid and open it fully.
2. **Lighting the Burners:**
 - Ensure the propane cylinder is connected and the gas valve is open.
 - Push and turn a burner control knob to the "HIGH/LIGHT" position.
 - Immediately press the red InstaStart ignition button until the burner lights. You should hear a click and see a flame.
 - If ignition does not occur within 5 seconds, turn the burner control to "OFF", wait 5 minutes, and repeat the lighting procedure.
 - Repeat for the second burner if desired.
3. **Adjusting Temperature:** Use the individual burner control knobs to adjust the heat from "LOW" to

"HIGH" as needed for your cooking. The integrated thermometer on the lid provides temperature monitoring.

4. **Cooking:** Place food on the cooking grates. The 225 sq. inch area accommodates a variety of items.
5. **Turning Off:** When finished cooking, turn both burner control knobs to the "OFF" position. Close the gas valve on the propane cylinder. Allow the grill to cool completely before cleaning or storing.

MAINTENANCE

- **Cleaning Grates:** After each use, once the grates have cooled, remove them and clean with a grill brush and warm soapy water.
- **Drip Tray:** The grill features a removable drip tray. For easier cleaning and to prevent grease fires, add a small amount of water to the drip tray before cooking. Empty and clean the drip tray after each use once cooled.
- **Exterior Cleaning:** Wipe down the exterior surfaces with a damp cloth. Avoid abrasive cleaners that may damage the finish.
- **Storage:** Store the grill in a dry, protected area. Disconnect the propane cylinder and store it separately in a well-ventilated area.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Burner will not light	No gas flow; clogged burner; faulty igniter.	Check propane cylinder connection and gas level. Clean burner ports. Check igniter electrode.
Low flame or uneven heat	Low gas pressure; clogged burner ports; regulator issue.	Check propane level. Clean burner ports. Reset regulator by disconnecting and reconnecting the cylinder.
Grease fire	Excess grease buildup in drip tray or on grates.	Turn off gas supply. Close lid. Do NOT use water. Allow to cool, then clean thoroughly.

SPECIFICATIONS

Feature	Detail
Brand	Coleman
Model Number	2000033053
Product Dimensions	28.78"D x 18.31"W x 14.17"H
Item Weight	35.1 Pounds
Color	Red
Fuel Type	Gas (Propane)
Heating Power	11,000 BTUs
Main Burner Count	2

Feature	Detail
Cooking Surface Area	225 Square Inches
Ignition Type	InstaStart Push-Button
Material Type	Cast Iron (Grates), Blend (Body)
Special Features	Portable, Smokeless, Quick-fold legs, Wheels, Integrated side tables

WARRANTY AND SUPPORT

The Coleman RoadTrip 225 Portable Propane Grill comes with a **3-year limited warranty**. For warranty claims, product support, or to purchase replacement parts, please visit the official Coleman website or contact Coleman customer service directly. Keep your proof of purchase for warranty validation. For additional information and resources, you may visit the [Coleman Store on Amazon](#).

© 2026 Coleman. All rights reserved.

This manual is for informational purposes only.

Always refer to the latest product documentation and safety guidelines provided by the manufacturer.

For Proposition 65 Warning information, please refer to the product packaging or manufacturer's website.