

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [The Woobles](#) /
- › [The Woobles Crochet Kit for Beginners - JoJo The Bunny Instruction Manual](#)

The Woobles Bunny

The Woobles Crochet Kit for Beginners - JoJo The Bunny Instruction Manual

Model: Bunny

INTRODUCTION

This instruction manual provides detailed guidance for assembling your JoJo The Bunny crochet project using The Woobles Crochet Kit. Designed for beginners, this kit includes all necessary materials and resources to help you learn the fundamentals of crochet and create your own finished item.



Image: The Woobles JoJo The Bunny Crochet Kit, showing the kit packaging, a finished JoJo The Bunny, and various components.

Kit Contents

Before beginning, please verify that all components listed below are present in your kit:

- Pre-started yarn (for the main body)
- Easy Peasy Yarn (for additional parts and details)
- Crochet hook
- Yarn needle
- Safety eyes
- Stuffing material
- Instruction card (Wee Woobly Bits)



Image: All components of The Woobles JoJo The Bunny Crochet Kit, including pre-started yarn, Easy Peasy yarn, crochet hook, yarn needle, safety eyes, stuffing, and instruction card, laid out on a purple background.

SETUP AND PREPARATION

1. **Unpack Components:** Carefully remove all items from the kit packaging.
2. **Familiarize Yourself:** Identify each component based on the "Kit Contents" section. The pre-started yarn will have the initial stitches already formed, making it easier to begin.
3. **Access Tutorials:** The kit includes access to step-by-step video tutorials. These tutorials are crucial for visual learners and provide clear demonstrations of each crochet technique required. Refer to the instruction card for details on accessing these videos.

Step-by-step videos for complete beginners




Image: A screenshot illustrating the step-by-step video tutorial interface, showing a crochet instruction for "Round 2" on a computer screen.

OPERATING INSTRUCTIONS (CROCHETING JOJO THE BUNNY)

Follow the provided video tutorials for comprehensive, step-by-step guidance. The instructions below outline the general process.

1. **Start with the Pre-started Yarn:** The main body of JoJo The Bunny begins with the pre-started yarn. This eliminates the need to create a magic ring, a common challenge for beginners.
2. **Follow Video Tutorials:** Each step, from basic stitches to increasing and decreasing, is demonstrated in the video tutorials. Pause, rewind, and re-watch as needed. The "Easy Peasy Yarn" is designed to make stitches visible and prevent fraying, aiding in the learning process.
3. **Form the Body:** Crochet the main body of the bunny according to the pattern.
4. **Attach Features:** Create the ears, nose, and tail using the additional yarn provided.
5. **Insert Safety Eyes:** Once the head is partially formed, securely insert the safety eyes. Ensure they are placed correctly before continuing to crochet.
6. **Stuffing:** As you complete sections, gradually fill them with the provided stuffing to achieve the desired shape and firmness. Do not overstuff.

7. **Assembly:** Use the yarn needle to sew together any separate crocheted parts, such as the ears, to the main body.
8. **Finishing Touches:** Weave in any loose ends with the yarn needle to create a neat appearance.



Image: A completed JoJo The Bunny crochet toy, showcasing its white body, pink inner ears, pink nose, and black safety eyes, against a purple background.

MAINTENANCE AND CARE

To ensure the longevity of your finished JoJo The Bunny:

- **Cleaning:** Spot clean with a damp cloth and mild soap if necessary. Avoid harsh chemicals.
- **Drying:** Air dry thoroughly. Do not machine wash or tumble dry, as this can distort the shape and damage the yarn.
- **Storage:** Store in a clean, dry place away from direct sunlight to prevent fading.
- **Safety Eyes:** Periodically check that the safety eyes remain securely attached.

TROUBLESHOOTING COMMON ISSUES

Issue	Solution
Difficulty seeing stitches	The Woobles Easy Peasy Yarn is designed for visibility. Ensure good lighting. Re-watch the video tutorials for stitch identification.
Stitches are too tight or too loose	Adjust your tension. Practice basic stitches until you achieve a consistent tension. The video tutorials can help demonstrate proper tension.
Losing count of stitches/rows	Utilize stitch markers to mark the beginning of rounds or specific stitches. Take breaks and count frequently.
Yarn splitting or fraying	The Easy Peasy Yarn is designed to resist splitting. Ensure your crochet hook is smooth and free of snags. If using other yarn, this can be a common issue.
Finished item looks different from image	Crochet tension and stuffing amount significantly impact the final shape. Review the video tutorials for shaping tips and adjust stuffing as needed.

SPECIFICATIONS

Brand: The Woobles

Model Name: JoJo The Bunny

Item Model Number: Bunny

Material: 75% cotton, 25% nylon

Item Weight: 2.89 ounces

Product Dimensions: 2.5 x 8.5 x 6.7 inches (L x W x H)

Age Range: 12+

Included Components: Yarn, crochet hook, needle, eyes, stuffing

Special Feature: Beginner-friendly custom-made yarn, step-by-step video tutorials, pre-started crochet pieces

SUPPORT

For any questions, difficulties, or additional assistance with your Woobles kit, comprehensive support is available. You can access unlimited help via email and text. Please refer to the contact information provided on The Woobles official website or within your kit's packaging for direct support channels. Visit [The Woobles Store on Amazon](#) for more information and resources.