

SIMON URMET UTD1051/901

URMET 1051/901 Zeno Wireless 3G Integrated Alarm System User Manual

Brand: SIMON URMET | Model: UTD1051/901

1. INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your URMET 1051/901 Zeno Wireless 3G Integrated Alarm System. This advanced wireless security system is designed to provide comprehensive protection for your home or office, featuring integrated 3G communication for reliable alerts and remote control capabilities. Please read this manual thoroughly before using the system to ensure proper functionality and safety.

2. PACKAGE CONTENTS

Upon opening your URMET 1051/901 Zeno Wireless 3G Integrated Alarm System package, please verify that all components listed below are present and in good condition. The main image below illustrates the primary components of the system.



Image: URMET 1051/901 Zeno Wireless 3G Integrated Alarm System main unit and various accessories.

- **Main Control Panel:** The central unit with integrated 3G communicator.
- **Power Adapter:** For powering the main control panel.
- **Wireless Door/Window Sensors:** Typically multiple units for securing entry points.
- **Wireless PIR Motion Detectors:** For detecting movement within protected areas.
- **Remote Controls:** For arming, disarming, and SOS functions.
- **Siren:** An audible alarm unit.
- **User Manual:** This document.
- **Mounting Hardware:** Screws, anchors, and adhesive pads for installation.

Note: Specific quantities of sensors and remote controls may vary based on the purchased kit configuration.

3. SETUP

3.1. Powering On the Control Panel

1. Connect the power adapter to the main control panel's power input port.
2. Plug the power adapter into a standard electrical outlet.
3. Ensure the control panel powers on and the display illuminates.

3.2. SIM Card Installation (for 3G Communication)

The URMET 1051/901 features an integrated 3G communicator for sending alerts via SMS or calls. A SIM card is required for this functionality.

1. Locate the SIM card slot on the side or back of the main control panel.
2. Carefully insert a standard-sized (2G/3G compatible) SIM card into the slot, ensuring the correct orientation as indicated by the diagram near the slot.
3. The system will automatically detect the SIM card and attempt to connect to the mobile network. Check the display for signal strength indicators.

3.3. Pairing Wireless Sensors (Door/Window, Motion)

Your kit includes wireless sensors that need to be paired with the main control panel.

1. On the main control panel, navigate to the 'Add Sensor' or 'Pair Device' menu (refer to the on-screen menu for exact wording).
2. Activate the sensor you wish to pair (e.g., separate the two parts of a door/window sensor, or trigger a motion detector by waving your hand in front of it).
3. The control panel should detect the sensor and prompt you to confirm pairing. Follow the on-screen instructions to assign a zone and name to the sensor.
4. Repeat for all wireless sensors.

3.4. Pairing Remote Controls

Remote controls allow for convenient arming and disarming of the system.

1. On the main control panel, navigate to the 'Add Remote' or 'Pair Remote' menu.
2. Press any button on the remote control you wish to pair.
3. The control panel should detect the remote and prompt you to confirm pairing.
4. Repeat for all remote controls.

3.5. Connecting the Siren

The siren provides an audible alert during an alarm event.

1. Connect the siren to the main control panel using the provided cable, if it is a wired siren. For wireless sirens, follow the pairing instructions similar to other wireless sensors.
2. Place the siren in a location where its sound can be clearly heard throughout the protected area.

3.6. Mobile App Setup

The URMET 1051/901 system can be controlled via a mobile application (compatible with iOS and Android). This allows for remote monitoring and control.

1. Download the official URMET alarm system app from your device's app store (e.g., Apple App Store or Google Play Store).
2. Create an account and log in.
3. Follow the in-app instructions to add your alarm system. This typically involves scanning a QR code on the control panel or manually entering device details and your Wi-Fi password.
4. Once connected, you can arm, disarm, and manage your system remotely.

4. OPERATION

4.1. Arming the System

- **Arm Away:** Activates all sensors. Use when leaving the premises. Enter your PIN on the control panel, press the 'Arm Away' button on the remote, or use the mobile app.

- **Arm Home:** Activates perimeter sensors (e.g., door/window sensors) while allowing free movement inside. Enter your PIN, press the 'Arm Home' button on the remote, or use the mobile app.

4.2. Disarming the System

To disarm the system, enter your PIN on the control panel, press the 'Disarm' button on the remote, or use the mobile app. This will deactivate all sensors and silence any active alarms.

4.3. SOS Function

In an emergency, press the SOS button on the control panel or remote control. The system will immediately trigger the siren and send emergency notifications (calls/SMS) to pre-programmed numbers.

4.4. Remote Control Functions

The remote controls typically feature buttons for Arm Away, Arm Home, Disarm, and SOS. Refer to the remote control's specific markings for exact functions.

4.5. App Control

The mobile app provides a comprehensive interface for managing your alarm system, including:

- Arming/Disarming the system remotely.
- Receiving real-time alarm notifications.
- Viewing system status and event history.
- Adding or removing sensors and accessories.
- Adjusting system settings, such as entry/exit delays and siren volume.

5. MAINTENANCE

5.1. Battery Replacement

Wireless sensors and remote controls are powered by batteries. The system will typically alert you when a sensor's battery is low. Replace batteries promptly to ensure continuous protection.

- **Sensors:** Open the sensor casing, remove the old battery, and insert a new one of the same type (e.g., CR2032 for small sensors, AA/AAA for larger ones).
- **Remote Controls:** Open the remote control casing, replace the battery (typically CR2032 or similar button cell), and reassemble.

5.2. Cleaning

Regularly clean the main control panel and sensors with a soft, dry cloth. Avoid using abrasive cleaners or solvents that could damage the devices.

5.3. System Updates

Periodically check for firmware updates for your main control panel via the mobile app or URMET's official website. Updates can improve performance, add new features, and enhance security.

6. TROUBLESHOOTING

- **System not powering on:** Ensure the power adapter is securely connected to both the panel and the power outlet. Check the outlet for power.

- **Sensors not pairing:** Ensure sensors are within range of the control panel. Check sensor batteries. Follow pairing instructions carefully.
- **False alarms:** Check sensor placement to avoid environmental triggers (e.g., direct sunlight on PIR sensors, loose doors/windows). Adjust sensor sensitivity if applicable.
- **No 3G signal:** Ensure the SIM card is correctly inserted and active. Check your mobile network coverage in the installation area.
- **App connectivity issues:** Ensure your control panel is connected to Wi-Fi and your mobile device has internet access. Restart both the app and the control panel.

For more detailed troubleshooting, refer to the full user manual provided with your kit or visit the SIMON URMET support website.

7. SPECIFICATIONS

Feature	Detail
Manufacturer	URMET
Item Model Number	UTD1051/901
Product Dimensions	1 x 1 x 1 cm
Item Weight	10 g
Color	White or Silver
Style	Minimalist
Material	Metal
Power Source	Battery Powered
Installation Method	Self-adhesive
Number of Items	1 (Main Control)
Compatible Devices	Smartphone
Battery Type	Lithium Ion

8. WARRANTY AND SUPPORT

Your URMET 1051/901 Zeno Wireless 3G Integrated Alarm System comes with a manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions. For technical support, product inquiries, or service requests, please visit the official SIMON URMET website or contact their customer service department.

No official product videos from the seller were found for the URMET 1051/901 model in the provided data. Videos for other brands were excluded to maintain product relevance.

