

## Timex T26481

# Timex Men's Charles Street Watch T26481 Instruction Manual

Model: T26481

## 1. INTRODUCTION

This manual provides instructions for the proper setup, operation, and maintenance of your Timex Men's Charles Street Watch, Model T26481. Please read these instructions carefully to ensure optimal performance and longevity of your timepiece.

## 2. SETUP

### 2.1 Setting the Time and Date

- 1. Pull the Crown:** Gently pull the crown (the small knob on the side of the watch case) out to position 2. This is typically the first click.
- 2. Set the Date:** Turn the crown clockwise or counter-clockwise to adjust the date. Continue turning until the correct date is displayed.
- 3. Pull the Crown Further:** Pull the crown out to position 3. This is typically the second click. The second hand will stop moving.
- 4. Set the Time:** Turn the crown to move the hour and minute hands. To ensure the AM/PM is set correctly, advance the hands past 12 o'clock. If the date changes, it is midnight (AM). If the date does not change, it is noon (PM). Continue setting the time to the desired hour and minute.
- 5. Push the Crown In:** Once the time and date are set, push the crown fully back into position 1 (against the watch case) to start the watch.

*Note: The day display may require advancing the time through 24-hour cycles to change. If the day changes around midnight, the AM/PM is correctly set.*

### 2.2 Adjusting the Expansion Band

The Timex Charles Street Watch features a two-tone stainless steel expansion band designed to fit a

range of wrist sizes. This band expands to allow the watch to slide over your hand and then contracts to fit your wrist. If the band is too loose or too tight, professional adjustment by a jeweler may be required to remove or add links.





Front view of the Timex Charles Street Watch, showcasing the dial and two-tone expansion band.



Side view of the Timex Charles Street Watch, showing the crown for time and date adjustment.

### 3. OPERATING THE WATCH

#### 3.1 Indiglo Night-Light

Your Timex Charles Street Watch features the Indiglo night-light for easy readability in low-light conditions. To activate the Indiglo night-light, simply **press and hold the crown**. The entire dial will illuminate evenly.

#### 3.2 Water Resistance

This watch is water resistant to 30 meters (100 feet). This rating means the watch is suitable for splashes or brief immersion in water. It is **not recommended** for swimming, bathing, or diving. Always ensure the crown is fully pushed in before any contact with water.







Back view of the Timex Charles Street Watch, showing the case back with water resistance rating.

## 4. MAINTENANCE

### 4.1 Cleaning Your Watch

To maintain the appearance of your watch, wipe the case and band regularly with a soft, dry cloth. For water-resistant models, a slightly damp cloth can be used, followed by a dry cloth. Avoid using chemical cleaners, as they may damage the watch's finish.

### 4.2 Battery Replacement

The watch is powered by one Lithium Metal battery (CR2016). When the watch stops running or the Indiglo light dims significantly, the battery may need replacement. It is recommended to have the battery replaced by a qualified watch technician to ensure proper sealing and maintain water resistance.

## 5. TROUBLESHOOTING

- **Watch Not Running:** Ensure the crown is fully pushed in against the watch case. If the watch still does not run, the battery may need replacement.
- **Indiglo Not Working:** If the Indiglo light does not activate when the crown is pressed, the battery may be low or depleted.
- **Day/Date Not Changing:** Ensure the time is set correctly for AM/PM. The day and date typically advance around midnight. If the issue persists, consult a watch technician.
- **Inaccurate Time:** If the watch is consistently running fast or slow, it may require servicing by a professional watch repairer.

## 6. SPECIFICATIONS

Feature	Detail
Model Name	Charles Street
Model Number	T26481
Case Material	Brass
Case Diameter	35 Millimeters
Case Thickness	8 Millimeters
Band Material	Stainless Steel
Band Width	16 Millimeters
Band Length	8 Inches
Dial Color	Black

Crystal Material	Mineral
Watch Movement Type	Quartz
Water Resistance Depth	30 Meters (100 Feet)
Battery Type	1 Lithium Metal (CR2016)
Item Weight	1.92 ounces

## 7. WARRANTY AND SUPPORT

---

Your Timex Charles Street Watch is covered by a manufacturer's warranty. For specific details regarding the warranty period and coverage, please refer to the warranty information provided with your purchase or visit the official Timex website. For technical support or service inquiries, please contact Timex customer service directly.

## 8. PRODUCT VIDEOS

---

### Timex Men's T26481 Charles Street Two-Tone Expansion Band Watch Overview

Your browser does not support the video tag.

This video provides a general overview of the Timex Men's T26481 Charles Street Two-Tone Expansion Band Watch, demonstrating its features and design.

### Timex Watch Sizing Chart

Your browser does not support the video tag.

This video from Timex Corporation provides guidance on how to size Timex watches, which can be helpful for understanding the fit of your Charles Street Watch.