



[Manuals.plus](#) /

> [soges](#) /

> soges 47 Inch Computer Desk Trestle Desk Instruction Manual (Model CS-Tplus-120MO)

soges CS-Tplus-120MO

soges 47 Inch Computer Desk Trestle Desk Instruction Manual

Model: CS-Tplus-120MO

1. INTRODUCTION

This manual provides comprehensive instructions for the assembly, operation, maintenance, and troubleshooting of your soges 47 Inch Computer Desk. Please read this manual thoroughly before assembly and use to ensure proper function and longevity of your product. Keep this manual for future reference.



Image 1.1: soges 47 Inch Computer Desk in White Oak with Trestle Base and Side Shelves.

2. SAFETY INFORMATION

Please observe the following safety guidelines to prevent injury or damage to the product:

- Ensure all components are securely fastened before use. Regularly check and tighten screws as needed.
- Do not exceed the maximum weight capacity of 222 lbs (100 kg) on the desktop.
- Keep small parts and packaging materials away from children to prevent choking hazards.
- Assemble the desk on a soft, clean surface to avoid scratching the finish.
- Avoid placing hot items directly on the desk surface without protection.
- Do not stand or sit on the desk.

3. PACKAGE CONTENTS

Verify that all parts are present and undamaged before beginning assembly. If any parts are missing or damaged, please contact customer support.

- Desktop Panel (1)
- Left Trestle Frame (1)
- Right Trestle Frame (1)
- Shelf Panels (2)
- Crossbar (1)
- Assembly Hardware (Screws, Nuts, Washers, Allen Wrench)




Image 3.1: Diagram showing dimensions and main components of the Soges 47 Inch Computer Desk.

4. SETUP AND ASSEMBLY INSTRUCTIONS

Assembly typically takes approximately 1 hour with one person. All necessary tools are included.

1. **Prepare the Area:** Clear a spacious, clean, and soft area for assembly to prevent damage to the desk components.
2. **Identify Components:** Lay out all parts and hardware. Refer to Image 3.1 to identify each piece.
3. **Assemble Trestle Frames:** Attach the crossbar between the two trestle frames using the provided screws and Allen wrench. Ensure all connections are finger-tight at this stage.
4. **Attach Shelves:** Decide whether you want the shelves on the left or right side of the desk. Secure the two shelf panels to the designated trestle frame using the appropriate hardware. The shelves are designed to be reversible.
5. **Position Desktop:** Carefully place the desktop panel onto the assembled trestle frames. Align the pre-drilled holes on the underside of the desktop with the holes on the top of the trestle frames.

6. **Secure Desktop:** Fasten the desktop to the frames using the remaining screws. Once all screws are in place, fully tighten all connections on the entire desk.



SHELVES CAN BE INSTALLED ON THE LEFT OR RIGHT



Image 4.1: Illustration demonstrating reversible shelf installation options.



2-tier open shelves provide enough storage. And the removable shelf for a computer tower.



Image 4.2: Detail of the two-tier open shelves, including space for a computer tower.

5. OPERATING INSTRUCTIONS

Your soges computer desk is designed for versatile use in home or office environments. The spacious desktop provides ample room for a computer, monitor, and other work essentials.

- **Utilize Storage:** The two-tier open shelves offer convenient storage for books, office supplies, decorative items, or a computer tower. The removable shelf allows for flexible configuration.
- **Placement:** Position the desk on a level surface to ensure stability.
- **Weight Distribution:** Distribute weight evenly across the desktop and shelves to maintain balance and prevent stress on the structure.



Image 5.1: soges 47 Inch Computer Desk in a typical home office setup.

6. MAINTENANCE

To keep your desk in optimal condition, follow these maintenance guidelines:

- **Cleaning:** Wipe the desk surface and metal frame with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, which can damage the finish.
- **Spills:** Clean up spills immediately to prevent staining or damage to the engineered wood.
- **Hardware Check:** Periodically check all screws and bolts to ensure they are tight. Re-tighten if necessary to maintain stability.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fading or discoloration of the wood finish.



Image 6.1: Close-up of the white oak wood finish.

7. TROUBLESHOOTING

If you encounter any issues with your desk, refer to the following common solutions:

- **Desk Wobbles:** Ensure the desk is on a level surface. Check all assembly screws and tighten them firmly. Uneven floors may require shims under the legs.
- **Parts Don't Align:** Loosen all screws slightly, adjust the components to align, then re-tighten all screws evenly. Avoid overtightening initially during assembly.
- **Missing Hardware:** Double-check all packaging materials. If hardware is genuinely missing, contact customer support for replacements.
- **Scratches/Dents:** For minor surface imperfections, wood repair kits or markers matching the finish color may be used.

8. SPECIFICATIONS

Feature	Detail
Model Number	CS-Tplus-120MO
Product Dimensions (L x W x H)	47.24" x 23.62" x 29.53" (120cm x 60cm x 75cm)
Item Weight	19 Kilograms (41.89 lbs)
Maximum Weight Recommendation	222 Pounds (100 kg)
Material Type	Engineered Wood, Metal
Color	White Oak
Number of Shelves	2
Assembly Required	Yes
Includes All Assembly Tools	Yes

9. WARRANTY AND SUPPORT

This product comes with a Limited Warranty. For specific details regarding warranty coverage, please refer to the warranty card included with your purchase or contact soges customer service.

For technical support, missing parts, or any other inquiries, please contact soges customer support through the retailer's platform or the official soges website. Please have your model number (CS-Tplus-120MO) and purchase information ready when contacting support.

© 2023 soges. All rights reserved.