

[Manuals.plus](#) /

> [Panasonic](#) /

> Panasonic Viera TH-32F300 32-inch LCD TV User Manual

Panasonic TH-32F300

Panasonic Viera TH-32F300 32-inch LCD TV

User Instruction Manual

INTRODUCTION

This manual provides detailed instructions for the safe and efficient use of your Panasonic Viera TH-32F300 32-inch LCD TV. Please read this manual thoroughly before operating the unit and keep it for future reference.

The Panasonic Viera TH-32F300 is a 32-inch High-Vision LCD TV featuring an IPS panel for wide viewing angles and energy-efficient LED backlighting. Key features include:

- **Simultaneous Program Recording:** Record one program while watching another (requires external USB HDD).
- **IPS Panel:** Enjoy clear and vibrant images from various viewing angles.
- **Room Jump Link:** Stream live or recorded programs from compatible Panasonic Viera TVs or DIGA recorders on your home network to this unit in another room.

SETUP

Unpacking and Assembly

Carefully remove the TV and all accessories from the packaging. Place the TV on a stable, flat surface or mount it securely using a VESA-compatible wall mount (200x200mm).

Note: A Phillips head screwdriver is required for stand assembly (if applicable).

Physical Dimensions and Weight

- **Dimensions (with stand):** 73.3 cm (Width) x 47.8 cm (Height) x 18.4 cm (Depth)
- **Dimensions (without stand):** 73.3 cm (Width) x 43.7 cm (Height) x 6.9 cm (Depth)
- **Weight (with stand):** Approx. 6.0 kg
- **Weight (without stand):** Approx. 5.5 kg

Connecting Cables

Refer to the diagram below for connection points. Ensure all cables are securely connected.



●イラストはイメージ

TH-32F300サイズ
(テレビスタンド含む)

奥行：
184mm

幅：733mm



高さ：478mm

サイズ	32 v
パネル	IPS×LED
解像度	1,366×766
チューナー数	 ×2  ×2  ×2
裏番組対応モデル	○
HDD容量	—
USB HDD接続	○
裏番組録画	○※
壁掛け	—
HDMI端子数	2
消費電力	69W

※別売のハードディスクが必要です

Image: Rear connection ports of the Panasonic Viera TH-32F300 TV, showing inputs for B-CAS card, USB, HDMI, LAN, and antenna.

1. **B-CAS Card Slot:** Insert your B-CAS card here.
2. **USB Port:** Connect an external USB hard disk drive for recording.
3. **Headphone/Earphone Jack:** Connect headphones for private listening.
4. **HDMI 1~2 Ports:** Connect external devices such as Blu-ray players, game consoles, or PCs.
5. **Video Input Terminal:** Connect older video devices.
6. **Terrestrial Digital Antenna Terminal:** Connect your terrestrial digital antenna.
7. **BS/CS Antenna Terminal:** Connect your BS/CS satellite antenna.
8. **LAN Port:** Connect to your home network for internet services and Room Jump Link.

Initial Setup

After connecting all necessary cables, plug the power cord into an electrical outlet. The TV will guide you through the initial setup process, including language selection, channel scanning, and network configuration. Follow the on-screen instructions.




Image: Illustration depicting the easy on-screen setup process for the TV.

OPERATING INSTRUCTIONS

Basic TV Functions

Use the supplied remote control to power on/off the TV, change channels, adjust volume, and access menus. The remote control is designed for intuitive navigation.

Simultaneous Program Recording

Your TV is equipped with dual tuners, allowing you to record one program to an external USB hard disk drive while watching another. To use this feature:

1. Connect a compatible external USB hard disk drive to the TV's USB port.
2. Format the HDD via the TV's menu (refer to the on-screen guide for instructions).
3. Press the 'Program Guide' button on your remote to select programs for recording.

別室で録画した番組を見られる

「お部屋ジャンプリンク」



(有線LAN接続対応)

※「お部屋ジャンプリンク」に対応のディーガ

●ホームネットワーク (LAN) 接続と設定が必要になります



操作はリモコンの
「お部屋ジャンプリンク」
を押すだけ

●写真・イラストはイメージです。

Image: Diagram illustrating the simultaneous recording feature, where a program is recorded to an external HDD while another is viewed.
An external hard disk is required.

IPS Panel Viewing

The IPS panel technology provides a wide viewing angle, ensuring consistent picture quality and color accuracy even when viewed from the side. This minimizes color shift and contrast degradation, offering a clear image from almost any position.

放送中の番組を見ながら裏番組を 録画できる※「裏番組録画」



※別売のハードディスクが必要です



操作はリモコンの 「番組表」ボタンから

●写真・イラストはイメージです。

Image: A visual comparison demonstrating the superior clarity and color retention of an IPS panel when viewed from an angle, compared to a standard panel.

Room Jump Link

If you have a home LAN environment and compatible Panasonic Viera or DIGA devices, you can use the 'Room Jump Link' feature to stream live broadcasts or recorded programs from those devices to your TH-32F300 TV in another room.

1. Ensure your TV and other compatible devices are connected to the same home network (LAN).
2. On your TH-32F300 remote, press the 'Room Jump Link' button.
3. Select the desired program from the list of available content on your network.

番組表を新聞のテレビ欄のように表示できる [番組ガイド]



The screenshot displays the VIERA Program Guide interface. At the top, it shows the current time (17:21) and the selected channel (VIERA). Below this, there's a grid of program listings for various channels (PNA, CAM, SVS, etc.) and time slots (17:00, 18:00, 19:00, 20:00, 21:00, 22:00, 23:00, 0:00). Each entry includes the program title, channel, and time. For example, at 17:00, PNA channel 1 shows 'タカノニュース' and CAM channel 1 shows 'カメメテレビ1'. The interface also includes navigation buttons like 'サブメニュー', '戻る', '広告詳細', and 'チャンネル別表示'.

●写真はイメージです。




操作はリモコンの
「番組表」
を押すだけ

Image: Diagram illustrating the 'Room Jump Link' feature, showing content being transferred from a living room TV/recorder to the TH-32F300 in a separate room over a home network.

Program Guide (EPG)

Access the Electronic Program Guide (EPG) by pressing the 'Program Guide' button on your remote control. This displays a detailed schedule of current and upcoming programs across all available channels.

背面接続図



- | | |
|----------------|----------------|
| 1 B-CASカード挿入口 | 5 ビデオ入力端子 |
| 2 USB端子 | 6 地上デジタルアンテナ端子 |
| 3 ヘッドホン/イヤホン端子 | 7 BS・CSアンテナ端子 |
| 4 HDMI 1~2端子 | 8 LAN端子 |

Image: Screenshot of the TV's electronic program guide (EPG) displaying channel listings and program schedules.

Using as a PC Monitor

The TV can also function as a PC monitor by connecting your computer via an HDMI cable. This model features two HDMI ports for versatile connectivity.

VIERAUSB/ハードディスク
裏番組録画対応

32型液晶テレビ

TH-32F300

Image: The Panasonic TH-32F300 TV displaying data from a connected laptop, demonstrating its use as a PC monitor.

MAINTENANCE

Cleaning the Screen

Gently wipe the screen with a soft, dry, lint-free cloth. For stubborn marks, slightly dampen the cloth with water or a specialized screen cleaner. Avoid using harsh chemicals, abrasive materials, or excessive pressure.

Cleaning the TV Body

Wipe the TV's exterior with a soft, dry cloth. Do not use solvents or alcohol-based cleaners, as they may damage the finish.

General Care

- Unplug the TV from the power outlet before cleaning or when not in use for extended periods.
- Keep the TV away from direct sunlight, heat sources, and excessive moisture.
- Ensure proper ventilation around the TV to prevent overheating.

TROUBLESHOOTING

If you encounter any issues with your TV, please refer to the following common solutions before contacting support.

No Power / No Picture

- Check if the power cord is securely plugged into both the TV and the wall outlet.
- Ensure the TV is turned on using the remote control or the power button on the TV.
- Verify that the correct input source is selected (e.g., HDMI 1, TV).

No Signal / Poor Picture Quality

- Check all antenna and HDMI cable connections for looseness or damage.
- Ensure your B-CAS card is correctly inserted into the slot.
- Perform a channel scan from the TV's menu to update available channels.

- If using as a PC monitor, adjust your PC's display settings (resolution, refresh rate) to match the TV's capabilities.

Remote Control Not Working

- Replace the batteries in the remote control.
- Ensure there are no obstructions between the remote and the TV's sensor.

Recording Issues

- Confirm that a compatible external USB hard disk drive is connected and properly formatted.
- Check if the HDD has sufficient free space.

SPECIFICATIONS

Feature	Detail
Screen Size	32 inches
Panel Type	IPS x LED
Resolution	1,366 x 768 (High-Vision)
Refresh Rate	60 Hz
Aspect Ratio	16:9
Tuners	Terrestrial Digital x2, BS x2, CS x2
HDMI Ports	2
USB Ports	1 (for external HDD)
LAN Port	1
Audio Output	10W (5W + 5W) JEITA
Power Consumption	69 W (Standby: approx. 0.1 W)
VESA Mount Standard	200 x 200 mm
Supported Internet Services	Actvila

WARRANTY AND SUPPORT

Warranty Information

Please refer to the warranty card included with your product for detailed warranty terms and conditions. Keep your proof of purchase for warranty claims.

Customer Support

For repairs or technical assistance regarding your Panasonic product, please contact the Panasonic Repair Consultation

Service.

- **Telephone:** 0120-878-554
- **Operating Hours:** 9:00 AM - 7:00 PM (Daily)
- **Special Hours (Sundays, Public Holidays, Year-end/New Year):**9:00 AM - 5:30 PM

You can also search for "Panasonic Repair" online for more information.

© 2024 Panasonic Corporation. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question