

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [KICKER](#) /
- › [KICKER 6.5" Silver Marine Speakers User Manual](#)

KICKER 41KM654

KICKER 6.5" Silver Marine Speakers User Manual

Model: 41KM654

Brand: KICKER

PRODUCT OVERVIEW

The KICKER 6.5" Silver Marine Speakers are designed for high-quality audio reproduction in marine environments. This pair of OEM replacement speakers features a water-resistant design, ensuring durability and reliable performance on the water. They come with silver grilles, offering a sleek aesthetic that complements various boat interiors.



Image: A pair of KICKER 6.5 inch silver marine speakers, showing both speakers with their silver grilles. A KICKER branded can cooler is also visible in the bottom left corner.

KEY FEATURES

- Includes Silver grilles for a stylish finish.
- Water resistant design for many years of use on the water.
- Designed as OEM replacement speakers.
- Durable construction suitable for marine environments.

WHAT'S IN THE Box

Your package should contain the following items:

- 1 Pair of Kicker 6.5 Inch KM OEM Marine Speakers with Silver grilles.

Note: These speakers do not come with a retail box or other accessories. They will arrive in plain brown packaging.

SETUP AND INSTALLATION

Proper installation is crucial for optimal performance and longevity of your marine speakers. It is recommended to have installation performed by a qualified professional if you are unfamiliar with marine audio systems.

Mounting Considerations:

- **Location:** Choose a mounting location that is secure, provides adequate clearance for the speaker's depth, and is away from direct exposure to extreme elements beyond its water resistance rating.
- **Cutting Template:** A cutting template is not included with these speakers. Carefully measure the required hole diameter (typically 6.5 inches for the speaker cone, with additional clearance for the frame) before cutting. Ensure the mounting surface is flat and sturdy.
- **Wiring:** Connect the speaker wires to your marine audio amplifier or head unit. Pay close attention to polarity (positive to positive, negative to negative) to ensure correct phase and sound quality. The speakers have an impedance of 4 Ohm.
- **Sealing:** Ensure a proper seal around the speaker mounting area to prevent water ingress into the boat's interior.



Image: This image provides a rear view of a KICKER marine speaker, highlighting the robust magnet structure and the blue and black wiring terminals for connection.

OPERATING INSTRUCTIONS

Once installed, operate your KICKER marine speakers through your connected marine audio system. Ensure your amplifier or head unit is properly configured for 4-ohm speakers.

- **Power On/Off:** Turn on your marine audio system. The speakers will receive power and audio signals from the connected amplifier or head unit.
- **Volume Control:** Adjust the volume level through your audio system. Avoid excessively high volumes that cause distortion, as this can damage the speakers.

- **Audio Settings:** Utilize the audio settings on your head unit or amplifier (e.g., bass, treble, balance, fader) to optimize sound quality for your listening environment.

MAINTENANCE

Regular maintenance will help prolong the life and performance of your marine speakers.

- **Cleaning:** Periodically wipe down the speaker grilles and surrounds with a soft, damp cloth to remove salt, dirt, and debris. Avoid using harsh chemicals or abrasive cleaners.
- **Inspection:** Regularly inspect the speaker cones, surrounds, and grilles for any signs of damage or wear. Check wiring connections for corrosion or looseness.
- **Water Exposure:** While water-resistant, avoid submerging the speakers. If exposed to heavy spray or rain, allow them to dry thoroughly.
- **Storage:** If storing your boat for extended periods, especially in harsh conditions, consider covering the speakers or storing the boat in a protected environment.

TROUBLESHOOTING

If you encounter issues with your KICKER marine speakers, refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
No Sound from Speakers	Power off/disconnected amplifier/head unit. Loose or incorrect wiring connections. Blown fuse in audio system. Speaker damage.	Ensure audio system is powered on and connected. Check all wiring for secure and correct polarity. Inspect and replace any blown fuses. Inspect speakers for visible damage; if damaged, replacement may be necessary.
Distorted Sound	Volume too high, causing clipping. Incorrect audio settings (e.g., bass boost too high). Loose wiring or poor connection. Speaker impedance mismatch.	Reduce volume to a comfortable level. Adjust audio settings on head unit/amplifier. Check and secure all wiring connections. Ensure amplifier is compatible with 4-ohm speakers.
Speakers Not as Advertised (e.g., wattage)	Product mislabeling or incorrect item received.	Verify the model number and specifications on the speaker itself against the product description. Contact the seller or KICKER customer support for clarification or resolution if there is a discrepancy.

SPECIFICATIONS

Model Name	(2)41BKM614S
Item Model Number	41KM654
Speaker Type	Outdoor
Special Feature	Waterproof
Subwoofer Diameter	6.5 Inches
Color	Silver
Item Weight	6.5 Pounds
Impedance	4 Ohm
Water Resistance Level	Water Resistant
Speaker Size	6.5 Inches
Vehicle Service Type	Boat
Speaker Maximum Output Power	195 Watts
Mounting Type	Boat Mount
Manufacturer	Kicker
Package Dimensions	15.04 x 8.15 x 5.71 inches
UPC	841992120396

WARRANTY AND SUPPORT

These KICKER marine speakers come with a **Limited Warranty**. For specific details regarding the warranty period and coverage, please refer to the documentation provided with your purchase or contact the manufacturer directly.

For technical support, installation assistance, or warranty claims, please contact KICKER customer service or the authorized seller from whom you purchased the product. The seller for this product is **Creative Audio**.

You can often find support contact information on the manufacturer's official website or through your purchase invoice.



Image: The 'Creative Audio' logo, identifying the seller as a leader in mobile electronics.

For further assistance, please visit the [KICKER Official Website](#) or contact your retailer.