



[Manuals.plus](#) /

› [Outsunny](#) /

› Outsunny 41 Gallon Outdoor Storage Bench (Model 84B-211) Instruction Manual

Outsunny 84B-211

Outsunny 41 Gallon Outdoor Storage Bench (Model 84B-211) Instruction Manual

Brand: Outsunny | Model: 84B-211

PRODUCT OVERVIEW

The Outsunny 41 Gallon Outdoor Storage Bench is a versatile piece of outdoor furniture designed to provide both comfortable seating and ample storage. Crafted from durable acacia wood, it features a spacious compartment with a waterproof PE lining, making it suitable for various outdoor items. This bench is ideal for patios, decks, gardens, balconies, and yards.



Image: The Outsunny 41 Gallon Outdoor Storage Bench, showcasing its teak finish and dual functionality as a bench and storage unit.

Key Features:

- **Multi-Functional Design:** Serves as both a 2-seat patio bench and a spacious outdoor storage solution.
- **Durable Construction:** Made from solid, weather-resistant acacia wood for longevity.
- **Waterproof Storage:** Features a removable waterproof PE lining to protect stored items from moisture.
- **High Weight Capacity:** Designed to accommodate up to 485 lbs.
- **Comfortable Seating:** Includes a backrest for added comfort.

SETUP AND ASSEMBLY

Assembly of the Outsunny Storage Bench requires careful attention to detail. It is recommended to have a drill or screwdriver for efficient assembly. Follow the provided instructions step-by-step.

Assembly Tips:

1. **Initial Fastening:** When attaching components, initially tighten screws only halfway. This allows for flexibility to align all pieces correctly before fully tightening.
2. **Lid Hinge Installation:** The lid features gas springs for smooth opening and closing. Before attaching

the gas springs, ensure the small plastic caps on the ends of the springs are removed. These caps cover the attachment points.

3. **Pre-drilled Holes:** Utilize the pre-drilled holes for installing the gas springs and other hardware. Attempting to create new holes or misaligning the springs can prevent the lid from closing properly or cause damage. Ensure the silver rod of the gas spring has sufficient clearance from the side wood when installed.
4. **Backrest and Sides:** Assemble the front and side panels first. Then, carefully position the backrest, ensuring all dowels and connections align before tightening.
5. **Final Tightening:** Once all components are correctly aligned and loosely assembled, proceed to fully tighten all screws for a secure and stable structure.

PE LINING

The removable storage bag is perfect for storing garden tools and toys.



Image: Detail of the safety pneumatic rod, which prevents the lid from slamming shut. Proper installation is crucial for its function.

For a visual guide on the product, please refer to the official video below:

Video: Official product overview of the Outsunny Garden Bench 84B-211, demonstrating its features and design.

OPERATING INSTRUCTIONS


Using the Bench:

- **Seating:** The bench is designed to comfortably seat two people with a maximum weight capacity of 485 lbs.
- **Lid Operation:** To access the storage compartment, gently lift the seat. The pneumatic rods will assist in holding the lid open. To close, gently push the lid down until it latches securely.

Using the Storage Compartment:

- **Waterproof Lining:** The storage compartment includes a removable waterproof PE lining. Ensure this lining is properly installed and secured to protect contents from moisture.
- **Storage Capacity:** The compartment offers 41 gallons of storage space, ideal for gardening tools, pool accessories, outdoor cushions, or toys.
- **Weight Distribution:** Avoid placing excessively heavy items directly on the bottom planks of the storage area, as they are thinner than the main frame. Distribute weight evenly.

SOLID ACACIA WOOD FRAME



Sturdy



Weather
-resistant



Corrosion
-resistant



Durable



Image: The removable waterproof PE lining, designed to keep stored items dry and protected.

MAINTENANCE

Proper maintenance will extend the life and appearance of your Outsunny Storage Bench.

- **Cleaning:** Wipe the acacia wood surfaces with a dry cloth to remove dust and debris. For deeper cleaning, use a damp cloth with mild soap and water, then dry thoroughly.
- **Weather Protection:** Although made from weather-resistant wood, prolonged exposure to harsh weather conditions (extreme sun, heavy rain, snow) can affect its longevity. Consider using a furniture cover during off-seasons or severe weather.
- **Wood Care:** The bench has a varnished finish. Periodically inspect the wood for any signs of wear or fading. Re-varnishing or applying a wood sealant may be necessary over time to maintain its appearance and protective qualities.
- **Hardware Check:** Regularly inspect all screws and bolts to ensure they remain tight. Tighten any loose fasteners to maintain structural integrity.
- **PE Lining Care:** The waterproof PE lining can be removed and cleaned separately. Ensure it is dry before placing it back into the compartment to prevent mold or mildew.

TROUBLESHOOTING

If you encounter any issues with your storage bench, refer to the following common solutions:

- **Lid Not Closing Properly:**
 - Check the installation of the gas springs. Ensure they are correctly attached to the pre-drilled holes and have proper clearance from the side panels.
 - Verify that no items in the storage compartment are obstructing the lid's path.
- **Bench Feels Unstable/Wobbly:**
 - Ensure all screws and bolts are fully tightened.
 - Confirm the bench is placed on a flat, level surface. Uneven ground can cause instability.
- **Water Accumulation in Storage:**
 - Check if the waterproof PE lining is correctly installed and sealed.
 - Ensure the lid is fully closed and latched.
- **Wood Discoloration/Damage:**
 - For minor discoloration, cleaning and re-application of wood sealant or varnish may help.
 - For significant damage, contact customer support for replacement parts or repair advice.

SPECIFICATIONS

2-IN-1 DESIGN



Deck Bench



Garden Bench

Image: Detailed dimensions of the storage bench for planning placement.

Feature	Detail
Product Dimensions	23.5"D x 47.25"W x 34.25"H
Storage Chest Size	42.5" L x 16.5" W x 13.5" H
Color	Teak
Material	Acacia Wood
Furniture Finish	Varnished
Seat Height	17.75 Inches
Maximum Weight Recommendation	485 Pounds
Seating Capacity	2 people
Item Weight	41.8 pounds
Item Model Number	84B-211

Feature	Detail
UPC	842525117821

IMPORTANT SAFETY INFORMATION

- Do not exceed the maximum weight capacity of 485 lbs.
- For outdoor use only.
- Ensure the bench is placed on a flat, stable surface to prevent tipping.
- Keep children away during assembly. This item contains small parts that could be dangerous for children.
- Children should always be under direct adult supervision while using this product.