**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



**VTech 80-193847**

# VTech Kidizoom Smart Watch DX2 User Manual

Model: 80-193847

## 1. Introduction

Welcome to the VTech Kidizoom Smart Watch DX2 user manual. This guide provides comprehensive instructions for setting up, operating, and maintaining your new smart watch. The Kidizoom Smart Watch DX2 is designed for children, offering a range of features including dual cameras, games, a pedometer, and various time-telling functions.




*Image 1.1: The VTech Kidizoom Smart Watch DX2, showcasing its vibrant raspberry red color and main screen interface.*

## 2. Safety Information

Please read the following safety information carefully before using the VTech Kidizoom Smart Watch DX2.

- **Age Recommendation:** This product is not suitable for children under 36 months due to small parts. Recommended for ages 5-12 years.

- **Water Resistance:** The watch is **not water resistant**. Avoid submerging it in water or exposing it to heavy rain. Clean with a slightly damp cloth only.
- **Battery Safety:** The watch contains a rechargeable battery. Do not attempt to replace the battery yourself. Use only the provided USB charging cable.
- **Strap Care:** If skin irritation occurs, discontinue use and consult a doctor. Ensure the strap is not too tight.
- **Choking Hazard:** Keep the charging cable and small parts away from young children.

## 3. Package Contents

Ensure all items are present in the package:

- VTech Kidizoom Smart Watch DX2
- USB Charging Cable
- Quick Start Guide (if included)






*Image 3.1: The VTech Kidizoom Smart Watch DX2 displayed within its clear retail packaging.*

# 4. Setup

## 4.1. Charging the Watch

1. Connect the small end of the USB charging cable to the charging port on the side of the watch.
2. Connect the larger end of the USB cable to a USB port on a computer or a USB wall adapter (not included).
3. The watch screen will display a charging indicator. A full charge typically takes a few hours.
4. Disconnect the cable once fully charged. Average battery life is up to 3 days, depending on usage.

## 4.2. Powering On/Off

- **To Power On:** Press and hold the Home button (usually on the side) for a few seconds until the VTech logo appears.
- **To Power Off:** Press and hold the Home button for a few seconds. A power-off confirmation screen will appear. Tap 'Yes' to confirm.

# 5. Operating Instructions

The Kidizoom Smart Watch DX2 features a touchscreen for easy navigation.




*Image 5.1: A detailed view of the VTech Kidizoom Smart Watch DX2 screen, showing multiple application icons and a classic analog watch face.*

## 5.1. Navigating the Interface

- **Touchscreen:** Tap icons to select applications or options. Swipe left or right to scroll through menus or watch faces.
- **Home Button:** Press to return to the main watch face from any application.

- **Shutter Button:** (If present, usually on the side) Press to take photos or start/stop video recording when in camera mode.

## 5.2. Camera and Video

The watch features dual cameras: one front-facing for selfies and one on the side for capturing the environment.

1. From the main screen, tap the Camera icon.
2. Tap the camera switch icon on the screen to toggle between the front and side cameras.
3. Tap the Shutter icon on the screen or press the physical Shutter button to take a photo.
4. To record a video, tap the Video icon within the camera app, then tap the Record button to start/stop.
5. Explore various photo effects, frames, and filters available within the camera application.

## 5.3. Games and Activities

The watch comes pre-loaded with several games and activities, including augmented reality games, logic puzzles, and active play challenges.

- Tap the Games icon to access the game library.
- Select a game by tapping its icon.
- Follow on-screen instructions to play.
- **Pedometer:** Access the Pedometer app to track steps taken throughout the day.
- **Explor@Park:** Connect your watch to a computer and visit the VTech Explor@Park website to download additional games and content.

## 5.4. Clock Functions

The watch offers various clock features and customization options.

- **Watch Faces:** Swipe left or right on the main screen to change between over 50 digital and analog watch faces. You can also create custom watch faces using your photos.
- **Alarm:** Set alarms with custom sounds or recorded voice messages.
- **Timer & Stopwatch:** Access these tools from the main menu for various timing needs.
- **Calendar:** View the current date and month.

## 5.5. Voice Recorder

Record short voice messages and apply fun sound effects.

1. Tap the Voice Recorder icon.
2. Tap the Record button to start recording (up to 60 seconds).
3. Tap the Stop button to end recording.
4. Play back your recording and apply various voice-changing effects.

# 6. Maintenance

## 6.1. Cleaning

- Wipe the watch and strap with a slightly damp, soft cloth.
- Do not use chemical cleaners or abrasive materials.
- Ensure the watch is completely dry before use or charging.

### 6.2. Battery Care

- Avoid fully discharging the battery frequently.
- Charge the watch regularly, even if not in use for extended periods, to maintain battery health.
- Store the watch in a cool, dry place away from direct sunlight and extreme temperatures.

## 7. Troubleshooting

| Problem | Solution |
|---|---|
| Watch does not turn on. | Ensure the watch is fully charged. Press and hold the Home button for at least 10 seconds to perform a hard reset. |
| Screen is unresponsive. | Recharge the watch. If the issue persists, perform a hard reset by holding the Home button. |
| Cannot connect to computer. | Ensure the USB cable is properly connected. Try a different USB port or computer. Install any necessary drivers from the VTech website if prompted. |
| Photos/videos are blurry. | Ensure the camera lens is clean and free from smudges. Ensure adequate lighting. |

## 8. Specifications

- **Model Number:** 80-193847
- **Dimensions:** 22.44 x 1.72 x 4.39 cm
- **Weight:** 440 g
- **Display:** 1.4-inch LCD Touchscreen
- **Internal Memory:** 256 MB
- **Connectivity:** Bluetooth (for data transfer to computer via VTech software)
- **Battery:** Rechargeable Alkaline (average 3 days usage)
- **Case Material:** Plastic
- **Strap Material:** Silicone
- **Water Resistance:** Not water resistant
- **Recommended Age:** 5 - 12 years

## 9. Warranty and Support

### 9.1. Warranty

The VTech Kidizoom Smart Watch DX2 comes with a**2-year manufacturer's warranty** from the date of purchase. Please retain your proof of purchase for warranty claims. The warranty covers manufacturing defects but does not cover damage caused by misuse, accidents, or unauthorized repairs.

### 9.2. Customer Support

For further assistance, technical support, or to download additional content, please visit the official VTech website or the Explor@Park platform. You may also refer to the comprehensive PDF user manual available for download on the product support page.

© 2026 VTech. All rights reserved.

## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B07BQ9ZG2T**

More documents and user manuals: **https://manuals.plus/**