

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Trust](#) /

› [Trust Urban Bluetooth Wireless Headphones - Purple Over-Ear \(Model 22764\)](#)

Trust 22764

Trust Urban Bluetooth Wireless Headphones - Purple Over-Ear (Model 22764)

Instruction Manual

INTRODUCTION

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your Trust Urban Bluetooth Wireless Headphones, Model 22764. Please read this manual carefully before using the product to ensure proper functionality and to maximize your listening experience.



Image: Front view of the Trust Urban Bluetooth Wireless Headphones in purple.

SETUP

1. Charging the Headphones

Before first use, fully charge your headphones. A USB charging cable is included.

- Connect the small end of the USB charging cable to the charging port on the headphones.
- Connect the larger end of the USB cable to a USB power source (e.g., computer USB port, USB wall adapter).
- The LED indicator on the headphones will show the charging status. It typically turns off or changes color when fully charged.





Image: Side view of the headphones, highlighting the charging port and control buttons.

2. Bluetooth Pairing

To connect your headphones wirelessly to a device:

1. Ensure the headphones are charged and turned off.
2. Press and hold the Power button on the headphones until the LED indicator flashes rapidly (usually blue and red), indicating pairing mode.
3. On your device (smartphone, tablet, laptop), enable Bluetooth and search for new devices.
4. Select "Trust Dura" or a similar name from the list of available devices.
5. Once connected, the LED indicator on the headphones will typically flash slowly or turn solid blue.

The headphones have a wireless range of up to 10 meters.

3. Wired Connection (Optional)

You can also use the headphones with a 3.5mm audio cable (not always included, check packaging) for a wired connection, which is useful when the battery is low or for devices without Bluetooth.

- Connect one end of the 3.5mm audio cable to the headphone jack on the headphones.
- Connect the other end to the 3.5mm audio output of your device.
- The headphones will automatically switch to wired mode.

OPERATING INSTRUCTIONS

Power On/Off

- **Power On:** Press and hold the Power button for approximately 3 seconds.
- **Power Off:** Press and hold the Power button for approximately 3-5 seconds.

Music Playback

- **Play/Pause:** Press the Multi-function button (often the Power button) once.
- **Next Track:** Press and hold the Volume Up (+) button.
- **Previous Track:** Press and hold the Volume Down (-) button.

Volume Control

- **Increase Volume:** Press the Volume Up (+) button.
- **Decrease Volume:** Press the Volume Down (-) button.

Call Management

The headphones feature a built-in microphone for hands-free calls.

- **Answer/End Call:** Press the Multi-function button once.
- **Reject Call:** Press and hold the Multi-function button for approximately 2 seconds.
- **Redial Last Number:** Double-press the Multi-function button.

Voice Assistant

Quickly access your smartphone's voice assistant (Siri, Google Assistant, etc.):

- **Activate Voice Assistant:** Press the Voice Assistant button (if available, or a specific combination as per device). Refer to your device's manual for specific button functions if not clearly marked.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the headphones. Do not use abrasive cleaners or solvents.
- **Storage:** Store the headphones in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the headphones regularly, even if not in use for extended periods.
- **Avoid Moisture:** Do not expose the headphones to water or excessive moisture.

TROUBLESHOOTING

Problem	Solution
Headphones do not turn on.	Ensure the headphones are fully charged. Connect them to a power source using the USB cable.
Cannot pair with a device.	<ul style="list-style-type: none">◦ Ensure Bluetooth is enabled on your device.◦ Make sure the headphones are in pairing mode (LED flashing rapidly).◦ Move the headphones closer to your device.◦ Forget the device from your phone's Bluetooth settings and try pairing again.◦ Restart both the headphones and your device.
No sound or low volume.	<ul style="list-style-type: none">◦ Check the volume levels on both the headphones and your connected device.◦ Ensure the headphones are properly connected via Bluetooth or the 3.5mm cable.◦ If using Bluetooth, ensure the device is within the 10m wireless range.
Microphone not working.	<ul style="list-style-type: none">◦ Ensure the headphones are properly connected via Bluetooth.◦ Check your device's audio input settings to ensure the headphone microphone is selected.

SPECIFICATIONS

Model Name	Dura
Model Number	22764
Brand	Trust
Color	Purple
Form Factor	Over-ear
Connectivity Technology	Wireless (Bluetooth), Wired (3.5mm jack)
Wireless Range	10 meters
Battery Life (Playtime)	Up to 6 hours
Battery Type	Lithium-ion (rechargeable, included)
Charging Port	USB (cable included)
Built-in Microphone	Yes
Control Type	Buttons for volume, media, call management, voice assistant access
Compatible Devices	Mobile phones, Tablets, Laptops, Desktop computers
Material	Plastic
Product Dimensions	4 x 5.5 x 9.5 cm; 190 g

WARRANTY INFORMATION

Trust products are manufactured to high quality standards. For detailed warranty terms and conditions, please refer to the official Trust website or the warranty card included with your purchase. Typically, Trust offers a limited warranty against defects in materials and workmanship from the date of original purchase. Please retain your proof of purchase for any warranty claims.

SUPPORT

For further assistance, technical support, or frequently asked questions, please visit the official Trust support website:

www.trust.com/support

You may also find additional resources and contact information on their website.