Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Picket House UAZ540100G

Picket House Furnishings Regal Accent Chair

Model: UAZ540100G | Brand: Picket House

Introduction

Thank you for choosing the Picket House Furnishings Regal Accent Chair. This manual provides essential information for the proper use, care, and maintenance of your new furniture. Please read it thoroughly to ensure long-lasting enjoyment of your accent chair.



Image: The Picket House Furnishings Regal Accent Chair, showcasing its elegant design and taupe upholstery in a home environment.

Safety Information

To prevent injury or damage to your furniture, please observe the following safety guidelines:

- Do not stand on the chair.
- Do not exceed the maximum weight recommendation of 44 pounds.
- Ensure the chair is placed on a stable, level surface to prevent tipping.
- Keep away from open flames and direct heat sources.
- Keep small children and pets away from the chair during initial setup to avoid accidental injury.

Product Overview & Design Features

The Regal Accent Chair is designed for comfort and style, featuring a taupe finish and distressed wood framing. Key features include:

- **Finish:** Taupe
- **Nail Head Trim:** Decorative accents along the frame.
- **Distressed Wood Framing:** Adds a vintage and elegant touch.
- **Padded Arms:** For enhanced comfort.
- **Cabriole Feet:** Stylish, curved legs.
- **Foam Cushion Seat and Back:** Provides comfortable support.



Image: Detailed view of the chair's top back, highlighting the distressed wood and nail head trim.



Image: A close-up of the chair's foam cushion seat, emphasizing its texture and construction.

Setup and Assembly

This Picket House Furnishings Regal Accent Chair requires **no assembly**. It arrives fully assembled and ready for immediate use. Simply remove it from its packaging and place it in your desired location.

Usage

The Regal Accent Chair is designed for relaxing and adding a touch of elegance to any indoor space. It is suitable for living rooms, bedrooms, studies, or any area where comfortable seating is desired. Ensure the chair is placed on a hard floor or carpeted surface as per your preference.

Maintenance and Care

Proper care will help maintain the beauty and longevity of your accent chair:

- **Regular Cleaning:** Vacuum regularly using an upholstery attachment to remove dust and debris.
- **Spot Cleaning:** For spills, blot immediately with a clean, dry cloth. Do not rub. For stubborn stains, consult a professional upholstery cleaner.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fabric fading. Position the chair away from direct sun or use curtains/blinds.
- **Protect Wood Frame:** Wipe the distressed wood frame with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Rotate Cushions:** If cushions are removable, rotate and flip them periodically to ensure even wear.

Troubleshooting

Here are solutions to common issues you might encounter:

Issue	Solution
Wobbly Chair	Ensure the chair is on a flat surface. If the issue persists, check for any loose connections (though this chair is pre-assembled, minor adjustments might be needed if parts shift during transit).
Fabric Stains	Blot spills immediately. For persistent stains, use a mild upholstery cleaner or consult a professional. Test any cleaning product on an inconspicuous area first.
Fading Fabric	Relocate the chair away from direct sunlight or use window coverings to protect it.

Specifications

Brand: Picket House

Model Name: Picket House Modern Wood Cream Furnishings Regal Accent Chair

Item Model Number: UAZ540100G

Color: Taupe

Product Dimensions: 32"D x 29"W x 38"H

Seat Height: 38 Inches

Seat Depth: 32 inches

Chair Backrest Width: 29 Inches

Material: Wood (Frame), Foam (Fill Material), Suede (Upholstery Fabric Type)

Maximum Weight Recommendation: 44 Pounds

Assembly Instructions: No assembly required

Indoor/Outdoor Usage: Indoor

Item Weight: 44 pounds

UPC: 810435038314




Image: Dimensional diagram of the Regal Accent Chair, indicating its height, depth, and width.

Warranty and Support

For any questions regarding your Picket House Furnishings Regal Accent Chair, please refer to the retailer's return policy or contact Picket House Furnishings customer support. Specific warranty details may vary by retailer and purchase date.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07BSHVC2G

More documents and user manuals: **https://manuals.plus/**