

[Manuals.plus](#) /

> [UPBRIGHT](#) /

> UPBRIGHT 5V AC/DC Adapter User Manual for Denon DJ MC4000 and DN-F400

UPBRIGHT 5V AC/DC Adapter

UPBRIGHT 5V AC/DC Adapter User Manual

Compatible with Denon DJ MC4000 and DN-F400

1. INTRODUCTION

This manual provides essential information for the safe and effective use of your UPBRIGHT 5V AC/DC Adapter. This power supply is designed to provide stable 5V DC power to compatible devices, specifically the Denon DJ MC4000 Professional 2-Channel DJ Controller and the Denon DN-F400 Rackmount Solid-State Audio Player.

Please read this manual thoroughly before using the adapter and retain it for future reference.

2. SAFETY INFORMATION

- **Indoor Use Only:** This adapter is designed for indoor use. Do not expose it to rain, moisture, or extreme temperatures.
- **Proper Voltage:** Ensure the wall outlet voltage matches the adapter's input voltage (100-240V AC).
- **Avoid Overloading:** Do not connect devices that exceed the adapter's output specifications (5V DC, 3A).
- **Handle with Care:** Do not drop, disassemble, or attempt to repair the adapter. Refer servicing to qualified personnel.
- **Ventilation:** Ensure adequate ventilation around the adapter during use to prevent overheating.
- **Disconnect When Not in Use:** Unplug the adapter from the power outlet when not in use for extended periods.
- **Short Circuit Protection:** This adapter features built-in short circuit protection for enhanced safety.

3. PRODUCT OVERVIEW

The UPBRIGHT 5V AC/DC Adapter is a compact power supply unit designed for reliability and compatibility. It consists of the main adapter unit and an integrated power cord with a barrel connector.



Image 3.1: The UPBRIGHT 5V AC/DC Adapter, showing the main unit, integrated power cord, and barrel connector. This adapter is designed to provide stable power to compatible electronic devices.

UpBright AC Adapter Power Supply Compatible with:



Image 3.2: A close-up view of the barrel connector, which plugs into the compatible device's power input port.

4. SETUP

1. **Verify Compatibility:** Ensure your device requires a 5V DC input with a current draw of 3A or less, and has a compatible barrel connector. This adapter is specifically tested for Denon DJ MC4000 and DN-F400.
2. **Connect to Device:** Insert the barrel connector of the adapter firmly into the DC input jack of your Denon DJ MC4000 or DN-F400 device.
3. **Connect to Power Outlet:** Plug the adapter's two-prong plug into a standard 100-240V AC wall outlet.
4. **Power On Device:** Once connected, you can power on your device according to its own operating instructions.

5. OPERATING INSTRUCTIONS

The UPBRIGHT 5V AC/DC Adapter operates automatically once connected to a power source and a compatible device. It provides a stable 5V DC output to power your equipment.

- Always ensure secure connections to prevent intermittent power supply.
- If the device is not powering on, check all connections and the power outlet.
- Unplug the adapter from the wall before disconnecting it from your device to prevent accidental power surges.

6. MAINTENANCE

- **Cleaning:** Disconnect the adapter from power before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or solvents.
- **Storage:** Store the adapter in a cool, dry place away from direct sunlight and moisture when not in use. Avoid tightly coiling the cable to prevent damage.
- **Inspection:** Periodically inspect the adapter and cable for any signs of damage, such as frayed wires or cracked casing. If damage is found, discontinue use immediately.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not power on.	No power from outlet. Adapter not properly connected. Faulty adapter or device.	Check if the wall outlet is functional by plugging in another device. Ensure the adapter is fully plugged into both the wall and the device. Test with another compatible adapter if available. If the issue persists, the device or adapter may be faulty.
Adapter feels hot during use.	Normal operation. Poor ventilation. Overload.	A slight warmth is normal. Ensure the adapter is in a well-ventilated area. Do not cover the adapter. Ensure the connected device does not exceed the adapter's current rating (3A).
Intermittent power to device.	Loose connection. Damaged cable.	Check all connections for tightness. Inspect the cable for any visible damage. If damaged, discontinue use and replace the adapter.

8. SPECIFICATIONS


- **Brand:** UPBRIGHT
- **Input Voltage:** 100-240V AC, 50/60Hz
- **Output Voltage:** 5V DC
- **Output Current:** 3 Amps (3000mA)
- **Wattage:** 40 Watts (Max)
- **Connector Type:** Barrel Connector
- **Special Feature:** Short Circuit Protection
- **Compatible Devices:** Denon DJ MC4000 Professional 2-Channel DJ Controller, Denon DN-F400 Rackmount Solid-State Audio Player
- **Power Plug:** Type A - 2 pin (North American)
- **Material:** Aluminum (Enclosure)

9. WARRANTY AND SUPPORT

This UPBRIGHT product comes with a warranty to ensure your satisfaction and peace of mind.

- **Warranty:** 30 Days Refund - 24 Months Exchange.
- **Customer Support:** For technical assistance, warranty claims, or any questions regarding your UPBRIGHT 5V AC/DC Adapter, please contact your retailer or visit the official UPBRIGHT store online.

Come With A Suitable Outlet Adapter (Only One) to Fit Your Country/Area For International Order



THIS PRODUCT COMES WITH A UPBRIGHT®

LIMITED WARRANTY CERTIFICATE
+ UPBRIGHT® LIMITED WARRANTY



Image 9.1: Example of international outlet adapters that may be included with international orders, alongside a representation of the UPBRIGHT Limited Warranty Certificate.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07BT2ZM5K>

More documents and user manuals: <https://manuals.plus/>