

Devoko DV17VNI

Devoko 9 Pieces Patio Dining Set User Manual

Brand: Devoko
Model: DV17VNI

1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Devoko 9 Pieces Patio Dining Set. Please read this manual thoroughly before assembly and use to ensure proper function and longevity of your furniture.

The Devoko 9 Pieces Patio Dining Set is designed to enhance your outdoor living space, offering a comfortable and stylish solution for dining and relaxation. Its space-saving design allows chairs and ottomans to be neatly stored under the table when not in use.

2. SAFETY INFORMATION

Important Safety Warning:

If you place this furniture set outdoors, it is advisable to use a protective cover during rain or snow to prevent damage and extend its service life.

- Ensure all bolts and screws are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not stand on the furniture.
- Keep children under supervision when near the furniture.
- Avoid placing hot items directly on the glass table surface without protection.
- Distribute weight evenly on the table and chairs.

3. PACKAGE CONTENTS

Your Devoko 9 Pieces Patio Dining Set includes the following components:

- Table x 1
- Single Chairs x 4

- Ottomans x 4
- Cushions x 12 (for chairs and ottomans)
- Assembly Hardware (bolts, washers, Allen wrench)
- Installation Instruction Manual

Note: The set is shipped in three separate boxes. You may receive them at different times.



Image: The complete Devoko 9 Pieces Patio Dining Set, showcasing all components including the table, chairs, and ottomans.

4. SETUP AND ASSEMBLY

Assembly of the Devoko Patio Dining Set requires some time but is straightforward with the provided instructions. It is recommended to have two people for assembly.

4.1 Before You Begin

- Unpack all components and verify against the package contents list.
- Lay out all parts on a soft, clean surface to prevent scratching.
- Ensure you have the necessary tools. While an Allen wrench is provided, a power drill with a hex bit can significantly speed up assembly.

4.2 Assembly Steps

1. **Assemble the Chairs:** Attach the backrest to the seat frame, then attach the side panels. Secure all connections with the provided bolts and washers. Do not fully tighten bolts until all parts are aligned.
2. **Assemble the Ottomans:** Connect the four sides to form the ottoman frame. Secure with bolts.
3. **Assemble the Table:** Attach the legs to the tabletop frame. Ensure the glass top is placed securely on the frame.
4. **Final Tightening:** Once all components are assembled and aligned, fully tighten all bolts.

5. **Add Cushions:** Place the cushions on the chairs and ottomans.

For a visual guide, please refer to the official installation manual PDF:

[Download Installation Manual \(PDF\)](#)



HAND-WOVEN RATTAN

Upgraded Rattan for All Kinds of Weather

Image: A person assembling one of the chairs, demonstrating the assembly process.

5. OPERATING INSTRUCTIONS

5.1 General Use

The Devoko Patio Dining Set is designed for outdoor use in patios, gardens, lawns, balconies, and poolside areas. It provides comfortable seating for dining and conversation.

5.2 Space-Saving Feature

One of the key features of this set is its space-saving design. The chairs and ottomans are designed to tuck neatly under the table when not in use, creating a compact cube that saves space and protects the furniture.



SPACE SAVING

Chairs Can be Combined Under the Table

Image: The patio dining set demonstrating its space-saving capability, with chairs and ottomans neatly stored under the table.



MODERN DESIGN

Perfect for Family Backyards and Gardens

Image: The patio set in use, with chairs and ottomans pulled out from under the table, ready for dining or lounging.

5.3 Ottoman Functionality

The ottomans can be used as additional seating for smaller individuals or as comfortable footrests to enhance relaxation.



HIGH QUALITY CUSHIONS

Provide You More Comfortable Experience

Image: A person comfortably using an ottoman as a footrest, highlighting its versatility.

6. MAINTENANCE

Proper care and maintenance will ensure the longevity and appearance of your Devoko Patio Dining Set.

- **Cleaning:** Wipe surfaces with a dry cloth. For deeper cleaning, use a mild soap and water solution with a soft cloth. Rinse thoroughly and dry completely.
- **Cushions:** The cushions have zippered covers, allowing for easy removal and cleaning. Spot clean with a mild detergent and water. Air dry completely before reattaching.
- **Weather Protection:** To protect the furniture from harsh weather conditions (heavy rain, snow, strong sun), it is highly recommended to use a furniture cover when not in use for extended periods.
- **Glass Tabletop:** Clean the glass tabletop with a standard glass cleaner. Avoid abrasive cleaners or tools that could scratch the surface.
- **Leg Caps:** Consider adding rubber end caps to the chair legs to prevent scratching of deck surfaces, especially if the furniture is frequently moved.

7. TROUBLESHOOTING

This section addresses common issues you might encounter with your patio dining set.

Problem	Possible Cause	Solution
Difficulty during assembly / Parts not aligning	Bolts tightened too early; misaligned parts; unthreaded screw holes.	Do not fully tighten bolts until all parts are loosely assembled and aligned. If screw holes are unthreaded, contact customer service.
Missing parts or boxes	Set shipped in multiple boxes; shipping delay.	The set ships in three boxes. If you only received one or two, the others are likely still in transit. Check tracking information. If parts are genuinely missing after all boxes arrive, contact Devoko customer service.
Chairs feel wobbly after assembly	Bolts not fully tightened.	Ensure all bolts are securely tightened. Periodically check and re-tighten as needed.
Cushions feel too thin or uncomfortable	Personal preference; standard cushion thickness.	Consider adding additional padding or replacing cushions with thicker ones if desired.

8. SPECIFICATIONS

Brand	Devoko
Model Number	DV17VNI
Material	Rattan, Steel
Fabric Type	100% Polyester
Color	Brown/Beige
Product Dimensions (L x W x H)	43 x 43 x 29 inches
Item Weight	135 pounds
Included Components	Chair x 4, Ottoman x 4, Table x 1
Product Care Instructions	Wipe with Dry Cloth

9. WARRANTY AND SUPPORT

Devoko offers worry-free after-sale service and friendly customer support for your product.

For any questions, missing parts, or assistance with assembly, please contact Devoko customer service directly through the Amazon messaging system or via the contact information provided with your purchase.

Please refer to your purchase documentation for specific warranty details.

You can also visit the official Devoko store on Amazon for more information: [Devoko Store](#)



© 2024 Devoko. All rights reserved.