

[Manuals.plus](#) /

› [Travelpro](#) /

› Travelpro Maxlite 5 Softside Expandable Carry-On Luggage User Manual

Travelpro Maxlite 5 (401176706)

Travelpro Maxlite 5 Softside Expandable Carry-On Luggage User Manual

1. INTRODUCTION

The Travelpro Maxlite 5 Softside Expandable Carry-On Luggage is engineered for lightweight durability and effortless mobility, designed to meet most international airline size restrictions. This manual provides essential information for the proper setup, operation, maintenance, and care of your luggage, ensuring its longevity and optimal performance.



Image 1: Travelpro Maxlite 5 Softside Expandable Carry-On Luggage, Slate Green.

2. SETUP

Upon receiving your Travelpro Maxlite 5 luggage, perform the following initial setup steps:

1. **Unpacking:** Carefully remove all packaging materials, including plastic wraps and protective inserts.
2. **Handle Inspection:** Extend and retract the PowerScope Lite handle several times to ensure it operates smoothly and locks securely at its designated stops (38 inches and 42.5 inches).
3. **Wheel Check:** Verify that all four 360° spinner wheels rotate freely and smoothly in all directions.



Image 2: Detailed view of the Contour Grip handle, ergonomic zipper pulls, and 360-degree spinner wheels.

3. OPERATING INSTRUCTIONS

3.1 Packing and Organization

- **Main Compartment:** Place larger clothing items and essentials in the main packing area.
- **Hold-Down Straps:** Utilize the adjustable hold-down straps to secure contents and minimize shifting during transit.
- **Interior Pockets:** Use the full-length interior lid pocket and side accessory pocket for smaller items, toiletries, or documents.
- **Exterior Pockets:** The two exterior compartments provide quick access to items like travel documents or small electronics.



Image 3: Interior view demonstrating the mesh pocket for organization and the lining made from recycled plastic.

3.2 Expanding the Luggage

To gain additional packing space, locate the expandable zipper around the perimeter of the main compartment. Unzip this section to expand the luggage by up to two inches. This feature is useful for accommodating extra items or souvenirs.



Image 4: Side profile illustrating the 2-inch expansion capability and low-profile carry handles.

3.3 Mobility

- **PowerScope Lite Handle:** Extend the handle to your preferred height for comfortable pushing or pulling. The Contour Grip is designed for ergonomic handling.
- **360° Spinner Wheels:** The four spinner wheels allow for smooth, multi-directional rolling, reducing strain on your arm and shoulder.
- **Carry Handles:** Use the top, side, or bottom handles for lifting the luggage into overhead bins or onto luggage racks.





Image 5: Rear view of the luggage showcasing the extended PowerScope Lite handle.

4. MAINTENANCE

Regular maintenance helps preserve the appearance and functionality of your luggage.

- **Exterior Cleaning:** Wipe the exterior fabric with a damp cloth and a mild soap solution. The DuraGuard coating provides water and stain resistance. Avoid using harsh chemicals or abrasive cleaners.
- **Interior Cleaning:** Wipe the interior lining with a damp cloth. The H2O Guard lining helps protect against moisture. Ensure the interior is dry before closing and storing.
- **Wheel Care:** Periodically inspect the spinner wheels for any accumulated debris, such as hair or lint. Remove any obstructions to ensure smooth rolling.
- **Zipper Maintenance:** Keep zippers free of dirt and debris. If a zipper becomes stiff, a small amount of zipper lubricant can improve its operation.
- **Storage:** Store your luggage in a clean, dry environment away from direct sunlight when not in use.



Image 6: Underside view highlighting the durable spinner wheels and bottom tray design.

5. TROUBLESHOOTING

If you encounter any issues with your luggage, refer to the following common troubleshooting tips:

- **Handle Not Extending/Retracting Smoothly:** Check for any internal obstructions within the luggage that might be interfering with the handle mechanism. Ensure the handle release button is fully depressed.
- **Wheels Not Rolling Smoothly:** Inspect the wheels for tangled hair, lint, or other debris. Carefully remove any obstructions. Ensure the luggage is not excessively overloaded, which can stress the wheels.

- **Zipper Snagging:** If a zipper snags, gently pull the fabric away from the zipper teeth. Do not force the zipper, as this can cause damage.
- **Luggage Tipping Over:** Uneven weight distribution, especially heavy items in exterior pockets, can cause the luggage to tip. Distribute contents evenly throughout the main compartment and pockets.

6. SPECIFICATIONS

Key specifications for the Travelpro Maxlite 5 Softside Expandable Carry-On Luggage:

Feature	Detail
Overall Dimensions (incl. wheels & handles)	21.75" x 15.75" x 7.75" (55.25 x 40.01 x 19.69 cm)
Case Dimensions	19" x 15" x 7.75"
Weight	5.3 lbs (2.4 kg)
Capacity	39 Liters
Material	Polyester with DuraGuard coating
Wheel Type	4 Spinner Wheels
Handle Type	Telescopic Extendable PowerScope Lite Handle
Lock Type	Zipper Lock
Water Resistance Level	Water Repellent
Expansion	Up to 2 inches
Model Number	401176706
UPC	051243088218



SIZE	INTL. CARRY-ON SPINNER
Overall Dimensions Include Handle and Wheels	21.75" x 15.75" x 7.75"
Case Dimensions	19" x 15" x 7.75"
Weight	5.3 lbs
Packing Capacity	39 L

Image 7: Diagram illustrating the overall and case dimensions, weight, and packing capacity.

7. WARRANTY AND SUPPORT

Your Travelpro Maxlite 5 luggage is backed by comprehensive coverage:

- **Limited Lifetime Coverage:** This warranty covers defects in materials and workmanship for the lifetime of the product. It specifically includes components such as wheels, zippers, extension handles, and carrying handles. Travelpro reserves the right to repair or replace the product at its discretion.
- **Trusted Companion Promise:** For the first year after purchase, this promise provides additional coverage for damage caused by airlines or other common carriers. To activate this coverage, product registration is required within 30 days of purchase. This includes covering shipping costs if the product needs to be sent to a Travelpro repair facility.

For warranty claims, service, or additional support, please refer to the official Travelpro website or contact their customer service department directly. Ensure you have your proof of purchase and product registration details available.



Image 8: Overview of Travelpro's Limited Lifetime Coverage and Trusted Companion Promise.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question