BABY born 824344

BABY Born Sister Mermaid Doll User Manual

Model: 824344

Introduction

Thank you for choosing the BABY Born Sister Mermaid Doll. This doll is designed for interactive water play, featuring a unique mermaid tail that moves when in contact with water. It also comes with extra-long hair for styling fun, a beautiful tiara, and a comb.

Important Safety Warning

WARNING: Not suitable for children under 3 years due to small parts that may present a choking hazard.

Always supervise children during water play. Ensure the doll is properly dried after use to maintain its condition.

Product Components

The BABY Born Sister Mermaid Doll package includes the following items:

- 1 x BABY Born Sister Mermaid Doll (46 cm)
- 1 x Finely decorated mermaid tail (attached)
- 1 x Beaded tiara
- 1 x Comb





Image: The BABY Born Sister Mermaid Doll, showcasing its full design, including the mermaid tail, tiara, and the included comb.



Image: The BABY Born Sister Mermaid Doll displayed in its original retail packaging, highlighting the product's presentation.

Setup

Before first use, ensure any packaging materials are removed. The doll requires batteries for its water-activated features.

Battery Installation

1. Locate the battery compartment, typically on the doll's back or lower body.
2. Using a small screwdriver (not included), open the battery compartment cover.
3. Insert the required batteries (refer to Specifications for type and quantity) ensuring correct polarity (+/-).
4. Securely close the battery compartment cover and tighten the screw to prevent water ingress.

Note: Batteries are not included with the doll and must be purchased separately.

Operating Instructions

Water Play Function

The BABY Born Sister Mermaid Doll is designed to move its tail when placed in water. This feature is activated automatically upon contact with water, allowing the doll to simulate swimming movements.

- Ensure the battery compartment is securely closed before placing the doll in water.
- Place the doll in a bathtub, pool, or other suitable water container.
- The mermaid tail will begin to flap, creating a swimming motion.
- Remove the doll from water to stop the tail movement.



Image: The BABY Born Sister Mermaid Doll submerged in water, demonstrating its tail-flapping swimming action.

Hair Styling and Posing

The doll features long, soft blonde hair with purple streaks, perfect for various hairstyles. Its head and arms are articulated for posing.

- Use the included comb to brush and style the doll's hair.
- The tiara can be placed on the doll's head for added decoration.
- Gently rotate the doll's head and arms to adjust its pose for imaginative play.



Image: A child gently styling the long blonde hair of the BABY Born Sister Mermaid Doll, demonstrating the hair play feature.



Image: A child placing the decorative tiara on the head of the BABY Born Sister Mermaid Doll, showcasing accessory use.



Image: A child engaging in imaginative play with the BABY Born Sister Mermaid Doll, demonstrating general interaction.

Maintenance

Cleaning Instructions

- After water play, thoroughly rinse the doll with clean water to remove any soap residue or pool chemicals.
- Gently squeeze excess water from the doll's hair.
- Wipe the doll's body with a soft, dry cloth.
- Allow the doll to air dry completely in a well-ventilated area before storage. Avoid direct sunlight or heat sources.

Storage

Store the doll in a clean, dry place away from extreme temperatures and direct sunlight to prevent damage and discoloration.

Battery Care

- Remove batteries if the doll will not be used for an extended period to prevent leakage.
- Dispose of used batteries responsibly according to local regulations.

Troubleshooting

Problem	Possible Cause	Solution
Doll's tail does not move in water.	Batteries are dead or incorrectly installed. Battery compartment is not sealed properly. Water sensor is obstructed or dirty.	Check and replace batteries, ensuring correct polarity. Ensure the battery compartment cover is securely closed and screwed tight. Gently clean the area around the doll's lower back/tail where water contact is made.
Doll's hair becomes tangled or matted.	Frequent play without brushing. Exposure to harsh chemicals or extreme temperatures.	Regularly brush the doll's hair with the included comb. Use a small amount of mild conditioner if needed, then rinse thoroughly and air dry.

Specifications

Model Number	824344
Brand	BABY born (Zapf Creation)
Product Dimensions (L x W x H)	37 x 15 x 42 cm (approx. 14.6 x 5.9 x 16.5 inches)
Weight	1 kg (approx. 2.2 lbs)
Recommended Age	3 years and up
Batteries Required	Yes (Type and quantity not specified in input, typically AA or AAA)
Batteries Included	No
Special Feature	Moves in water

Warranty and Support

Specific warranty information for the BABY Born Sister Mermaid Doll is not provided in this manual. Please refer to the product packaging or the manufacturer's official website for detailed warranty terms and conditions.

Customer Support

For further assistance, questions, or to report any issues with your product, please contact Zapf Creation customer support. Contact details can typically be found on the product packaging or their official website. *Please retain this manual for future reference.*

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question