

[Manuals.plus](#) /

› [argoclima](#) /

› Argoclima Adak Portable Air Conditioner User Manual

argoclima Adak 8000 BTU

Argoclima Adak 8000 BTU Portable Air Conditioner

Model: Adak 8000 BTU

Brand: Argoclima

PRODUCT OVERVIEW

The Argoclima Adak 8000 BTU Portable Air Conditioner is a versatile and efficient climate control solution designed for ease of use and portability. Featuring a pure white finish, a digital control panel, and an LED display, this unit offers cooling, ventilation, and dehumidification functions. Its user-friendly remote control and 24-hour timer provide convenient operation. The unit includes a memory function for automatic restart after power interruptions, maintaining previous settings. Air delivery can be vertically oriented for optimal comfort. The washable air filter is easily removable for maintenance, and the automatic condensation feature simplifies operation. Equipped with multi-directional wheels, the unit offers maximum transfer capacity and easy positioning.






Front view of the Argoclima Adak 8000 BTU Portable Air Conditioner, showcasing its compact design and control panel.

SETUP AND INSTALLATION


1. **Unpacking:** Carefully remove the air conditioner and all accessories from the packaging. Retain the packaging for future storage or transport.
2. **Placement:** Position the unit on a flat, stable surface. Ensure there is adequate space around the unit for proper airflow (at least 20 cm from walls or furniture). The multi-directional wheels allow for easy movement.
3. **Exhaust Hose Installation:** Connect the exhaust hose to the designated outlet on the rear of the unit. Extend the hose to a window or other suitable opening to vent hot air outside. Ensure the hose is as straight and short as possible to maximize efficiency.

4. **Window Kit (if applicable):** Install the window sealing kit (if provided) to create a secure and efficient seal for the exhaust hose.
5. **Power Connection:** Plug the power cord into a grounded electrical outlet with the correct voltage (230V AC).





Side view of the unit, illustrating the exhaust hose connection point for venting hot air.



Dimensional diagram of the air conditioner, showing its height, width, and depth for proper placement planning.

OPERATING INSTRUCTIONS

Control Panel and Display

The unit features a digital control panel and an LED display on the top surface for easy access to all functions. All settings can also be adjusted via the included remote control.

Operating Modes

- **Cooling Mode:** Activates the refrigeration system to lower room temperature. Set your desired temperature using the control panel or remote.
- **Ventilation Mode:** Operates the fan without engaging the cooling or dehumidifying functions, providing air circulation. Fan speed can typically be adjusted.
- **Dehumidification Mode:** Removes excess moisture from the air, helping to reduce humidity levels in the room.

Additional Features

- **24-Hour Timer:** Program the unit to turn on or off automatically within a 24-hour period, optimizing energy usage.
- **Memory Function:** In the event of a power interruption, the unit will automatically restart with the previously set fan speed and other settings once power is restored.
- **Vertical Air Delivery:** The air outlet can be oriented vertically to direct airflow as needed for optimal comfort.

MAINTENANCE

Air Filter Cleaning

The air filter is washable and easily removable. Regular cleaning of the air filter is crucial for maintaining the unit's efficiency and air quality. It is recommended to clean the filter every two weeks, or more frequently depending on usage and air quality.

1. Turn off and unplug the unit before cleaning.
2. Locate and remove the air filter according to the diagrams in the full manual.
3. Wash the filter gently with lukewarm water and a mild detergent. Rinse thoroughly.
4. Allow the filter to air dry completely before reinserting it into the unit. Do not expose to direct sunlight or heat.

Condensation Management

The unit features automatic condensation, which means most of the collected moisture is evaporated and expelled with the hot air. However, in very humid conditions, the internal water tank may fill. Refer to the full product manual for instructions on how to drain the unit if the water tank indicator illuminates.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Unit does not turn on	No power supply; Power cord not plugged in; Circuit breaker tripped.	Check power outlet; Ensure power cord is securely plugged in; Reset circuit breaker.
Unit not cooling effectively	Air filter clogged; Exhaust hose not properly installed; Room too large; Doors/windows open.	Clean air filter; Ensure exhaust hose is sealed and straight; Close doors and windows; Consider unit capacity for room size.

Problem	Possible Cause	Solution
Water leakage	Water tank full (in dehumidification mode); Unit not level.	Drain the water tank; Ensure unit is on a flat, level surface.
Unusual noise	Unit not level; Obstruction in fan.	Ensure unit is on a flat surface; Check for and remove any obstructions.

SPECIFICATIONS

Attribute	Value
Brand	Argoclima
Model	Adak 8000 BTU
Color	White
Product Dimensions (LxWxH)	28 x 33 x 68 cm
Wattage	2344.57 watts
Voltage	230 Volts (AC)
Cooling Power	8000 British Thermal Units (BTU)
Special Feature	Dehumidifier
Refrigerant	R32 (example, low GWP)
Filter Type	Prefilter
Power Source	Corded Electric
Form Factor	Standing

WARRANTY INFORMATION

For detailed warranty information, please refer to the warranty card included with your product packaging or visit the official Argoclima website. Keep your proof of purchase for any warranty claims.

CUSTOMER SUPPORT

If you encounter any issues not covered in this manual or require further assistance, please contact Argoclima customer support. Contact details can typically be found on the product packaging, the official Argoclima website, or your purchase documentation.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07BYCFJ13>

More documents and user manuals: <https://manuals.plus/>