

[Manuals.plus](#) /

› [CTS](#) /

› CTS Cylinder Piston & Ring Kit Installation Manual for OLEO-MAC 753 and EFCO 8530 Brushcutters

CTS OLEO-MAC 753 EFCO 8530

CTS Cylinder Piston & Ring Kit Installation Manual

For OLEO-MAC 753 and EFCO 8530 Brushcutters

1. INTRODUCTION

This manual provides essential information and step-by-step instructions for the proper installation of your new CTS Cylinder Piston & Ring Kit. This kit is designed as a direct replacement for OLEO-MAC 753 and EFCO 8530 brushcutter engines. Adhering to these instructions will help ensure correct assembly and optimal performance of your equipment.

Please read this manual thoroughly before beginning any installation procedures. Professional installation is highly recommended for engine components.

2. SAFETY INFORMATION

- **Always wear appropriate personal protective equipment (PPE)**, including safety glasses and gloves, when working on engine components.
- Ensure the brushcutter engine is **completely cool and disconnected from its power source** (e.g., spark plug cap removed) before starting any work.
- Work in a **well-ventilated area**.
- Keep all tools and parts organized to prevent loss or damage.
- If you are unsure about any step, consult a qualified technician.

3. KIT CONTENTS

Your CTS Cylinder Piston & Ring Kit includes the following components:

- 1 x Cylinder Head
- 1 x 45mm Piston
- 1 x Piston Pin
- 2 x Piston Rings
- 2 x Circlips




Image 3.1: All components of the CTS Cylinder Piston & Ring Kit, including the cylinder head, piston, piston pin, two piston rings, and two circlips, laid out for inspection.




Image 3.2: Another view of the CTS Cylinder Piston & Ring Kit components, showing the cylinder head from a side angle, alongside the piston, pin, rings, and circlips.




Image 3.3: Top-down view of the CTS Cylinder Piston & Ring Kit, highlighting the cylinder head's top surface, with the piston, pin, rings, and circlips arranged next to it.

4. COMPATIBILITY

This CTS Cylinder Piston & Ring Kit is specifically designed as a replacement for the following brushcutter models:

- **OLEO-MAC 753**
- **EFCO 8530**

It replaces original part numbers **6111 2035B** and **61112035B**. Please verify your brushcutter model and existing part number before installation to ensure compatibility.

5. INSTALLATION INSTRUCTIONS

This section outlines the general steps for installing the cylinder, piston, and ring kit. Specific procedures may vary slightly depending on your brushcutter's exact configuration. Refer to your brushcutter's service manual for detailed disassembly and reassembly instructions.

5.1. Preparation

1. Ensure the engine is cool and the spark plug cap is removed.
2. Clean the exterior of the engine to prevent dirt from entering internal components during disassembly.
3. Gather all necessary tools, including wrenches, screwdrivers, piston ring compressor (if needed), and a clean work surface.

5.2. Disassembly (Overview)

Carefully disassemble the existing cylinder and piston assembly. This typically involves:

- Removing the muffler and carburetor (if necessary).
- Unbolting the cylinder head from the crankcase.
- Removing the old piston pin circlips and the piston pin to detach the piston from the connecting rod.
- Inspecting the connecting rod and crankshaft for any damage or wear.

5.3. Assembly of New Components

1. **Install Piston Rings:** Carefully install the new piston rings onto the new piston. Ensure the rings are correctly oriented (if directional) and do not overlap. Use a piston ring compressor if available to prevent damage.
2. **Attach Piston to Connecting Rod:** Position the piston onto the connecting rod. Insert the piston pin through the piston and connecting rod. Secure the piston pin with the new circlips on both sides. Ensure circlips are fully seated in their grooves.
3. **Lubricate:** Apply a thin coat of two-stroke engine oil to the piston, piston rings, piston pin, and the inside of the new cylinder bore.
4. **Install Cylinder:** Carefully slide the new cylinder head over the piston, compressing the piston rings as it slides down. Ensure the piston rings align with the cylinder's ring locating pins.
5. **Secure Cylinder:** Bolt the new cylinder head to the crankcase. Tighten bolts evenly and to the manufacturer's specified torque settings (refer to your brushcutter's service manual).
6. **Reassemble Peripherals:** Reinstall the carburetor, muffler, and any other components removed during disassembly.

5.4. Post-Installation Checks

1. Ensure all bolts and fasteners are tightened securely.
2. Check for any loose connections or hoses.
3. Verify that the engine rotates freely by slowly pulling the starter cord (with the spark plug removed for easier rotation).
4. Reinstall the spark plug and connect the cap.
5. Add fresh fuel/oil mixture according to your brushcutter's specifications.

6. MAINTENANCE TIPS

After installing your new cylinder, piston, and ring kit, proper engine maintenance is crucial for longevity:

- **Break-in Period:** Operate the engine at varying speeds, avoiding prolonged full throttle, for the first few hours of use to allow the new components to seat properly.
- **Fuel Mixture:** Always use the correct fuel-to-oil mixture ratio specified by your brushcutter's manufacturer.
- **Air Filter:** Regularly clean or replace the air filter to prevent dirt from entering the engine.
- **Spark Plug:** Inspect and replace the spark plug as recommended by the manufacturer.
- **Storage:** When storing the brushcutter for extended periods, drain the fuel tank or use a fuel stabilizer.

7. TROUBLESHOOTING

If you encounter issues after installation, consider the following common troubleshooting steps:

- **Engine Fails to Start:**

- Check fuel level and mixture.
- Ensure spark plug is clean, gapped correctly, and producing a spark.
- Verify all electrical connections are secure.
- Check for proper compression (a new engine will have higher compression).

- **Loss of Power / Poor Performance:**

- Inspect air filter for clogging.
- Check fuel filter and lines for obstructions.
- Ensure carburetor is properly adjusted.
- Verify exhaust port is not carbonized.

- **Unusual Noises:**

- Recheck all fasteners for tightness.
- Listen for air leaks around the cylinder base or intake.
- If knocking, stop engine immediately and consult a professional.

For persistent issues, it is recommended to consult a qualified small engine mechanic.

8. SPECIFICATIONS

- **Product:** Cylinder Piston & Ring Kit
- **Brand:** CTS
- **Piston Diameter:** 45mm
- **Replaces Part Numbers:** 6111 2035B, 61112035B
- **Compatible Models:** OLEO-MAC 753, EFCO 8530
- **Package Dimensions:** Approximately 5 x 4.5 x 4 inches
- **Item Weight:** Approximately 1 pound

9. WARRANTY AND SUPPORT

For warranty information and technical support regarding your CTS Cylinder Piston & Ring Kit, please refer to the original purchase documentation or contact your retailer. Specific warranty terms and conditions may apply.

For general inquiries or assistance, please reach out to the manufacturer, CTS, through their official support channels.

© 2024 CTS. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07BZRCN1R>

More documents and user manuals: **<https://manuals.plus/>**