

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Yaheetech](#) /

› [Yaheetech Bird Cage with Openable Roof, 46x35x92.5 cm, White - Instruction Manual](#)

**Yaheetech VC591824White260122**

# Yaheetech Bird Cage with Openable Roof (Model: VC591824White260122)

Instruction Manual

## 1. INTRODUCTION

---

This manual provides essential information for the safe assembly, operation, and maintenance of your Yaheetech Bird Cage. Please read these instructions carefully before use and retain them for future reference. This bird cage is designed to provide a secure and comfortable habitat for small birds such as parrots, parakeets, lovebirds, and cockatiels.



Image 1.1: Yaheetech Bird Cage in a home setting.

## 2. SAFETY INFORMATION

---

- Ensure all parts are securely fastened before placing birds inside the cage.
- Regularly inspect the cage for any damaged or loose components that could harm your pet.
- Keep the cage away from direct sunlight, drafts, and extreme temperatures.
- Supervise children when they are near the bird cage to prevent accidents.
- The bar spacing of 1 cm is suitable for small birds. Ensure your bird cannot escape or get stuck.

## 3. PACKAGE CONTENTS

---

Please verify that all components are present before beginning assembly:

- Coated metal cage panels
- Plastic base tray
- Removable bottom grid
- Wooden perches (4 pieces)

- Food/water cups (4 pieces)
- Swing (1 piece)
- Assembly hardware (clips, screws if applicable)

## 4. SETUP INSTRUCTIONS

Follow these steps to assemble your bird cage:

1. Unpack all components and lay them out on a clean, flat surface.
2. Assemble the main cage panels, ensuring they interlock securely. Use any provided clips or fasteners to reinforce the connections.
3. Insert the removable bottom grid into the base of the cage.
4. Slide the plastic base tray underneath the bottom grid.
5. Attach the wooden perches at desired heights within the cage.
6. Hang the swing inside the cage.
7. Place the food and water cups into the designated sliding doors.





Image 4.1: Key features including handles, feeder doors, and slide-out tray.

## 5. OPERATING INSTRUCTIONS

## 5.1. Using the Openable Roof

The cage features an openable roof design, allowing your birds to perch outside the cage for interaction and exercise.

1. To open the roof, gently lift the top panels upwards.
2. Use the included wooden perch to prop open the roof, creating a secure perching area for your bird.
3. To close, remove the perch and lower the panels until they are securely latched.



The open-top design includes a perch that keeps the top doors open for your birds to stand on, top doors can be opened or closed at will.

Image 5.1: Open-top design with a bird perching.

## 5.2. Feeding and Watering

The cage is equipped with four sliding side doors for easy access to food and water cups.

- Gently slide the small doors up or down to access the food/water cups from outside the cage.
- Refill or replace food and water as needed without disturbing your birds.

## 6. MAINTENANCE

---

Regular cleaning is crucial for your bird's health and the longevity of the cage.

### 6.1. Daily Cleaning

- Remove and clean food and water cups daily.
- Check and remove any visible droppings from perches and the bottom grid.

## 6.2. Weekly Cleaning

The slide-out tray and bottom grid make cleaning convenient:

1. Carefully slide out the bottom tray for easy disposal of waste.
2. Remove the bottom wire mesh grid.
3. Wash the tray and grid with mild soap and water. Rinse thoroughly and dry completely before returning them to the cage.
4. Wipe down all cage surfaces with a damp cloth.



Image 6.1: Features highlighting solid structure, easy cleaning, and adequate bar spacing.

## 7. TROUBLESHOOTING

Here are solutions to common issues you might encounter:

- **Cage feels unstable:** Ensure all panels are correctly aligned and all clips/fasteners are securely engaged during assembly. Double-check that the base is firmly attached.
- **Difficulty sliding tray:** Check for any debris or obstructions in the tray runners. Ensure the tray is inserted correctly and not at an angle.
- **Bird trying to escape:** Verify that all doors (main and feeder doors) are fully closed and latched. Confirm the bar spacing is appropriate for your bird's size (1 cm spacing).
- **Perches are loose:** Re-tighten the perch attachments. If perches are worn, consider replacing them.

## 8. SPECIFICATIONS

Feature	Detail
---------	--------

Feature	Detail
Model Number	VC591824White260122
Overall Dimensions (L x W x H)	46 cm x 35 cm x 92.5 cm
Bar Spacing	1 cm
Material	Coated Iron Wire, Plastic Base, Wooden Perches
Color	White
Specific Uses	Indoor, Outdoor
Weight	4.4 kg



Image 8.1: Detailed dimensions of the bird cage.

## 9. WARRANTY AND SUPPORT

Yaheetech products are designed for quality and durability. For information regarding returns, warranty claims, or product support, please refer to the retailer's return policy or contact Yaheetech customer

service directly. Typically, products can be returned within 30 days of receipt if you change your mind. For defective or damaged products, specific help pages are available through your purchase platform.

For further assistance, please visit the official Yaheetech store or contact their customer support channels.