

- Manuals.plus /
- › Bluefin SUP /
- › Bluefin SUP Stand Up Inflatable Paddle Board | 14' Sprint Model | Touring/Race Model | Complete with All Accessories

Bluefin SUP Sprint 14'

Bluefin SUP Sprint 14' Inflatable Paddle Board Instruction Manual

Brand: Bluefin SUP | Model: Sprint 14'

INTRODUCTION

Welcome to the Bluefin SUP Sprint 14' Inflatable Paddle Board manual. This guide provides essential information for setting up, operating, maintaining, and troubleshooting your new paddle board. Designed for touring and speed, the Sprint 14' offers exceptional stability and performance. Please read through these instructions carefully to ensure safe and enjoyable use of your product.

SETUP AND ASSEMBLY

1. Inflation

Unroll the paddle board on a flat, clean surface. Locate the high-pressure valve. Ensure the valve pin is in the 'up' position for inflation. Connect the double action pump hose to the valve. Begin pumping until the board reaches the recommended pressure of 15 PSI (up to a maximum of 28 PSI for optimal rigidity). The double action pump inflates on both the up and down strokes, speeding up the process.




Image: Inflation process and board dimensions.



Image: The complete Bluefin SUP Sprint 14' kit.

2. Fin Installation

The Sprint 14' features a Smart Lock Fin system. With the board inflated, slide the 8-inch center fin into the fin box located on the underside of the board. Secure it by pressing down the locking lever until it clicks into place. No tools or small parts are required.

3. Paddle Assembly

Assemble the lightweight fiberglass paddle by connecting the two main shaft pieces. Ensure the adjustable height mechanism is securely fastened after setting the paddle to your preferred length (170-220 cm). The no-flutter polyurethane composite blade is designed for durability and efficient paddling.



Image: Paddle assembly and adjustable height feature.

OPERATING INSTRUCTIONS

1. Paddling Techniques

For optimal balance and tracking, stand with your feet parallel and shoulder-width apart over the center of the board. Keep your knees slightly bent and your core engaged. For kneeling, position yourself on your knees in the center of the board, maintaining balance with the paddle.



Image: Paddler demonstrating standing technique on the Sprint 14'.

2. Steering and Maneuvering

The angled nose of the Sprint 14' is designed for efficient wave cutting and straight-line tracking. To steer, apply more pressure on one side of the board with your paddle, or use sweep strokes to turn. The board's length (427 cm) provides excellent glide, making it ideal for covering longer distances efficiently.



Image: The Sprint 14' offers optimal balance and tracking for touring.

MAINTENANCE

1. Cleaning and Drying

After each use, rinse your paddle board with fresh water to remove any salt, sand, or debris. Use a mild soap if necessary. Ensure the board is completely dry before deflating and storing to prevent mold and mildew growth.

2. Storage

Deflate the board by pressing the valve pin down and turning it to lock in the open position. Roll the board tightly from the nose towards the tail, expelling all air. Store the board and accessories in the provided durable travel backpack in a cool, dry place away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

1. Board Not Holding Air

Check the valve for any debris or loose components. Ensure the valve cap is tightly secured after inflation. Inspect the board's surface for any punctures or damage. Small punctures can often be repaired using the included repair kit.

2. Difficulty Inflating

Verify that the pump hose is securely attached to the valve and that the valve pin is in the 'up' position. If using an electric pump, ensure it is properly connected and powered. Manual inflation may require significant effort to reach higher PSI levels.

SPECIFICATIONS

Feature	Detail
Product Dimensions	168.11"L x 27.95"W
Item Thickness	16 Centimeters
Maximum Pressure	28 Pound per Square Inch
Item Weight	17.66 Kilograms
Material	Polyvinyl Chloride (PVC)
Skill Level	All
Included Components	Paddle board

WARRANTY AND SUPPORT

Bluefin SUP products come with a 5-year support commitment. For any questions, issues, or warranty claims, please visit the official Bluefin SUP store or contact their customer support directly.
[Visit the Bluefin SUP Store](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07C2TD5PV>

More documents and user manuals: **<https://manuals.plus/>**