

Loupedeck LD+

Loupedeck+ Photo and Video Editing Console User Manual

Model: LD+

1. INTRODUCTION

The Loupedeck+ is a versatile editing console designed to streamline photo and video editing workflows. It offers tactile control over various software functions, enhancing precision and efficiency for both professional and amateur creators. This manual provides essential information to help you get started and make the most of your Loupedeck+ device.



Figure 1: Top view of the Loupedeck+ console.

2. SETUP

Follow these steps to set up your Loupedeck+ console:

1. **Unboxing:** Carefully remove the Loupedeck+ console from its packaging. Ensure all components, including the

USB cable, are present.

2. **System Requirements:** Verify your computer meets the minimum operating system requirements. The Loupedeck+ is compatible with Windows 10 or later and macOS 10.14 or later.
3. **Software Installation:** Download and install the latest Loupedeck software from the official Loupedeck website. This software is essential for the console's functionality and customization.
4. **Connect to Computer:** Connect the Loupedeck+ to your computer using the provided USB cable. The console is USB-powered and does not require an external power adapter.
5. **Software Launch:** Launch the Loupedeck software. The software should automatically detect your connected Loupedeck+ device.
6. **Initial Configuration:** The software will guide you through the initial setup, including selecting your primary editing applications and loading default profiles.




Figure 2: Loupedeck+ in use, illustrating its compact size and connectivity.

3. OPERATING THE LOUPEDECK+

The Loupedeck+ is designed for intuitive and efficient control over your creative software. It features a combination of dials, buttons, and color wheels, each programmable for various functions.

3.1 Key Features and Controls

- **Control Dial:** A large, central dial for precise adjustments, often used for primary parameters like exposure or timeline navigation.
- **Adjustment Dials (D1, D2, etc.):** Multiple smaller dials for fine-tuning specific parameters such as contrast, clarity, shadows, highlights, temperature, and tint.
- **Programmable Buttons (P1-P8, C1-C6, L1-L3):** These buttons can be assigned to various shortcuts, macros, or

functions within your software.

- **Color Wheels:** Dedicated sliders and buttons for adjusting Hue, Saturation, and Luminance, providing tactile control over color grading.
- **Dedicated Function Buttons:** Buttons for common actions like Undo, Redo, Custom Mode, Before/After view, Screen Mode, and Export.




Figure 3: Overview of Loupedeck+ controls.

3.2 Software Compatibility

The Loupedeck+ offers native support and deep integration with a wide range of creative applications, including:

- Adobe Lightroom Classic
- Capture One Pro (for MacOS)
- Adobe Photoshop
- Adobe Premiere Pro
- Adobe After Effects
- Adobe Audition

- Final Cut Pro X
- Illustrator
- Ableton Live
- Spotify Premium
- OBS, Streamlabs (for Windows)
- Twitch
- vMix
- Philips Hue
- Operating System Control



Works with your software

LOUPEDECK NATIVE PLUGINS

Loupedeck+ integrates seamlessly with leading creative software such as Adobe Lightroom Classic, Photoshop, Premiere Pro, Final Cut Pro, Capture One Pro, and more, offering time-saving features that make editing faster and easier.



Figure 4: Loupedeck+ compatibility with various software applications.

3.3 Customization

The Loupedeck software allows extensive customization:

- Create up to 4 layers of programmable controls for each application profile.
- Combine multiple actions into a single button.
- Develop custom macros and multi-toggle actions.
- Adjust rotary controls to your preference.
- Build custom profiles for any creative application not natively supported.

Loupedeck Software

NEW IMPROVED USER INTERFACE

Customize all buttons and dials and create up to 4 layers of controls per application profile.

Combine several actions in one button, create custom dial adjustments and text commands.

Explore new plugins in the Loupedeck Marketplace.



Figure 5: Loupedeck software interface for customization.

3.4 Official Product Video

Video 1: Loupedeck+ Photo Editing Console for Lightroom, Skylum Aurora HDR, and Capture One. This video demonstrates the console's functionality and integration with popular photo editing software.

4. MAINTENANCE

To ensure the longevity and optimal performance of your Loupedeck+:

- **Cleaning:** Use a soft, dry cloth to wipe down the surface of the console. For stubborn smudges, a slightly damp cloth with mild soap can be used, ensuring no liquid enters the device.
- **Avoid Liquids:** Keep the console away from liquids to prevent damage to internal components.
- **Storage:** When not in use, store the Loupedeck+ in a clean, dry environment, away from direct sunlight or extreme temperatures.
- **Cable Care:** Avoid bending or crimping the USB cable excessively to prevent internal wire damage.

5. TROUBLESHOOTING

If you encounter issues with your Loupedeck+, refer to the following common solutions:

- **Device Not Recognized:**
 - Ensure the USB cable is securely connected to both the Loupedeck+ and your computer.
 - Try connecting to a different USB port.

- Restart your computer and the Loupedeck software.
- Verify that the Loupedeck software is up to date.
- **Controls Not Responding:**
 - Check if the correct application profile is active in the Loupedeck software.
 - Ensure the software you are trying to control is open and in focus.
 - Restart the Loupedeck software and the creative application.
- **Software Crashes/Freezes:**
 - Ensure your operating system and creative software are up to date.
 - Temporarily disable any conflicting background applications.
 - Reinstall the Loupedeck software if the issue persists.

For further assistance, consult the official Loupedeck support resources or community forums.

6. SPECIFICATIONS

Feature	Detail
Brand	Loupedeck
Model Number	LD+
Connectivity Technology	USB
Operating System Compatibility	Windows 10 or later, macOS 10.14 or later
Item Weight	1.48 pounds
Product Dimensions (LxWxH)	15.55 x 5.91 x 15.55 inches
Color	Black
Power Source	USB-powered
Number of Keys	24

7. WARRANTY AND SUPPORT

Loupedeck products typically come with a manufacturer's warranty covering defects in materials and workmanship. For specific warranty terms and conditions, please refer to the warranty card included with your product or visit the official Loupedeck website.

For technical support, software updates, and additional resources, please visit the Loupedeck support page. You can also find an extensive knowledge base and community forums for common questions and tips.

Online Resources:

- Loupedeck Official Website: loupedeck.com

- Loupedeck Support: Refer to the support section on the official website for FAQs, drivers, and contact information.