

[Manuals.plus](#) /

- › [Emporio Armani](#) /
- › Emporio Armani AR11135 Quartz Watch Instruction Manual

Emporio Armani AR11135

Emporio Armani AR11135 Quartz Watch Instruction Manual

Model: AR11135

1. INTRODUCTION

This manual provides essential instructions for the proper use and care of your Emporio Armani AR11135 Quartz Watch. This timepiece features a precise quartz movement with a 3-hand analog display and date function, housed in a 43mm stainless steel case with a leather band. Please read this manual thoroughly to ensure optimal performance and longevity of your watch.





Image 1.1: Front view of the Emporio Armani AR11135 Quartz Watch, showcasing the rose gold case, navy dial, and leather band.

2. SETUP AND INITIAL OPERATION

2.1 Setting the Time

1. **Pull the crown out to position 2:** Locate the crown on the right side of the watch case. Gently pull it out until you feel two distinct clicks. The second hand will stop, indicating the watch is in time-setting mode.
2. **Rotate the crown:** Turn the crown clockwise or counter-clockwise to move the hour and minute hands to the desired time. Ensure you set the correct AM/PM by observing the date change (the date will change around midnight).
3. **Push the crown back to position 0:** Once the time is set, push the crown back in completely to its original position. The second hand will resume movement.

2.2 Setting the Date

1. **Pull the crown out to position 1:** Gently pull the crown out until you feel one click. The watch will continue to run.
2. **Rotate the crown:** Turn the crown clockwise to advance the date. Do not attempt to set the date between 9:00 PM and 3:00 AM, as this may damage the movement. If the current time falls within this period, first set the time outside this range, then set the date, and finally reset the correct time.

3. **Push the crown back to position 0:** Once the date is set, push the crown back in completely.





Image 2.1: Side view of the watch, highlighting the crown used for setting time and date.

3. OPERATING YOUR WATCH

3.1 Quartz Movement

Your Emporio Armani AR11135 watch is powered by a precise quartz movement, which uses a battery and a vibrating quartz crystal to keep accurate time. This ensures consistent and reliable timekeeping with minimal maintenance.

3.2 Water Resistance

This watch is water resistant up to 50 meters (5 ATM). This means it is suitable for short periods of recreational swimming in shallow water. It is **not** suitable for diving, snorkeling, or high-impact water sports. Always ensure the crown is fully pushed in before any contact with water. Avoid operating the crown while the watch is wet or submerged.

3.3 Daily Wear

For optimal comfort and to prevent excessive wear on the leather band, ensure the watch fits snugly but not too tightly on your wrist. Avoid exposing the watch to extreme temperatures, direct sunlight for prolonged periods, or harsh chemicals.



Image 3.1: The Emporio Armani AR11135 watch displayed on a wrist, illustrating its fit and appearance.

4. MAINTENANCE AND CARE

4.1 Cleaning

- Wipe the watch case and crystal with a soft, dry cloth regularly to remove dust and fingerprints.
- For the leather band, avoid excessive moisture. If it gets wet, gently pat it dry and allow it to air dry naturally, away from direct heat or sunlight.
- Do not use chemical cleaners, solvents, or abrasive materials, as these can damage the watch's finish or the leather band.

4.2 Battery Replacement

Your watch uses one LR44 battery. When the battery is depleted, the watch will stop running. Battery replacement should be performed by a qualified watch technician to ensure proper sealing and maintain water resistance.

Attempting to replace the battery yourself may void the warranty and compromise the watch's integrity.

4.3 Storage

When not in use, store your watch in a cool, dry place, preferably in its original box or a watch case, to protect it from dust, moisture, and scratches. Avoid storing it near strong magnetic fields, such as those produced by speakers, refrigerators, or certain electronic devices, as this can affect the quartz movement's accuracy.



Image 4.1: The Emporio Armani watch box, suitable for safe storage.

5. TROUBLESHOOTING

- **Watch not running:**
 - Check if the crown is fully pushed in to position 0.
 - The battery may be depleted. Refer to section 4.2 for battery replacement.
- **Incorrect time or date:**
 - Refer to section 2.1 and 2.2 for instructions on setting the time and date.
- **Condensation under the crystal:**

- This may indicate a loss of water resistance. Avoid further contact with water and have the watch inspected by a qualified technician immediately.

6. SPECIFICATIONS

Model Number	AR11135
Movement Type	Quartz with 3-hand analog display and date
Case Diameter	43mm
Band Width	22mm
Case Material	Stainless Steel (Rose Gold-tone)
Band Material	Leather calfskin (Navy)
Crystal Type	Mineral
Water Resistance	50 meters (5 ATM)
Battery Type	1 x LR44 (included)
Product Dimensions	3.86 x 4.49 x 4.25 inches; 8 ounces




Image 6.1: A general case size guide for watches, illustrating various watch diameters.

7. WARRANTY AND SUPPORT

Your Emporio Armani watch is covered by a manufacturer's warranty against defects in materials and workmanship. For specific warranty terms, duration, and to register your product, please refer to the warranty card included with your purchase or visit the official Emporio Armani website. For technical support or service inquiries, please contact Emporio Armani customer service or an authorized service center.

Manufacturer: Emporio Armani Watches

Brand Store: [Emporio Armani Store on Amazon](#)