

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [AMERTEER](#) /

› [AMERTEER Wireless Presenter Remote User Manual](#)

AMERTEER RCRF-006

AMERTEER Wireless Presenter Remote User Manual

Brand: AMERTEER | Model: RCRF-006

INTRODUCTION

The AMERTEER Wireless Presenter Remote is a versatile tool designed to enhance your presentations. Equipped with a 2.4GHz RF hyperlink and volume control, this clicker allows for seamless navigation through slides and media. Its built-in rechargeable battery ensures long-lasting performance, making it compatible with various operating systems and presentation software, including Keynote, PowerPoint, Mac, PC, and Laptops.

SETUP

Setting up your AMERTEER Wireless Presenter Remote is quick and easy, thanks to its plug-and-play technology. No additional drivers are required.

1. Charging the Presenter

Before first use, ensure the presenter is fully charged. It features a built-in rechargeable Li-polymer battery.

- Connect the provided Micro USB cable to the presenter's USB input port.
- Connect the other end of the cable to a laptop's USB port or a wall adapter.
- A full charge takes approximately 2 hours and provides up to 7 days of usage time.

PRODUCT DETAILS



Image: The AMERTEER Wireless Presenter Remote connected to a charging cable, illustrating its rechargeable battery feature with indicators for 2 hours charging time and 7 days usage time.

2. Connecting the USB Receiver

The mini USB receiver enables wireless communication between the presenter and your computer. It supports plug-and-play technology, meaning no driver installation is needed.

- Locate the mini USB receiver, which is magnetically stored within the presenter for convenience.
- Insert the USB receiver into an available USB port on your computer (laptop or PC).
- The system will automatically recognize the device and install necessary components.



Image: The AMERTEER Wireless Presenter Remote shown alongside its mini USB receiver, ready for connection to a computer, demonstrating its compact design and plug-and-play readiness.

OPERATING INSTRUCTIONS

The AMERTEER Wireless Presenter Remote provides intuitive controls for a smooth presentation experience.

Button Functions:

Page Navigation & Window Switching

Use the dedicated buttons for moving through your presentation slides and switching between open windows.

- **Page Up/Down:** Navigate to the previous or next slide.
- **Switch Windows:** Quickly switch between active applications or presentation windows.




Page Up & Down



Switch Windows



Volume Control



Open Hyperlink

Image: Close-up of the presenter remote highlighting the Page Up/Down and Switch Windows buttons, with corresponding on-screen actions.

Volume Control & Hyperlink Function

Manage audio levels and interact with hyperlinks directly from the remote.

- **Volume Up/Down:** Adjust the system volume during your presentation.
- **Hyperlink:** One click to choose, double click to open hyperlinks within your presentation.

Universal Compatibility

Windows, Android, Mac IOS, Unix, Linux



macOs



Linux



Windows



Ubuntu



Andrioid

Software



Canva



Prezi



Google slides



Keynote



Power Point



Image: The presenter remote illustrating the volume control buttons on the side and the hyperlink activation button on the front.

Laser Pointer & Full Screen/Black Screen

Highlight key points and manage screen visibility.

- **Laser Button:** Activate the red laser pointer to draw attention to specific areas. The laser has a light range of up to 656 feet.
- **Full Screen/Black Screen:** Toggle between full-screen presentation mode and a black screen to focus audience attention.

Presentation Remote Clicker Rechargeable

- **Slim And Fashion Mirror Design**
- **Light Weight For Easy Carrying**
- **Specific Power Button For Power Saving**
- **Magnetic Storage Design For USB Receiver**



PLUG & PLAY TECHNOLOGY

**No additional driver needed,
just plug the USB into
computer to begin**

Image: A hand holding the presenter remote, demonstrating the bright red laser light being used in a presentation setting, with specifications for light range (656ft) and wireless range (100ft).

Wireless Range & Compatibility

Enjoy freedom of movement and broad system support.

- **Wireless Range:** Offers wireless control up to 39 feet (approximately 12 meters).
- **Operating Systems:** Compatible with Win2000, XP, Vista, Win7, Win8, Win10, MAC OS, Linux, Android, Unix.
- **Software Support:** Supports PowerPoint, MS Word, Excel, ACD See, website, iWork (Keynote & Numbers & Pages), Google Slides, Prezi, etc.

RECHARGEABLE PRESENTER CLICKER

Fast charging with the provided usbcable to keep long using time



2 Hours
Charging Time



7 Days
Using Time



Image: The presenter remote displayed with icons representing various compatible operating systems (macOS, Linux, Windows, Ubuntu, Android) and software (Canva, Prezi, Google Slides, Keynote, PowerPoint).

Product Overview Diagram:

Familiarize yourself with the different parts and their functions.



BRIGHT RED LIGHT

Red light is easier to draw audience's attention



656FT
Light Range



100FT
Wireless Range

Image: A detailed diagram of the AMERTEER Wireless Presenter Remote, labeling its components including LED indicator light, Hyperlink button, Page Up/Down buttons, Laser button, USB Charger port, ON/OFF switch, Volume buttons, and USB Receiver storage.

MAINTENANCE

To ensure the longevity and optimal performance of your AMERTEER Wireless Presenter Remote, follow these maintenance guidelines:

- **Charging:** Recharge the device when the battery indicator shows low power. Avoid completely draining the battery frequently to prolong its lifespan.
- **Cleaning:** Wipe the full mirror glass surface and body with a soft, dry cloth. Avoid using abrasive cleaners or solvents.
- **Storage:** When not in use, store the presenter and its USB receiver in a cool, dry place. The magnetic storage for the USB receiver helps prevent loss.
- **Handling:** Handle the device with care. Avoid dropping it or exposing it to extreme temperatures or moisture.

TROUBLESHOOTING

If you encounter issues with your AMERTEER Wireless Presenter Remote, consider the following common solutions:

- **Presenter Not Responding:**

- Ensure the presenter is sufficiently charged.
- Verify that the USB receiver is securely plugged into a working USB port on your computer.
- Check if the presenter's ON/OFF switch is in the 'ON' position.
- Try plugging the USB receiver into a different USB port.
- Restart your computer.

- **Laser Pointer Not Working:**

- Ensure the presenter is powered on and charged.
- Press the laser button firmly.

- **Limited Wireless Range:**

- Ensure there are no significant obstructions between the presenter and the USB receiver.
- Avoid strong electromagnetic interference from other devices.

- **Buttons Not Functioning Correctly:**

- Confirm that the presenter is connected and recognized by your computer.
- Check if the presentation software is active and in focus.
- For hyperlink function, ensure you are in a compatible application and the hyperlink is active.

SPECIFICATIONS

Feature	Detail
Product Dimensions	5 x 0.7 x 0.4 inches
Item Weight	0.67 ounces
Model Number	RCRF-006
Batteries	1 Lithium Polymer battery (included)
Wireless Technology	2.4GHz RF
Wireless Range	Up to 39 feet (approx. 12 meters)
Laser Light Range	Up to 656 feet (approx. 200 meters)
Charging Time	Approx. 2 hours
Usage Time	Up to 7 days
Manufacturer	Shenzhen Kangson Electronic Co.,Ltd
ASIN	B07C4WHYCF

WARRANTY AND SUPPORT

For specific warranty information and support inquiries regarding your AMERTEER Wireless Presenter Remote (Model: RCRF-006), please refer to the documentation included with your purchase or contact the manufacturer directly.

Manufacturer: Shenzhen Kangson Electronic Co.,Ltd

For further assistance, you may also visit the AMERTEER store page on Amazon or contact the seller, AMERTEERUS, through the Amazon platform.

© 2024 AMERTEER. All rights reserved.