

[Manuals.plus](#) /

› [Benzara](#) /

› Benzara BM163498 Queen/Queen Bunk Bed Instruction Manual

Benzara BM163498

Benzara BM163498 Queen/Queen Bunk Bed Instruction Manual

Model: BM163498 | Brand: Benzara

1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Benzara BM163498 Queen/Queen Bunk Bed. Please read all instructions carefully before beginning assembly and retain this manual for future reference. Proper assembly and care will ensure the longevity and safe use of your bunk bed.

2. IMPORTANT SAFETY INFORMATION

WARNING: Failure to follow these warnings and instructions could result in serious injury or death.

- Always use the recommended mattress size for both the upper and lower bunks to prevent entrapment or falls.
- Ensure all connections are tight before use and periodically check to ensure they remain secure.
- The top bunk is designed for a maximum weight of **175 lbs**. The bottom bunk is designed for a maximum weight of **350 lbs**. Do not exceed these weight limits.
- The top bunk is not suitable for children under 6 years of age.
- Always use the ladder for entering and exiting the upper bunk. Do not use the bed as a play structure.
- Ensure guardrails are properly installed on the upper bunk.
- Prohibit more than one person on the upper bunk.
- Do not attach or hang items to any part of the bunk bed that are not designed for use with the bed; for example, but not limited to, hooks, belts, and jump ropes.
- Keep these instructions for future reference.




Figure 1: Bunk bed dimensions and weight capacity. The top bunk has a maximum weight capacity of 175 lbs, and the bottom bunk has a maximum weight capacity of 350 lbs. Overall dimensions are 83 inches L x 63 inches W x 65 inches H.

3. SETUP AND ASSEMBLY

The Benzara BM163498 Bunk Bed requires assembly. It ships in several boxes, which may arrive separately. It is recommended to assemble the bed with at least two adults.

3.1. Unpacking and Parts Identification

- Carefully unpack all components and hardware from the boxes.
- Place all parts on a soft, clean surface to prevent scratches.
- Verify that all listed components are present. Refer to the included parts list (usually found in a separate sheet within the packaging).
- Included components: Guardrails, Ladder, Slats.

3.2. Assembly Steps

1. **Assemble the Lower Bunk Frame:** Connect the side rails to the headboard and footboard using the provided hardware. Ensure all bolts are finger-tight only at this stage.
2. **Install Lower Bunk Slats:** Place the metal slats onto the lower bunk frame. Secure them according to the instructions provided with the hardware.
3. **Assemble the Upper Bunk Frame:** Repeat step 1 for the upper bunk frame.
4. **Install Upper Bunk Slats:** Place the metal slats onto the upper bunk frame. Secure them.
5. **Stack the Bunks:** Carefully lift the upper bunk frame and place it onto the lower bunk frame, aligning the

connection points. Secure with the appropriate hardware.

6. **Attach Guardrails:** Install the full-length guardrails to the upper bunk. Ensure they are securely fastened.
7. **Attach Ladder:** The front ladder is reversible. Attach it to the desired side of the bunk bed, ensuring it is firmly secured to prevent movement during use.
8. **Final Tightening:** Once all components are in place, systematically tighten all bolts and screws using the provided tools. Do not overtighten.



Figure 2: The Benzara BM163498 Queen/Queen Bunk Bed frame after complete assembly, showcasing the metal construction, guardrails, and integrated ladder.



Figure 3: The bunk bed with mattresses placed on both the upper and lower bunks, illustrating how the bed appears when ready for bedding.

4. OPERATING INSTRUCTIONS

Once assembled, the Benzara BM163498 Bunk Bed is ready for use. Ensure that mattresses are placed securely on both bunks.

- **Upper Bunk Access:** Always use the integrated ladder to access or exit the upper bunk. Do not jump onto or off the upper bunk.
- **Weight Distribution:** Distribute weight evenly on both bunks. Adhere strictly to the weight limits: 175 lbs for the top bunk and 350 lbs for the bottom bunk.
- **Mattress Requirements:** Use mattresses that fit snugly within the bed frame to prevent gaps where a child could become entrapped.



Figure 4: The Benzara Queen/Queen Bunk Bed in a typical bedroom environment, demonstrating its functional use with bedding on both levels.

5. MAINTENANCE AND CARE

Regular maintenance will help preserve the condition and safety of your bunk bed.

- **Cleaning:** Wipe the metal frame with a soft, dry cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Hardware Check:** Periodically check all bolts, screws, and connections to ensure they are tight. Retighten as necessary to maintain stability and safety.
- **Environmental Conditions:** Avoid exposing the bed to extreme humidity or direct sunlight for prolonged periods, as this may affect the material integrity over time.

6. TROUBLESHOOTING

If you encounter any issues with your bunk bed, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Bed feels wobbly or unstable.	Loose hardware connections.	Carefully re-tighten all bolts and screws. Ensure the bed is on a level surface.
Squeaking noises during use.	Loose connections or friction between metal parts.	Check and tighten all hardware. If squeaking persists, a small amount of lubricant (e.g., silicone spray) can be applied to connection points, avoiding contact with sleeping surfaces.
Ladder feels loose.	Ladder attachment hardware is not secure.	Ensure the ladder is correctly hooked and all securing bolts are fully tightened.

7. PRODUCT SPECIFICATIONS

Feature	Detail
Model Number	BM163498
Brand	Benzara
Size	Queen/Queen
Product Dimensions	83"L x 63"W x 65"H
Color	Black
Finish Type	Black
Included Components	Guardrails, Ladder, Slats
Item Weight	129 pounds
Assembly Required	Yes
Top Bunk Weight Capacity	175 lbs
Bottom Bunk Weight Capacity	350 lbs

8. WARRANTY AND SUPPORT

For warranty information, please refer to the documentation included with your purchase or contact the retailer where the product was purchased. Benzara provides customer support for product inquiries and assistance with parts. Please have your model number (BM163498) and purchase details ready when contacting support. You can visit the Benzara Store for more information:[Benzara Store on Amazon](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07C5K7HJ9>

More documents and user manuals: **<https://manuals.plus/>**