vidaXL 42792

vidaXL Garden Terrace Patio Table (Model 42792) Instruction Manual

Model: 42792 | Brand: vidaXL

INTRODUCTION

Thank you for choosing the vidaXL Garden Terrace Patio Table. This durable and easy-to-assemble outdoor dining table features a WPC top and a powder-coated aluminum frame, designed for long-lasting use in various weather conditions. This manual provides essential information for the safe assembly, operation, maintenance, and troubleshooting of your new table. Please read it thoroughly before assembly and retain it for future reference.

Image: Front view of the vidaXL Garden Terrace Patio Table, showcasing its black WPC top and aluminum frame.

SAFETY INFORMATION

To ensure safe use and prevent injury or damage, please observe the following safety guidelines:

- Always assemble the table on a flat, stable surface to prevent tipping.

- Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten as necessary.

- Do not overload the table. Refer to specifications for weight capacity (if available, otherwise use general caution).

- Keep children and pets away from the assembly area. Small parts can be a choking hazard.

- Avoid placing hot items directly on the WPC surface without protection to prevent damage.

- Do not stand or sit on the table.

- In strong winds, consider securing the table or moving it to a sheltered location to prevent it from being blown over.

PACKAGE CONTENTS

Before beginning assembly, verify that all components are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Tabletop (WPC)

- Table Legs (Aluminum, 4 pcs)

- Frame Connectors/Brackets (Aluminum)

- Hardware Pack (Screws, washers, Allen key)

- Assembly Guide (This document)

SETUP AND ASSEMBLY

The vidaXL patio table is designed for effortless assembly. It is recommended that one person performs the assembly.

1. Unpack all components and lay them out on a clean, soft surface to prevent scratches.

2. Attach the table legs to the frame connectors using the provided screws and Allen key. Do not fully tighten the screws at this stage.

3. Carefully place the WPC tabletop onto the assembled frame. Align the pre-drilled holes on the tabletop with the frame.

4. Secure the tabletop to the frame using the remaining screws.

5. Once all components are loosely assembled, gradually tighten all screws evenly until secure. Avoid over-tightening.

6. Gently lift the table and place it upright on its legs. Ensure it is stable and does not wobble. Adjust leg levelers if present and necessary.

Image: The assembled vidaXL Garden Terrace Patio Table, ready for use.

OPERATING INSTRUCTIONS (USAGE)

This vidaXL patio table is designed for outdoor dining and general outdoor use. It is suitable for non-residential applications.

- Place the table on a level, stable surface in your garden, terrace, or patio area.
- Use coasters or placemats to protect the WPC surface from scratches and heat.
- Distribute weight evenly across the tabletop.
- Avoid dragging the table; always lift it when moving to prevent damage to legs or frame.

MAINTENANCE

Proper maintenance will extend the life and appearance of your patio table.

- **Cleaning:** Wipe the table surface and frame with a dry cloth regularly to remove dust and dirt. For more stubborn dirt, use a damp cloth with mild soap and water, then dry thoroughly.
- **Stain Resistance:** The table is not stain resistant. Clean spills immediately to prevent permanent marks.
- **Weather Protection:** While designed for outdoor use, covering the table during harsh weather conditions (heavy rain, snow, extreme sun) or prolonged periods of non-use will help preserve its condition.
- **Fasteners:** Periodically check all screws and bolts to ensure they remain tight. Re-tighten if necessary.
- **Storage:** If storing indoors during off-season, ensure the table is clean and dry.

TROUBLESHOOTING

If you encounter any issues with your table, refer to the following common solutions:

Problem	Possible Cause	Solution
Table wobbles or is unstable.	Uneven surface; loose fasteners.	Move table to a level surface. Check and tighten all assembly screws.

Problem	Possible Cause	Solution
Difficulty during assembly.	Incorrect alignment of parts; screws not fully loosened.	Review the assembly steps. Ensure all screws are only finger-tight until all parts are aligned, then tighten evenly.
Scratches or marks on surface.	Sharp objects; abrasive cleaning.	Use coasters/placemats. Clean with soft cloth. Minor scratches on WPC may be buffed gently with fine sandpaper (test in an inconspicuous area first).

SPECIFICATIONS

Detailed product specifications for the vidaXL Garden Terrace Patio Table (Model 42792).

Brand: vidaXL

Model Number: 42792

Dimensions (L x W x H): 72.8" x 35.4" x 29.1" (185 cm x 90 cm x 74 cm)

Item Weight: 22 Kilograms

Frame Material: Powder-Coated Aluminum

Tabletop Material: WPC (Wood Plastic Composite)

Color: Black

Shape: Rectangular

Assembly Required: Yes (Recommended 1 person)

Usage: Outdoor Dining

Base Type: Leg

Foldable: No

Image: Diagram showing the dimensions of the vidaXL Garden Terrace Patio Table (185 cm / 72.8" length, 90 cm / 35.4" width, 74 cm / 29.1" height).

WARRANTY INFORMATION

All products sold by vidaXL are covered by a legal guarantee of at least 2 years. This warranty covers manufacturing defects and material faults under normal use. Please retain your proof of purchase for any warranty

claims. For specific terms and conditions, refer to the official vidaXL website or contact customer support.

Customer Support

If you have any questions, require assistance with assembly, or need to report a missing or damaged part, please contact vidaXL customer support. You can typically find contact information on the official vidaXL website or through your retailer's support channels.
For more information, visit the vidaXL Store on Amazon.