

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

> [Armitron](#) /

> [Armitron Women's 75/2447 Diamond-Accented Leather Strap Watch User Manual](#)

Armitron 75/2447BLK

Armitron Women's 75/2447 Diamond-Accented Leather Strap Watch User Manual

Model: 75/2447BLK

INTRODUCTION

This manual provides essential information for the proper use, care, and maintenance of your Armitron Women's 75/2447 Diamond-Accented Leather Strap Watch. Please read it thoroughly to ensure optimal performance and longevity of your timepiece.

PRODUCT OVERVIEW

The Armitron 75/2447 is a classic analog watch designed for women, featuring a diamond accent and a durable leather strap. Key features include:

- Round watch face with a diamond hour marker at the 12 o'clock position.
- Gold-tone dial features and hands.
- Smooth black leather band with a buckle closure.
- Reliable Japanese quartz movement for accurate timekeeping.
- Protective mineral crystal dial window, designed to resist scratches.





Image: Front view of the Armitron Women's 75/2447 Diamond-Accented Leather Strap Watch. The watch features a black dial with gold-tone hands and hour markers, a single diamond at the 12 o'clock position, and a black leather strap with a gold-tone buckle.

SETUP

Your Armitron watch comes with a battery pre-installed. Before first use, ensure any protective film or plastic

stopper on the crown is removed.

1. **Unpack:** Carefully remove the watch from its packaging.
2. **Inspect:** Check for any protective plastic on the watch face or crown. Remove these if present.
3. **Initial Time Setting:** If the watch is not running, pull out the crown (the small knob on the side of the watch case) to the time-setting position. Rotate the crown to set the correct time, then push it back in to start the watch.

OPERATING INSTRUCTIONS

Setting the Time

1. Locate the crown on the right side of the watch case.
2. Gently pull the crown outwards until you feel a click. This is the time-setting position. The second hand may stop moving.
3. Rotate the crown clockwise or counter-clockwise to move the hour and minute hands to the desired time.
4. Once the correct time is set, push the crown back into its original position. The second hand will resume movement (if it stopped), indicating the watch is now running.



Image: The Armitron 75/2447 watch worn on a wrist, providing a perspective of its size and appearance when worn. The black leather strap and gold-tone case are visible.

MAINTENANCE

Care and Cleaning

- **Cleaning:** Wipe the watch case and crystal with a soft, dry cloth. For the leather strap, avoid excessive moisture. If it gets wet, allow it to air dry naturally.
- **Water Resistance:** This watch is generally designed for everyday use and can withstand splashes or brief immersion. However, it is not suitable for swimming or diving. Avoid exposing the watch to hot water or steam, as this can damage seals.
- **Temperature:** Avoid exposing your watch to extreme temperatures, both hot and cold, as this can affect the battery life and movement accuracy.
- **Chemicals:** Keep the watch away from solvents, detergents, perfumes, and cosmetics, as these can damage the case, strap, or seals.
- **Magnetic Fields:** Strong magnetic fields can affect the accuracy of quartz watches. Keep the watch away from strong magnets.

Battery Replacement

The watch is powered by a product-specific battery (included). When the watch stops running, it indicates the battery needs replacement. It is recommended to have the battery replaced by a qualified watch technician to ensure proper sealing and prevent damage to the movement.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Watch not running	Battery depleted or crown pulled out.	Push the crown in fully. If still not running, the battery may need replacement. Consult a watch technician.
Time is inaccurate	Watch exposed to strong magnetic fields or low battery.	Reset the time. If inaccuracy persists, consider battery replacement or professional inspection.
Condensation under crystal	Exposure to extreme temperature changes or moisture ingress.	Seek professional service immediately to prevent damage to the movement.

SPECIFICATIONS

Model Number	75/2447BLK
Movement	Japanese Quartz
Dial Window Material	Mineral Crystal
Case Material	Metal Alloy (Gold-tone finish)
Band Material	Leather
Clasp Type	Buckle
Battery	1 Product Specific battery (included)
Product Dimensions	8.4 x 13.8 x 8.8 cm; 17.01 g

WARRANTY AND SUPPORT

Armitron watches typically come with a limited warranty covering manufacturing defects. For specific warranty terms and conditions, please refer to the warranty card included with your purchase or visit the official Armitron website. For technical support or service inquiries, please contact Armitron customer service.

Manufacturer: Armitron



Image: The grey product box for the Armitron watch, featuring the "ARMITRON" logo on the lid. This box typically contains the watch and accompanying documentation, including warranty information.