

[manuals.plus](#) /

› [Legami](#) /

› [Legami Warm It Up Panda USB Mug Warmer Instruction Manual WIU0001](#)

Legami WIU0001

Legami Warm It Up Panda USB Mug Warmer Instruction Manual

Model: WIU0001

INTRODUCTION

The Legami Warm It Up Panda USB Mug Warmer is designed to keep your beverages warm. This device is compatible with mugs or glasses that have a flat bottom and connects to any standard USB port (PC or Mac). Please read this manual carefully before using the product to ensure safe and optimal operation.



Image: Front view of the Legami Warm It Up Panda USB Mug Warmer packaging, showing the panda design and product name.

SAFETY INFORMATION AND WARNINGS

Important: Failure to follow these safety instructions may result in fire, electric shock, injury, or damage to the product or property.

- **DO NOT** immerse the mug warmer in water or any other liquid.
- **DO NOT** wash the mug warmer in a dishwasher.
- **DO NOT** use with paper or polystyrene cups, as these materials are not suitable for heating and may pose a fire hazard.
- Ensure the surface where the mug warmer is placed is heat-resistant to prevent damage.
- The device may take a few minutes to warm up to its operating temperature.
- The warming performance may be reduced if other USB ports on your computer are heavily utilized.
- Always unplug the device when not in use or before cleaning.
- Keep out of reach of children.



Image: Back of the product packaging displaying multilingual safety warnings and product specifications.

PACKAGE CONTENTS

- 1 x Legami Warm It Up Panda USB Mug Warmer (Model: WIU0001)

SETUP

1. Unpack the Legami Warm It Up Panda USB Mug Warmer from its packaging.
2. Place the mug warmer on a flat, stable, and heat-resistant surface.



Image: The Legami Warm It Up Panda USB Mug Warmer, showing its integrated USB cable.

3. Connect the USB plug of the mug warmer into an available USB port on your computer (PC or Mac) or a compatible USB power adapter (not included).



Image: A close-up view of the standard USB-A connector, which plugs into a computer or power adapter.

4. Ensure the connection is secure. The warmer will begin to heat up once connected.

OPERATING INSTRUCTIONS

1. After connecting the mug warmer as described in the "Setup" section, allow a few minutes for the device to reach its optimal warming temperature.
2. Place your mug or glass, containing your beverage, directly onto the center of the panda mug warmer. Ensure the mug or glass has a flat bottom for efficient heat transfer.



Image: A mug placed on the Legami Warm It Up Panda USB Mug Warmer, which is connected to a laptop via its USB cable, demonstrating typical use.

3. The mug warmer will maintain the temperature of your beverage. Note that this device is designed to keep warm beverages warm, not to heat cold beverages.
4. To turn off the mug warmer, simply disconnect the USB cable from the port.

MAINTENANCE

- Always unplug the mug warmer before cleaning.
- Wipe the surface of the warmer with a soft, damp cloth. Do not use abrasive cleaners or immerse the device in water.
- Ensure the device is completely dry before reconnecting it to a power source.
- Store the mug warmer in a cool, dry place when not in use.

TROUBLESHOOTING

Problem: The mug warmer is not heating.

Solution 1: Ensure the USB cable is securely plugged into a functioning USB port. Try a different USB port or a different computer/USB power adapter.

Solution 2: If connected to a computer, check if other USB ports are heavily in use, as this can reduce power to the warmer. Disconnect other non-essential USB devices.

Problem: Beverage is not staying warm enough.

Solution 1: Ensure your mug or glass has a flat bottom to maximize contact with the heating surface.

Solution 2: The device is designed to maintain warmth, not to heat cold liquids. Start with an already warm beverage.

Solution 3: Check the room temperature. In very cold environments, the warmer's effectiveness may be reduced.

SPECIFICATIONS

Model Number	WIU0001
Brand	Legami
Material	Plastic
Power Source	Electric (USB)
Voltage	5 Volts
Wattage	7 watts
Upper Temperature Rating	140 Degrees Fahrenheit (approx. 60 Degrees Celsius)
Product Dimensions	3.75"L x 3.45"W x 0.28"H (approx. 9.5 cm x 8.8 cm x 0.7 cm)
Item Weight	3.52 ounces (approx. 100 grams)
USB Cable Length	95 cm (approx. 37.4 inches)
GTIN (UPC)	8051122263790



Image: A diagram illustrating the approximate dimensions of the mug warmer, showing a width of 3.7 inches (9 cm).

WARRANTY AND SUPPORT

Specific warranty information for the Legami Warm It Up Panda USB Mug Warmer is not provided in the product details. For warranty claims or technical support, please refer to the retailer where the product was purchased or visit the official Legami website for their customer service contact information. You can find more information about Legami products and support at: www.legami.com

© 2026 Legami. All rights reserved.