

## AutoFull AF047UM/IN

# AutoFull Gaming Chair Model AF047UM/IN Instruction Manual

Model: AF047UM/IN

## INTRODUCTION

---

Welcome to your new AutoFull Gaming Chair. This manual provides detailed instructions for the assembly, operation, maintenance, and troubleshooting of your chair. Reading this manual thoroughly before assembly and use will help ensure optimal performance, comfort, and longevity of your product. Please retain this manual for future reference.

## SAFETY INFORMATION

---

- **Maximum Weight Capacity:** This chair is designed to support a maximum weight of 150 kilograms (approximately 330 pounds). Do not exceed this limit to prevent damage or injury.
- **Proper Use:** Use the chair only for its intended purpose of sitting. Avoid standing on the chair, using it as a step stool, or for any other unintended activities.
- **Assembly:** Ensure all components are securely fastened before use. Periodically check all screws and bolts to ensure they remain tight.
- **Children and Pets:** Keep children and pets away from the assembly area. Small parts can be a choking hazard.
- **Floor Protection:** Consider using a chair mat, especially on delicate flooring, to prevent scratches from the chair's wheels.
- **Moving the Chair:** When moving the chair, lift it rather than dragging it to prevent damage to the base or floor.

## PACKAGE CONTENTS

---

Before beginning assembly, please verify that all parts are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Backrest
- Seat Base

- Armrests (2)
- Gas Lift Cylinder
- Five-Star Base
- Casters (5)
- Mechanism Plate
- Lumbar Support Pillow
- Headrest Pillow
- Hardware Kit (screws, washers, Allen wrench)
- Instruction Manual (this document)

## ASSEMBLY INSTRUCTIONS

---

Follow these steps carefully to assemble your AutoFull Gaming Chair. It is recommended to assemble the chair on a soft, clean surface to prevent damage.

1. **Attach Casters to Base:** Insert each of the five casters into the holes at the end of each leg of the five-star base until they click securely into place.
2. **Install Gas Lift:** Place the gas lift cylinder into the center hole of the five-star base. Ensure it is seated firmly.
3. **Attach Mechanism Plate to Seat:** Align the mechanism plate with the pre-drilled holes on the underside of the seat base. Secure it using the provided screws and Allen wrench. Ensure the front of the mechanism plate faces the front of the seat.
4. **Connect Seat to Gas Lift:** Carefully place the assembled seat onto the gas lift cylinder, ensuring the center hole of the mechanism plate aligns with the top of the gas lift. Press down firmly to secure.
5. **Attach Armrests:** Secure the armrests to the sides of the seat base using the designated screws. Ensure they are oriented correctly (left and right).
6. **Attach Backrest to Seat:** Align the backrest with the metal brackets on the seat base and armrests. Secure it using the remaining screws. Do not overtighten.
7. **Install Pillows:** Attach the headrest pillow and lumbar support pillow using their integrated straps. Adjust their positions for personal comfort.



Image: Overview of AutoFull Gaming Chair features, including height adjustment, 360-degree swivel, and Class 4 gas lift.

## OPERATING INSTRUCTIONS

Your AutoFull Gaming Chair offers several adjustable features to customize your seating experience for maximum comfort and ergonomic support.

- **Height Adjustment:** Locate the lever on the right side, beneath the seat. Pull the lever upwards to raise the seat. To lower the seat, pull the lever upwards while seated. Release the lever at the desired height.
- **Recline Function:** The chair back can be reclined and locked at various angles between 90 and 170 degrees. Use the recline lever, typically found on the left side of the seat, to adjust the backrest angle. Push the lever down to unlock and recline, then pull it up to lock the backrest in position.
- **Armrest Adjustment:** The armrests are height-adjustable. Press the button on the side of each armrest and move it up or down to your preferred height. Release the button to lock.
- **Lumbar Support:** The detachable lumbar support pillow can be moved up or down along the backrest straps to provide support to your lower back at the most comfortable position.
- **Tilt Lock:** The chair features a tilt mechanism. A separate lever (often on the right side, near the height adjustment) allows you to lock the chair in an upright position or enable a rocking motion.
- **360° Swivel:** The chair's base allows for full 360-degree rotation.



Image: Illustration of the chair's flexible recline angles for various activities.



Image: Detailed view of the removable headrest, adjustable armrest, and lumbar support.

## Product Features Video

Your browser does not support the video tag.

Video: This video demonstrates the key adjustable features of the AutoFull Gaming Chair, including lumbar support, armrest adjustment, and recline functionality.

## MAINTENANCE

- **Cleaning:** For general cleaning, wipe the chair with a soft, damp cloth. For stubborn stains on PU leather, use a mild soap solution and wipe dry immediately. Avoid harsh chemicals or abrasive cleaners.
- **Mesh Back Care:** The breathable mesh back can be gently vacuumed to remove dust. For spills, dab with a damp cloth and mild soap, then air dry.
- **Hardware Check:** Periodically (e.g., every 3-6 months) check all screws and bolts to ensure they are tight. Loose hardware can affect stability and safety.
- **Caster Care:** Clean casters regularly to remove hair, dust, and debris that can impede smooth rolling.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause the material to fade or crack.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Chair is unstable or wobbly.	Loose screws or bolts.	Check and tighten all assembly screws and bolts. Ensure the gas lift is properly seated in the base.
Chair does not adjust height.	Gas lift malfunction or lever not engaged.	Ensure the height adjustment lever is fully engaged. If the issue persists, the gas lift may need replacement. Contact support.
Chair squeaks when moving.	Loose connections or friction between parts.	Tighten all screws. Apply a small amount of silicone lubricant to moving parts or connection points if necessary.
Casters do not roll smoothly.	Debris caught in casters.	Turn the chair over and remove any hair, dust, or debris from the caster wheels.

## SPECIFICATIONS

Feature	Detail
Brand	AutoFull
Model Name	AF047UM/IN

Feature	Detail
<b>Product Dimensions (D x W x H)</b>	11.81"D x 25.2"W x 34.64"H (approximate, as packaged)
<b>Overall Dimensions (assembled, from image)</b>	Seat Width: 20 in / 52 cm, Backrest Width: 22 in / 56 cm, Seat Depth: 19 in / 47 cm, Seat Height Range: 16-20 in / 40-50 cm, Total Height: 54 in / 137 cm
<b>Item Weight</b>	41.8 pounds (19 Kilograms)
<b>Maximum Weight Recommendation</b>	150 Kilograms (330 lbs)
<b>Material</b>	PU Leather Surface, Dense Foam Padding, Thicken Steel Frame, Breathable Mesh Back
<b>Special Features</b>	Adjustable Height, 90-170° Recline, Adjustable Armrests, Detachable Lumbar Support, Detachable Headrest, 360° Swivel, Class 4 Gas Lift
<b>Back Style</b>	Solid Back with Mesh Panel



Image: Dimensional diagram of the AutoFull Gaming Chair.

## WARRANTY AND SUPPORT

---

AutoFull provides the following warranty for your gaming chair:

- **30-Day Policy:** Free replacement or money back for quality reasons within 30 days of purchase.
- **Frame Warranty:** Lifetime warranty on the chair frame.
- **Parts Warranty:** 24 months warranty on all other parts.

For any dissatisfaction with our products, missing parts, or to claim warranty service, please contact AutoFull customer support directly. We are committed to resolving any issues you may encounter. You can visit the official AutoFull store for more information: [AutoFull Store on Amazon](#)