

[Manuals.plus](#) /

› [KHOI1971](#) /

› KHOI1971 4-FT Wall AC Power Adapter Instruction Manual

KHOI1971 KHOI1971 ® CUSTOM MADE

KHOI1971 4-FT Wall AC Power Adapter Instruction Manual

Model: KHOI1971 ® CUSTOM MADE

INTRODUCTION

This manual provides essential information for the safe and effective use of your **KHOI1971 4-FT Wall AC Power Adapter**. Please read this manual thoroughly before use and retain it for future reference.



Image 1: The KHOI1971 4-FT Wall AC Power Adapter, showing its compact design and barrel connector.

PRODUCT FEATURES

- **Smart IC Chip:** Features an intelligent integrated circuit chip for automatic shut-off, protecting your device from overcharging and power fluctuations.
- **Universal Input:** Supports 100-240V AC input, making it suitable for use in various regions.
- **LED Power Indicator:** A built-in LED light provides a visual indication when the adapter is receiving power.
- **Compatibility:** Specifically designed for the V1179 Luv U Zoo Fisher Price Cradle N Swing Baby.
- **Cable Length:** 4-foot cable for convenient reach.

SAFETY INFORMATION

Always observe the following safety precautions:

- Use only with compatible devices as specified.
- Do not expose the adapter to water or excessive moisture.
- Avoid dropping or subjecting the adapter to severe impact.
- Do not attempt to disassemble or modify the adapter.
- Unplug the adapter from the wall outlet when not in use for extended periods.
- Keep out of reach of children.

SETUP

1. **Verify Compatibility:** Ensure your device is the V1179 Luv U Zoo Fisher Price Cradle N Swing Baby or another device requiring a 12V DC input with a compatible barrel connector.
2. **Connect to Device:** Insert the barrel connector end of the power adapter firmly into the power input port of your Fisher Price Cradle N Swing.
3. **Connect to Power Outlet:** Plug the AC prongs of the power adapter into a standard 100-240V wall outlet.
4. **Power Indicator:** The LED light on the adapter will illuminate, indicating that power is being supplied.



Image 2: Illustrative image showing the power adapter connected to a compatible Fisher Price Cradle N Swing.

OPERATING INSTRUCTIONS

Once the adapter is properly connected, your Fisher Price Cradle N Swing will receive power. Operate your device according to its own instruction manual. The adapter provides a stable 12V DC power supply.

- The smart IC chip automatically regulates power to prevent overcharging or damage to your device.
- The LED indicator confirms active power flow.

MAINTENANCE

To ensure the longevity and optimal performance of your power adapter:

- **Cleaning:** Disconnect the adapter from the power outlet and the device before cleaning. Wipe the adapter with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Storage:** Store the adapter in a cool, dry place away from direct sunlight and extreme temperatures. Avoid tightly winding the cable to prevent damage.
- **Inspection:** Periodically inspect the cable and connector for any signs of wear, fraying, or damage. If damage is observed, discontinue use immediately.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Adapter LED not lit / Device not powering on	No power from wall outlet.	Test the wall outlet with another appliance.
	Adapter not fully plugged in.	Ensure the adapter is securely plugged into the wall outlet.
	Device not fully connected.	Ensure the barrel connector is fully inserted into the device.
	Adapter or device malfunction.	Try the adapter with another compatible device (if available) or contact support.
Device powers on but behaves erratically	Incorrect adapter used.	Verify the adapter is the correct model for your device (V1179 Luv U Zoo Fisher Price Cradle N Swing Baby).
	Adapter is faulty.	Discontinue use and contact support.

SPECIFICATIONS

Feature	Detail
Model Number	KHOI1971 ® CUSTOM MADE
Input Voltage	AC 100-240V, 50/60Hz, 0.35A
Output Voltage	DC 12V
Connector Type	Barrel Connector
Cable Length	4 Feet (approx. 1.2 meters)
Color	Black
Special Features	Smart IC Chip for auto shut-off, LED Power Indicator
Compatible Devices	V1179 Luv U Zoo Fisher Price Cradle N Swing Baby
Certifications	UL

WARRANTY INFORMATION

This product is covered by a standard manufacturer's warranty. For details regarding warranty terms, duration, and claims, please refer to the information provided at the time of purchase or contact KHOI1971 customer support. Keep your proof of purchase for warranty validation.

CUSTOMER SUPPORT

For technical assistance, troubleshooting, or warranty inquiries, please contact KHOI1971 customer support:

- **Online:** Visit the official KHOI1971 store on Amazon: [KHOI1971 Store](#)
- **Seller Contact:** You may also contact the seller directly through your Amazon order history.

Please have your product model number (KHOI1971 ® CUSTOM MADE) and purchase date ready when contacting support.

© 2024 KHOI1971. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07C7S52LT>

More documents and user manuals: <https://manuals.plus/>