



[Manuals.plus](#) /

› [Ravensburger](#) /

› Ravensburger 221479 Geveze Sincap Board Game Instruction Manual

Ravensburger Geveze Sincap ROT221479

Ravensburger Geveze Sincap Board Game Instruction Manual

Model: Geveze Sincap ROT221479 | Brand: Ravensburger

1. INTRODUCTION

The Ravensburger Geveze Sincap (Chatty Squirrel) is an engaging board game designed for 1 to 4 players, suitable for ages 4 and above. The objective of the game is for players to carefully remove different colored logs from a river setup without disturbing the naughty beaver. The player who successfully collects the most logs by the end of the game wins. This manual provides detailed instructions for setting up, playing, and maintaining your game.

2. SAFETY INFORMATION

WARNING: CHOKING HAZARD – Small Parts. This game contains small parts and is not suitable for children under 3 years of age. Adult supervision is recommended during play, especially with younger children, to ensure all components are handled appropriately.

3. PACKAGE CONTENTS

Please check the box to ensure all the following components are included:

- 1 x Squirrel Figure
- Numerous Logs (in various colors)
- 1 x Stick Tool
- 1 x Game Base (river/log pile structure)
- 1 x User Manual (this document)



Image: All game components laid out, including the game base, squirrel, logs, and stick tool.

4. SETUP

1. **Assemble the Game Base:** Place the green river banks onto the blue river base, ensuring they are securely connected.
2. **Insert the Logs:** Carefully insert all the colored logs into the holes in the game base, creating a pile. Mix the colors randomly.
3. **Place the Squirrel:** Position the squirrel figure on top of the log pile. The squirrel is designed to react if the logs are disturbed too much.
4. **Prepare the Stick:** Keep the stick tool within easy reach of all players.
5. **Player Seating:** Players should sit around the game base, ensuring everyone has equal access to the logs.



Image: The game box alongside the fully assembled game base with logs and the squirrel in place.

5. OPERATING (HOW TO PLAY)

The game is played in turns. The goal is to collect logs without making the squirrel complain.

- Starting the Game:** The youngest player typically starts the game.
- Player's Turn:** On your turn, use the stick tool to carefully push one log out of the pile. You may choose any log you wish.
- Collecting Logs:** If you successfully remove a log without the squirrel reacting (making a sound or shaking significantly), you keep that log.
- Squirrel's Reaction:** If the squirrel reacts when you remove a log, you must return the log to the pile (if possible) or forfeit your turn. The squirrel's reaction indicates that the log pile was disturbed too much.

5. **End of Turn:** After your turn, play passes to the next player in a clockwise direction.
6. **Game End:** The game continues until all logs have been removed or the squirrel has reacted a predetermined number of times (refer to specific game rules if included in the box for variations).
7. **Winning the Game:** The player who has collected the most logs at the end of the game is the winner.



Image: Two children playing the Geveze Sincap game, demonstrating the interaction with the log pile.

6. MAINTENANCE

To ensure the longevity of your Ravensburger Geveze Sincap game, follow these simple maintenance guidelines:

- **Cleaning:** Wipe all plastic components with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, followed by immediate drying. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store all game components in their original box in a cool, dry place away from direct sunlight and extreme temperatures.
- **Handling:** Handle the squirrel figure and game base with care to avoid damage to any sensitive mechanisms.

7. TROUBLESHOOTING

If you encounter any issues during gameplay, consider the following:

- **Squirrel Not Reacting:** Ensure the squirrel is correctly placed on top of the log pile. Check if the logs are inserted properly and creating enough tension for the squirrel's mechanism to detect movement.
- **Logs Falling Too Easily:** Verify that the game base is on a flat, stable surface. Ensure logs are inserted firmly into their slots.
- **Missing Components:** Refer to the 'Package Contents' section. If any parts are missing upon initial unboxing, contact Ravensburger customer support.

8. SPECIFICATIONS

Brand	Ravensburger
Model Name	Geveze Sincap

Model Number	ROT221479
Part Number	221479
Country of Origin	Germany
Material	Plastic
Color	Multi-color
Age Range	4 - 99 Years
Number of Players	1 - 4
Product Dimensions	55.2 x 23.3 x 33.7 cm (21.7 x 9.2 x 13.3 inches)
Product Weight	0.78 Kilograms (1.72 lbs)
Operation Mode	Manual
Educational Purpose	Strategy
Assembly Required	No (Minor setup of logs and squirrel)

9. WARRANTY AND SUPPORT

Warranty Information: This product is sold without an explicit manufacturer's warranty. Please refer to the retailer's return policy for details on returns or exchanges for defective items.

Customer Support: For further assistance, questions about gameplay, or inquiries regarding missing parts, please visit the official Ravensburger website or contact their customer service department. Contact information can typically be found on the Ravensburger packaging or their official website.

10. OFFICIAL PRODUCT VIDEOS

No official product videos from the seller were found for embedding in this manual.