

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Amcrest](#) /

› [Amcrest AMCPFA130-E Waterproof Junction Box Instruction Manual](#)

## Amcrest AMCPFA130-E

# Amcrest AMCPFA130-E Waterproof Junction Box Instruction Manual

**MODEL: AMCPFA130-E**

**Brand: Amcrest**

## Introduction

This manual provides detailed instructions for the installation, operation, and maintenance of the Amcrest AMCPFA130-E Waterproof Junction Box. This junction box is designed to protect and conceal wiring and connectors for compatible Amcrest bullet and dome cameras, ensuring a clean and secure installation, particularly in outdoor or exposed environments.

## Setup and Installation

The Amcrest AMCPFA130-E junction box is constructed from durable aluminum and SECC materials, providing robust protection for camera connections. It is designed for surface mounting and offers rear/bottom access for cable routing.

### Package Contents:

- Amcrest AMCPFA130-E Junction Box
- Mounting Screws and Wall Anchors
- Allen Wrench (for opening the box)

### Installation Steps:

1. **Preparation:** Ensure the installation surface is clean and stable. Identify the desired mounting location, considering cable routing and camera field of view.
2. **Marking Drill Holes:** Place the junction box against the mounting surface and mark the positions for the three mounting holes.
3. **Drilling:** Drill pilot holes at the marked positions. If mounting on masonry or concrete, insert the provided wall anchors.

- 4. Mounting the Box:** Secure the junction box to the surface using the provided mounting screws. Ensure it is firmly attached.
- 5. Cable Management:** Route the camera's cables through the rear or bottom access points of the junction box. Connect the necessary power and data cables.
- 6. Camera Attachment:** Attach your compatible Amcrest camera to the front plate of the junction box using the camera's mounting screws. Ensure all connections are secure and waterproof.
- 7. Sealing:** For outdoor installations, apply a weather-resistant sealant around the edges of the junction box where it meets the mounting surface to prevent water ingress.



This image displays the Amcrest AMCPFA130-E Waterproof Junction Box, highlighting its key dimensions. The box has a diameter of 4.87 inches and a height of 1.62 inches, providing space for cable management and connections.

**Your browser does not support the video tag.**

This video provides an overview of Amcrest's commitment to simple, reliable, and secure surveillance solutions, demonstrating how their products, including accessories like junction boxes, contribute to comprehensive home and business security.

## Operation

The Amcrest AMCPFA130-E Waterproof Junction Box is a passive component designed to house and

protect the electrical connections and excess cabling of your security camera. Once installed, its primary function is to provide a secure, weather-resistant enclosure, ensuring the longevity and reliable operation of your camera's wiring.

## Maintenance

To ensure optimal performance and longevity of your junction box and camera system, periodic maintenance is recommended:

- **Visual Inspection:** Regularly check the exterior of the junction box for any signs of damage, cracks, or loose components.
- **Seal Integrity:** Inspect the sealant around the box and mounting surface for any deterioration. Reapply sealant if necessary to maintain waterproof integrity.
- **Cleaning:** Clean the exterior of the box with a soft, damp cloth to remove dirt, dust, or debris. Avoid using harsh chemicals that could damage the finish.
- **Fastener Check:** Periodically verify that all mounting screws are tight and secure.

## Troubleshooting

Most issues related to the junction box are installation-dependent. If you experience problems with your camera system after installing the junction box, consider the following:

- **Camera Not Functioning:** Verify that all cable connections inside the junction box are secure and correctly wired. Ensure power is supplied to the camera.
- **Water Ingress:** If moisture is found inside the box, immediately disconnect power to the camera. Inspect all seals and cable entry points for damage or improper sealing. Re-seal as needed.
- **Loose Mounting:** If the junction box feels loose, tighten the mounting screws. If the wall anchors are compromised, consider relocating or using stronger anchors.

For camera-specific issues, refer to your camera's instruction manual or contact Amcrest support.

## Specifications

|                           |                           |
|---------------------------|---------------------------|
| <b>Model Number</b>       | AMCPFA130-E               |
| <b>Material</b>           | Aluminum & SECC           |
| <b>Color</b>              | White                     |
| <b>Style</b>              | Compact                   |
| <b>Finish Type</b>        | Powder Coated             |
| <b>Installation Type</b>  | Mounted                   |
| <b>Item Weight</b>        | 0.4 Kilograms (14 ounces) |
| <b>Package Dimensions</b> | 5.75 x 5.71 x 2.56 inches |
| <b>UPC</b>                | 851352008516              |

## Warranty and Support

Amcrest products come with a **1-YEAR US WARRANTY** and **LIFETIME SUPPORT**, provided directly by Amcrest. For technical assistance, warranty claims, or further information, please visit the official Amcrest website or contact their customer support.