

## Eueasy B07CBR86VT

# Eueasy Replacement Remote for Leggett & Platt S-Cape Adjustable Beds

Model: B07CBR86VT

## INTRODUCTION

This manual provides essential instructions for the setup, operation, and maintenance of your Eueasy Replacement Remote. This remote is specifically designed for compatibility with certain older Leggett & Platt S-Cape adjustable bed models that utilize Raven electronics, and may also function with older Sleep Number remotes. It is important to verify your bed's compatibility before use.

## SETUP

### 1. Battery Installation

The remote requires batteries for operation. Ensure you have the correct type and size as specified in the product details (Alkaline batteries are typically required).

1. Locate the battery compartment on the back of the remote control.
2. Open the battery compartment cover.
3. Insert the required batteries, observing the correct polarity (+/-) as indicated inside the compartment.
4. Close the battery compartment cover securely.

### 2. Pairing the Remote with Your Adjustable Bed

To establish communication between the remote and your adjustable bed, a pairing process is necessary. This process may require multiple attempts. Ensure your bed's power down box has fresh 5-volt batteries if applicable.

1. **Prepare the Bed:** Unplug the adjustable bed's power cord from the wall outlet. Wait for approximately 30 seconds.
2. **Restore Power:** Plug the adjustable bed's power cord back into the wall outlet.
3. **Activate Power Down Box:** Locate the power down box (if present) on your bed frame. Press and hold the button on the power down box for approximately 5 seconds. Both the power down box and

the remote should blink green lights simultaneously, indicating they are ready for pairing.

4. **Initiate Remote Pairing:** Immediately after the lights blink, press the designated pairing button or sequence on your new Eueasy remote. *(Note: The specific button or sequence may vary; refer to any included quick-start guide or look for a "Pair" or "Sync" button on the remote itself.)*
5. **Verify Pairing:** Test the remote's functions (e.g., head up/down, foot up/down). If the bed responds, pairing is successful.
6. **Repeat if Necessary:** If pairing is unsuccessful, repeat the entire sequence from step 1 multiple times until the remote successfully controls the bed. Patience is key during this process.

## OPERATING INSTRUCTIONS

The Eueasy Replacement Remote provides control over the basic functions of compatible adjustable beds. While specific button layouts may vary, common functions include:

- **Head Up/Down:** Adjusts the head section of the bed upwards or downwards.
- **Foot Up/Down:** Adjusts the foot section of the bed upwards or downwards.
- **Flat:** Returns the bed to a completely flat position.
- **Preset Positions:** Some remotes may feature preset buttons (e.g., "Zero Gravity," "Lounge") that move the bed to pre-programmed positions. If your remote has these, press the corresponding button to activate the preset.

Familiarize yourself with the buttons on your specific remote model to utilize all available functions.

## MAINTENANCE

- **Battery Replacement:** Replace batteries promptly when the remote's performance degrades or it stops responding. Always use new batteries of the specified type.
- **Cleaning:** Clean the remote with a soft, dry cloth. Avoid using liquid cleaners or abrasive materials, which can damage the remote's surface or internal components.
- **Storage:** Store the remote in a dry place, away from extreme temperatures and direct sunlight.
- **Protection:** Avoid dropping the remote or exposing it to excessive force, as this can cause internal damage.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Remote not responding.	Dead or low batteries. Remote not paired. Obstruction between remote and bed receiver.	Replace batteries. Re-attempt pairing process (see Setup section). Ensure clear line of sight.
Bed moves erratically or not as expected.	Interference. Partial pairing.	Move away from other electronic devices. Repeat the pairing process.

Problem	Possible Cause	Solution
Pairing fails after multiple attempts.	Incorrect pairing sequence. Incompatible bed model. Faulty power down box or bed receiver.	Carefully follow pairing steps, ensuring timing is correct. Confirm your bed model is compatible with this remote. Contact a qualified technician if issues persist.

## SPECIFICATIONS

---

- **Model:** B07CBR86VT
- **Brand:** Eueasy
- **Compatibility:** Older Leggett & Platt S-Cape adjustable bed models with Raven electronics; older Sleep Number remotes.
- **Batteries Required:** Yes
- **Battery Type:** Alkaline

## WARRANTY AND SUPPORT

---

Information regarding specific warranty terms or direct support contacts for the Eueasy Replacement Remote is not provided in the product details. Please refer to the retailer or your purchase documentation for any available warranty information or customer service contacts.

## IMPORTANT NOTES ON MEDIA

---

No relevant product images or official product videos were provided in the source data for this specific remote control. The images provided in the input were for a different product (earbuds) and are therefore not included in this manual to avoid confusion.