Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Coolife yd72

Coolife Luggage Expandable 5 Piece Sets User Manual

Brand: Coolife | Model: yd72

INTRODUCTION

This user manual provides essential information for the proper use, setup, and maintenance of your Coolife Expandable 5-Piece Luggage Set. Designed for durability and convenience, this set features lightweight PC+ABS material, smooth spinner wheels, and a secure TSA-approved lock, ensuring a comfortable travel experience.



Image: The complete Coolife 5-piece luggage set, showcasing the various sizes and the white grid new design.

Safety Information

- Do not overload luggage beyond its stated capacity to prevent damage to zippers, handles, and the shell.
- Keep luggage away from open flames and extreme heat sources.
- Ensure all zippers are fully closed before lifting or checking luggage.
- Always use the telescopic handle and spinner wheels on flat, stable surfaces for optimal maneuverability.
- Store luggage in a cool, dry place when not in use.

Package Contents

Your Coolife 5-Piece Luggage Set includes the following items:

- 1 x 16-inch Suitcase
- 1 x 20-inch Suitcase (Carry-on size)
- 1 x 24-inch Suitcase
- 1 x 28-inch Suitcase (Expandable)
- 1 x Cosmetic Case

Setup

Setting the TSA Combination Lock

Your luggage is equipped with a TSA-approved combination lock. The initial combination is set to 0-0-0.

1. Locate the reset button (a small, recessed button) next to the dials. Use a pen or a pointed object to press and hold this button.
2. While holding the reset button, set your desired 3-digit combination by rotating the dials.
3. Release the reset button. Your new combination is now set.
4. Test your new combination by scrambling the dials and then entering your new code to open the lock.
5. Remember your combination. Do not write it down on the luggage.



Image: A detailed view of the built-in TSA-approved combination lock, showing the dials and release mechanism.

Operating Instructions

Telescopic Handle Operation

The multi-stage telescopic handle allows for comfortable maneuvering for users of different heights.

- To extend the handle: Press the button located on the top of the handle and pull upwards until it locks into your desired height.
- To retract the handle: Press the button and push the handle downwards until it is fully recessed.



Image: The adjustable telescopic handle shown in various extended positions, along with close-ups of the reinforced grip handle, dent-proof corner protector, and side bumper feet.

Using the Dual Spinner Wheels

Each suitcase is equipped with four dual spinner wheels, providing 360-degree rotation for effortless mobility in any direction.

- For smooth movement, push the luggage upright on all four wheels.
- Avoid dragging the luggage on two wheels for extended periods, as this can cause premature wear on the wheels.



Image: The spacious interior of the luggage with organized mesh pockets, a view of the dual spinner wheels, and an illustration of the expandable feature on the 28-inch model.

Utilizing the Expansion Feature (28-inch suitcase only)

The 28-inch suitcase in your set features an expandable zipper, providing approximately 15% additional packing space.

- To expand: Locate the secondary zipper running along the perimeter of the suitcase and unzip it.
- To return to standard size: Zip the expansion zipper closed.

Cosmetic Case Usage

The included cosmetic case is designed for organizing smaller items and can be securely attached to the telescopic handle of a larger suitcase for convenient transport.



Image: The interior of the cosmetic case, open and filled with various personal items, demonstrating its storage capacity.

Maintenance

- **Cleaning the Shell:** Wipe the PC+ABS hard shell with a soft, damp cloth and mild soap. Avoid abrasive cleaners or solvents that could damage the finish.
- **Zippers:** Periodically check zippers for debris. If they become stiff, apply a small amount of zipper lubricant or wax.
- **Wheels:** Inspect wheels regularly for tangled hair or debris. Clean them gently with a brush if necessary. Avoid exposing wheels to excessive dirt or sand.
- **Handles:** Ensure the telescopic handle extends and retracts smoothly. Do not force it if it gets stuck.
- **Storage:** When not in use, store luggage in a clean, dry environment, preferably nested inside each other to save space.

Troubleshooting

Problem	Possible Cause	Solution
TSA Lock not opening/resetting.	Incorrect combination; reset button not fully pressed.	Ensure the correct combination is entered. Re-attempt the reset procedure, ensuring the reset button is fully depressed before setting a new code. If forgotten, contact customer support.
Wheels not rolling smoothly.	Debris (hair, lint) caught in wheels; damaged wheel.	Clean wheels thoroughly to remove any obstructions. If a wheel is damaged, contact customer support for replacement options.
Telescopic handle sticking.	Dirt/debris in mechanism; bent handle.	Clean the handle mechanism. Do not force the handle. If bent or severely stuck, avoid further use and contact customer support.
Zippers are difficult to move.	Dirt/debris in zipper teeth; zipper misalignment.	Clean zipper teeth with a small brush. Apply a zipper lubricant or wax. Ensure the zipper is aligned correctly before pulling.

Specifications

Detailed specifications for each piece in the Coolife 5-Piece Luggage Set:



Image: A visual guide detailing the exterior measurements, weight, capacity, and recommended travel days for each suitcase size (16, 20, 24, 28 inches) and the cosmetic case.

Piece	Exterior Measurements (L x W x H)	Weight	Capacity	Travel Days (Approx.)
16-inch Suitcase	11.8" x 8.1" x 18.7"	4.6 lbs	30L	1-2 days
20-inch Suitcase	15.4" x 8.7" x 22.4"	6.3 lbs	38L	1-4 days
24-inch Suitcase	17.3" x 9.8" x 26.4"	8.1 lbs	60L	4-7 days
28-inch Suitcase	20.1" x 11.8" (13.0" expanded) x 30.3"	10.2 lbs	93L	7-9 days
Cosmetic Case	14.2" x 6.8" x 10.6"	1.9 lbs	N/A	N/A

Note: Maximum height of the extended handle is 41 inches.

Warranty and Support

For warranty information, product support, or to inquire about replacement parts, please contact Coolife customer service directly. Refer to the contact information provided with your purchase or visit the official Coolife website.
You can also visit the Coolife Store on Amazon for more information and product offerings.

© 2025 Coolife. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07CBYWVLZ

More documents and user manuals: **https://manuals.plus/**