Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Soundstream XP1.1600D

Soundstream XP1.1600D Class D Monoblock Amplifier

User Manual

1. Introduction

Thank you for choosing the Soundstream XP1.1600D Class D Monoblock Amplifier. This amplifier is designed to deliver powerful and clear audio performance for your vehicle's sound system. This manual provides essential information for the proper installation, operation, and maintenance of your amplifier to ensure optimal performance and longevity.

Please read this manual thoroughly before attempting installation or operation. Keep this manual for future reference.

2. Safety Instructions

To prevent injury or damage to the amplifier, always observe the following safety precautions:

- **Professional Installation Recommended:** Installation of car audio components can be complex. If you are unsure about any part of the installation process, seek assistance from a qualified professional.
- **Disconnect Battery:** Always disconnect the vehicle's negative battery terminal before beginning any electrical work to prevent accidental short circuits.
- **Proper Wiring:** Ensure all wiring is correctly sized and fused. Incorrect wiring can lead to overheating, fire, or damage to the amplifier and vehicle.
- **Ventilation:** Install the amplifier in a location that allows for adequate air circulation. Do not mount the amplifier in an enclosed space without proper ventilation, as this can lead to overheating.
- **Secure Mounting:** Mount the amplifier securely to prevent it from coming loose during vehicle operation, which could cause injury or damage.
- **Avoid Moisture:** Do not expose the amplifier to moisture or water.
- **Correct Impedance:** Ensure the speaker load impedance matches the amplifier's specifications to prevent damage.

3. Setup and Installation

Careful installation is crucial for optimal performance and safety. The Soundstream XP1.1600D is designed for independent mounting.



This image displays the Soundstream XP1.1600D monoblock amplifier, featuring a black casing with silver accents and the Soundstream 'Tarantula' logo prominently displayed on top. The model number 'XP1.1600D' and '1600W' are also visible on the unit.

3.1 Mounting Location

- Choose a dry, well-ventilated location away from direct sunlight or heat sources.
- Ensure the mounting surface is sturdy enough to support the amplifier's weight.
- Allow at least 2 inches (5 cm) of clearance around the amplifier for proper heat dissipation.

3.2 Wiring Connections

All wiring should be of appropriate gauge for the power requirements and kept as short as possible to minimize signal loss and interference.

- **Power (B+):** Connect to the positive terminal of the vehicle's battery using a fused power cable. The fuse should be located within 18 inches (45 cm) of the battery.
- **Ground (GND):** Connect to a clean, unpainted metal surface of the vehicle's chassis. Ensure a solid, low-resistance connection.

- **Remote (REM):** Connect to the remote turn-on lead from your head unit. This wire turns the amplifier on and off with your stereo.
- **RCA Inputs:** Connect the RCA cables from your head unit's pre-amp outputs to the amplifier's RCA inputs.
- **Speaker Outputs:** Connect your subwoofer(s) to the amplifier's speaker terminals, observing correct polarity (+ to + and - to -). Ensure the total impedance of the connected speakers is within the amplifier's specified range.

4. Operating the Amplifier

Once properly installed, the amplifier will power on when your head unit is turned on. Adjust the settings for optimal sound quality.

4.1 Gain Control

The gain control (often labeled 'Level' or 'Input Sensitivity') matches the amplifier's input sensitivity to the output voltage of your head unit. Start with the gain control at its minimum setting and slowly increase it until you hear distortion, then back off slightly. This is not a volume control.

4.2 Low Pass Filter (LPF)

As a monoblock amplifier, the XP1.1600D is designed for subwoofers and typically includes a Low Pass Filter. This filter allows only frequencies below a certain point to pass through to the subwoofer. Adjust the LPF frequency to blend smoothly with your other speakers.

4.3 Bass Boost

The bass boost control allows you to enhance low frequencies. Use this feature sparingly, as excessive bass boost can lead to distortion and potential damage to your speakers or amplifier.

5. Maintenance

Regular maintenance helps ensure the longevity and performance of your amplifier.

- **Cleaning:** Periodically wipe the amplifier's exterior with a soft, dry cloth to remove dust and dirt. Do not use harsh chemicals or abrasive cleaners.
- **Check Connections:** Annually, inspect all power, ground, remote, and speaker connections to ensure they are secure and free from corrosion. Loose connections can cause performance issues or damage.
- **Ventilation:** Ensure that the area around the amplifier remains clear of obstructions to maintain proper airflow.

6. Troubleshooting

If you experience issues with your amplifier, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Amplifier does not turn on	No power, blown fuse, loose ground, no remote signal	Check power cable, fuse, ground connection, and remote wire from head unit.
No sound output	RCA cables disconnected, speaker wires disconnected, gain too low, amplifier in protect mode	Verify RCA and speaker connections. Adjust gain. Check for protect light (usually red) and resolve underlying issue (e.g., overheating, short circuit).

Problem	Possible Cause	Solution
Distorted sound	Gain set too high, incorrect LPF setting, poor ground connection, speaker impedance mismatch	Lower gain. Adjust LPF. Check ground. Verify speaker impedance.
Amplifier overheats	Insufficient ventilation, impedance too low, gain too high	Ensure proper airflow. Check speaker impedance. Reduce gain.

If these steps do not resolve the issue, please contact Soundstream customer support.

7. Specifications

Feature	Specification
Model Number	XP1.1600D
Brand	Soundstream
Channels	1 (Monoblock)
Output Power	1600 Watts
Mounting Type	Independent Mounting
ASIN	B07CBZ4V2D
Manufacturer	Soundstream
First Available Date	August 28, 2019

8. Warranty and Support

For warranty information and technical support, please refer to the documentation included with your purchase or visit the official Soundstream website. Keep your proof of purchase for warranty claims.

For general inquiries or assistance, you may contact Soundstream customer service through their official channels.

© 2024 Soundstream. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07CBZ4V2D

More documents and user manuals: **https://manuals.plus/**