

[manuals.plus](#) /› [LG](#) /› [LG PK7 XBOOM Go Water-Resistant Wireless Bluetooth Party Speaker Instruction Manual](#)

LG PK7

LG PK7 XBOOM Go Water-Resistant Wireless Bluetooth Party Speaker Instruction Manual

Model: PK7

PRODUCT OVERVIEW

The LG PK7 XBOOM Go is a powerful, portable Bluetooth speaker designed for an exceptional audio experience. Featuring Meridian Audio Technology, it delivers rich bass and clear vocals. Its water-resistant design and long-lasting battery make it ideal for various environments, from outdoor parties to poolside events. Key features include easy Bluetooth pairing, up to 22 hours of playback, enhanced bass with LED beat lighting, and an IPX5 water and weather-resistant rating.



Image: Front view of the LG PK7 XBOOM Go speaker, showcasing its sleek black design and illuminated speaker cones.

SETUP

1. Charging the Speaker

Before initial use, fully charge the LG PK7 speaker using the provided AC adapter. The charging port is located on the back of the device, protected by a cover.

2. Bluetooth Pairing

1. Power on the speaker by pressing the power button.
2. Press and hold the Bluetooth button on the speaker until the indicator light flashes, indicating pairing mode.
3. On your smartphone or audio device, enable Bluetooth and select "LG PK7" from the list of available devices.
4. Once connected, the Bluetooth indicator light will become solid.

3. App Installation and Firmware Update

For full control over sound effects and lighting, download the LG Music Flow Bluetooth app from your device's

app store (currently available for Android, iOS app expected). After installing and connecting via Bluetooth:

1. Open the app and connect to your LG PK7 speaker.
2. Navigate to the settings menu within the app.
3. Locate "Device version info" and check for available firmware updates. It is recommended to perform a firmware update to unlock all features, such as "Sound Boost".
4. Follow the on-screen instructions to complete the update. The speaker will power off and on during this process.

Your browser does not support the video tag.

Video: A user demonstrates the LG Music Flow Bluetooth app, showing how to connect the speaker, access sound and lighting effects, and perform a firmware update.

OPERATING INSTRUCTIONS

1. Basic Controls

The top panel of the speaker features intuitive buttons for power, Bluetooth pairing, volume control (+/-), play/pause/skip track, voice assistant activation, clear vocal, and enhanced bass.



Image: Close-up of the LG PK7 speaker's top panel, showing the power, Bluetooth, volume, playback, voice assistant, Clear Vocal, and Enhanced Bass buttons.

2. Sound Effects

- **Clear Vocal:** Enhances vocal clarity in music. Activate via the dedicated button on the speaker or within the app.
- **Enhanced Bass:** Boosts low-frequency sounds for a deeper bass experience. Activate via the dedicated button on the speaker or within the app.
- **Sound Boost:** (Requires firmware update) Increases the maximum volume output of the speaker. Activate via the LG Music Flow Bluetooth app.

3. Lighting Effects

The LG PK7 features interactive, multi-colored LED lights that can dance to the beat of the music. Control lighting effects via the LG Music Flow Bluetooth app:

- Choose from preset lighting modes like "Party" (cycles through all colors), "Water" (blue tones), or "Forest" (yellow tones).
- "My Style" mode allows customization of colors and speed.
- Enable "Beat Lighting" to synchronize lights with the music.
- Lights can also be turned off completely.

4. Dual Play Connection

Connect two LG PK7 speakers wirelessly for a stereo sound experience. This feature is managed through the LG Music Flow Bluetooth app under the "Dual Play" option.

5. Voice Control

When your smartphone is connected, press the voice assistant button on the speaker to activate your device's voice control for music playback (e.g., "Next track").

MAINTENANCE

1. Water Resistance

The LG PK7 has an IPX5 water-resistant rating, meaning it can withstand splashes and light rain. It is certified for outdoor use and can get wet, but it should **not** be submerged in water.

Your browser does not support the video tag.

Video: The LG PK7 speaker is shown being splashed with water, demonstrating its IPX5 water resistance.

2. Cleaning

To clean the speaker, use a soft, damp cloth. Avoid using harsh chemicals or abrasive materials that could damage the finish. Ensure all port covers are securely closed before cleaning or exposing to water.

TROUBLESHOOTING

- **No Power:** Ensure the speaker is fully charged. Connect to the AC adapter and try powering on again.
- **Bluetooth Disconnection:** Ensure the speaker and your device are within Bluetooth range (approx. 10 feet). Re-pair the devices if necessary.
- **Sound Distortion:** Check audio source quality. Adjust sound effects (Clear Vocal, Enhanced Bass) in the app or on the speaker. Ensure firmware is updated for optimal performance.
- **Lights Not Working:** Check lighting effect settings in the LG Music Flow Bluetooth app. Ensure "Beat Lighting" is enabled if desired, or select a different mode.

SPECIFICATIONS

Feature	Detail
Brand	LG
Model Name	PK7
Speaker Type	Outdoor
Connectivity Technology	Bluetooth AUX In (3.5mm) AC Adapter (charging)
Wireless Communication Technology	Bluetooth
Bluetooth Range	10 Feet
Speaker Maximum Output Power	40 Watts
Audio Output Mode	Stereo
Battery Life	Up to 22 hours playback (features off), approx. 13 hours (features on)
Water Resistance Level	IPX5 (Water Resistant)
Product Dimensions	6"D x 12.6"W x 6.6"H
Item Weight	6.3 Pounds
Control Method	App, Buttons

WARRANTY AND SUPPORT

The LG PK7 XBOOM Go speaker comes with a limited warranty. For detailed warranty information, please refer to the documentation included with your product or visit the official LG website.

For technical support, troubleshooting assistance, or service inquiries, please contact LG Customer Service. Contact details can be found on the LG website or in your product's user manual.