

Marshall 4092186

Marshall Major III Bluetooth Wireless On-Ear Headphones User Manual

Model: 4092186

INTRODUCTION

The Marshall Major III Bluetooth headphones combine iconic Marshall design with modern wireless technology, offering a premium audio experience. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your headphones to ensure optimal performance and longevity.





Image: Front view of the Marshall Major III Bluetooth Wireless On-Ear Headphones in black, showcasing the iconic Marshall logo on the earcups and the textured headband.

SETUP

1. Unboxing and Included Components

Carefully remove all items from the packaging. Ensure the following components are present:

- Marshall Major III Bluetooth Headphones
- 3.5mm audio cable
- Micro USB charging cable
- User manual (this document)






Image: The Marshall Major III Bluetooth headphones unfolded, alongside the coiled 3.5mm audio cable and the micro USB charging cable, as they appear when unboxed.

2. Charging the Headphones

Before first use, fully charge your headphones. A full charge provides over 30 hours of wireless playtime.

1. Connect the micro USB charging cable to the charging port on the headphone earcup.
2. Connect the other end of the USB cable to a USB power adapter (not included) or a computer's USB port.
3. The LED indicator will show charging status. A full charge typically takes approximately 3 hours.

Note: The LED indicator will turn green when fully charged.

3. Bluetooth Pairing

To connect your Major III Bluetooth headphones to a device:

1. Ensure the headphones are charged and powered off.
2. Press and hold the control knob for 5 seconds until the LED indicator flashes blue. This indicates pairing mode.
3. On your device (smartphone, tablet, computer), enable Bluetooth and search for available devices.
4. Select "Major III Bluetooth" from the list of devices.
5. Once connected, the LED indicator will turn solid blue.

The headphones will automatically attempt to reconnect to the last paired device when powered on.

OPERATING INSTRUCTIONS

Multi-directional Control Knob

The single multi-directional control knob on the left earcup allows for comprehensive control of your headphones and connected device.

Action	Function
Press and hold (2 seconds)	Power On/Off
Press (short)	Play/Pause audio, Answer/End call
Press (double)	Reject call
Push Up/Down	Volume Up/Down
Push Right/Left	Next Track/Previous Track

Wired Connection

The Major III Bluetooth headphones can also be used with the included 3.5mm audio cable when Bluetooth is not available or when the battery is depleted.

- Connect one end of the 3.5mm audio cable to the input jack on the headphone earcup.
- Connect the other end to the 3.5mm audio output of your device.

Note: When using the wired connection, the control knob functionality for audio playback and calls may be limited or unavailable, depending on your device.




Image: A person wearing the Marshall Major III Bluetooth headphones, demonstrating their on-ear fit and stylish appearance.

Maintenance

Cleaning

- Wipe the headphones with a soft, dry cloth.
- Do not use harsh chemicals, cleaning solvents, or strong detergents.
- Avoid getting moisture into any openings.

Storage

When not in use, store the headphones in a cool, dry place, away from direct sunlight and extreme temperatures. The collapsible design allows for compact storage.






Image: The Marshall Major III Bluetooth headphones in their folded position, illustrating their compact design for easy portability and storage.

TROUBLESHOOTING

If you experience issues with your Marshall Major III Bluetooth headphones, refer to the following common solutions:

Problem	Possible Solution
Headphones do not power on	Ensure the headphones are fully charged. Connect to a power source using the micro USB cable.
Cannot pair via Bluetooth	Ensure headphones are in pairing mode (flashing blue LED). Make sure Bluetooth is enabled on your device. Move headphones closer to the device. Forget "Major III Bluetooth" from your device's Bluetooth settings and try pairing again. Restart both the headphones and your device.
No sound or low volume	Increase volume on both the headphones (using the control knob) and your connected device. Ensure the headphones are properly connected via Bluetooth or the 3.5mm cable. Check if the audio source is playing.
Sound distortion or intermittent connection	Move closer to your device to reduce interference. Avoid obstacles between the headphones and your device. Disconnect and reconnect the Bluetooth connection.

SPECIFICATIONS

Feature	Detail
Model Name	4092186
Connectivity Technology	Bluetooth
Wireless Communication Technology	Bluetooth 5.0
Audio Driver Type	Dynamic Driver
Audio Driver Size	40 Millimeters
Frequency Range	20Hz - 20kHz
Battery Life	30+ Hours (Wireless Playtime)

Feature	Detail
Charging Time	3 Hours (Full Recharge)
Bluetooth Range	Up to 32.8 Feet (10 meters)
Headphones Jack	3.5 mm Jack
Control Type	Multi-directional control knob
Ear Placement	On Ear
Material	Plastic, Metal
Item Weight	6.3 Ounces (178.6 grams)
Product Dimensions	6.3 x 6.3 x 3.4 inches

WARRANTY AND SUPPORT

Marshall Major III Bluetooth headphones come with a standard manufacturer's warranty. For specific warranty terms and conditions, please refer to the documentation included with your purchase or visit the official Marshall website.

For technical support, troubleshooting assistance beyond this manual, or warranty claims, please contact Marshall customer support through their official channels. Keep your proof of purchase for warranty validation.

© 2024 Marshall. All rights reserved.
Marshall and the Marshall logo are registered trademarks

Documents - Marshall – 4092186

[pdf]

ukr pivak «Музичні знижки до 44%» Eldorado ua Портативна акустика JBL Charge 4 Black

JBLCHARGE4BLK 4999 3999 20% 71263739 Blue JBLCHARGE4BLU 14441 1601364597 i eldorado

promotion images |||

-1 -44 1. 1.1. -44 , . 03150, . , 45 -1 . . - , . . . 65 JBL Clip 3 Black JBLCLIP3BLK 1899

1299 32 71257892 Marshall Major III Bluetooth Black 4092186 4599 3199 30

71257189 Sony SBS-XB31B Black 3999 2799 30 71257894 Marshall Major

lang:tl score:15 filesize: 538.11 K page_count: 4 document_date: 2020-09-29

Digitized by srujanika@gmail.com on 11/07/2017. Page count: 1. Document date: 2020-05-20



[pdf] Specifications

Marshall Major III Bluetooth Wireless On Ear Headphones Black New 4092186 Specification Sheet Zoundify

Industries B07P7LQC4P B07CMFBJM7 B07CDZD8B7 B07CMC4Y5 61 cE1RZD3L m media amazon

images

■ ■