

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Ecolab](#) /

› [Ecolab Maxx Dual Action Floor Cleaner Bright Speed - 2.5 Gallon Instruction Manual](#)

Ecolab Maxx Dual Action Floor Cleaner Bright Speed

Ecolab Maxx Dual Action Floor Cleaner Bright Speed - 2.5 Gallon Instruction Manual

[Product Overview](#) [Safety Information](#) [Setup](#) [Operating](#)
[Instructions](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty](#) [Support](#)

1. PRODUCT OVERVIEW

The Ecolab Maxx Dual Action Floor Cleaner Bright Speed is an alkaline, dual-purpose floor cleaning concentrate designed for effective removal of dirt and grime from various floor surfaces. Its ultra-low foaming technology is optimized for use with auto scrubbers, enhancing productivity. The product features a clean, fresh scent, contributing to a more pleasant environment during and after cleaning operations. This manual provides detailed instructions for safe and efficient use of the 2.5-gallon container.



Image 1.1: A 2.5-gallon container of Ecolab Maxx Dual Action Floor Cleaner Bright Speed. The container is white with a blue label, indicating product name and brand.

2. SAFETY INFORMATION

Always read and understand the Safety Data Sheet (SDS) before using this product. The SDS provides detailed information on hazards, precautions, and emergency procedures. A copy of the SDS can typically be obtained from your supplier or the manufacturer's website.

- **Personal Protective Equipment (PPE):** Wear appropriate PPE, including safety glasses or goggles and chemical-resistant gloves, to prevent skin and eye contact.
- **Ventilation:** Use in a well-ventilated area to avoid inhalation of vapors. If ventilation is inadequate, wear respiratory protection.
- **First Aid:**
 - *Eye Contact:* Immediately flush eyes with plenty of water for at least 15 minutes, occasionally lifting the upper and lower eyelids. Seek medical attention if irritation persists.
 - *Skin Contact:* Wash thoroughly with soap and water. Remove contaminated clothing and wash before reuse. Seek medical attention if irritation develops.
 - *Inhalation:* Remove to fresh air. If not breathing, give artificial respiration. If breathing is difficult, give oxygen. Seek medical attention.
 - *Ingestion:* Do NOT induce vomiting. Drink plenty of water. Never give anything by mouth to an unconscious person. Seek immediate medical attention.
- **Storage:** Store in original container in a cool, dry, well-ventilated area away from incompatible materials and foodstuffs. Keep container tightly closed when not in use.
- **Disposal:** Dispose of contents and container in accordance with local, regional, national, and international regulations.

For further safety details, refer to the [Ecolab Safety Data Sheet \(SDS\)](#).

3. SETUP

3.1. Preparation

- Clear the area to be cleaned of any loose debris, furniture, or obstructions.
- Ensure adequate ventilation in the cleaning area.
- Gather all necessary cleaning equipment, such as mops, buckets, auto scrubbers, and appropriate PPE.

3.2. Dilution Instructions

Always dilute the product according to the recommended ratios for optimal performance and safety. Use cold water for dilution unless otherwise specified.

Application	Dilution Ratio (Product:Water)	Notes
General Floor Cleaning	1:128 (1 oz per gallon)	For daily cleaning and light soil removal.
Heavy Duty Cleaning / Stripping	1:64 (2 oz per gallon)	For heavily soiled areas or periodic deep cleaning.

To mix, add the specified amount of Ecolab Maxx Dual Action Floor Cleaner Bright Speed to the water in your cleaning equipment (bucket or auto scrubber tank). Stir gently to ensure even distribution.

4. OPERATING INSTRUCTIONS

4.1. Manual Cleaning (Mop & Bucket)

1. Prepare the diluted cleaning solution in a clean mop bucket according to the "Dilution Instructions" section.
2. Dip a clean mop into the solution, wring out excess liquid until damp.
3. Apply the solution evenly to the floor surface, working in small sections.
4. Allow the solution to dwell for 5-10 minutes for general cleaning, or up to 15 minutes for heavy duty cleaning, without letting it dry.
5. Scrub the floor surface with the mop or a deck brush to loosen dirt and grime.
6. Rinse the mop frequently in a separate bucket of clean water, or use a fresh mop for rinsing.
7. Remove the dirty solution from the floor using a clean mop or wet vacuum.
8. Allow the floor to air dry completely.

4.2. Auto Scrubber Application

1. Fill the solution tank of the auto scrubber with the diluted cleaning solution, following the "Dilution Instructions" section.
2. Ensure the appropriate pads or brushes are installed for the floor type and soil level.
3. Operate the auto scrubber over the floor surface, allowing the solution to dispense, scrub, and be recovered in a single pass.
4. For heavily soiled areas, a double pass or a longer dwell time (by dispensing solution and then scrubbing/recovering on a second pass) may be beneficial.
5. Empty and rinse the recovery tank after use. Clean and store pads/brushes.
6. Allow the floor to air dry completely.

5. MAINTENANCE

5.1. Storage

Store the Ecolab Maxx Dual Action Floor Cleaner Bright Speed in its original, tightly sealed container in a cool, dry, and well-ventilated area. Keep away from direct sunlight, extreme temperatures, and incompatible materials. Ensure the container is stored upright to prevent leaks. Keep out of reach of children and pets.

5.2. Container Care

After each use, ensure the cap is securely fastened to prevent evaporation or contamination. Do not reuse the container for other purposes. When the container is empty, rinse it thoroughly with water before disposing of it according to local regulations.

6. TROUBLESHOOTING

Refer to the table below for common issues and their potential solutions.

Problem	Possible Cause	Solution
Floor appears streaky after drying.	<ul style="list-style-type: none">• Too much product used (over-dilution).• Insufficient rinsing.• Dirty mop or recovery tank.	<ul style="list-style-type: none">• Ensure correct dilution ratio.• Rinse thoroughly with clean water.• Use clean equipment.

Problem	Possible Cause	Solution
Floor is not clean enough.	<ul style="list-style-type: none"> Insufficient product concentration (under-dilution). Not enough dwell time. Heavy soil requiring stronger solution. 	<ul style="list-style-type: none"> Verify correct dilution ratio for soil level. Allow adequate dwell time. Consider using heavy-duty dilution for stubborn areas.
Excessive foaming in auto scrubber.	<ul style="list-style-type: none"> Product not designed for low-foaming. Incorrect dilution. 	<ul style="list-style-type: none"> This product is ultra-low foaming; if foaming occurs, check dilution. Ensure no other foaming agents are present.

7. SPECIFICATIONS

- Product Name:** Ecolab Maxx Dual Action Floor Cleaner Bright Speed
- Brand:** Ecolab
- Item Form:** Liquid
- Scent:** Fresh
- Specific Uses For Product:** Floor Cleaning
- Material Feature:** Non-Toxic (when used as directed)
- Container Size:** 2.5 Gallons
- Product Type:** Dual Purpose Alkaline Floor Cleaner
- Technology:** Ultra-low foaming

8. WARRANTY INFORMATION

Ecolab products are manufactured to high-quality standards. For specific warranty details regarding the Ecolab Maxx Dual Action Floor Cleaner Bright Speed, please refer to the terms and conditions provided at the point of purchase or contact Ecolab customer support directly. General product warranties typically cover manufacturing defects under normal use conditions.

9. CUSTOMER SUPPORT

If you have any questions, require technical assistance, or need further information regarding the Ecolab Maxx Dual Action Floor Cleaner Bright Speed, please contact Ecolab customer support. You can find contact details on the official Ecolab website or on the product label.

Ecolab Official Website: www.ecolab.com