

## EliteShade WUMB\_J

# EliteShade USA 9Ft 3 Tiers Market Umbrella Instruction Manual

MODEL: WUMB\_J

Brand: EliteShade

## Product Overview

---

The EliteShade USA 9Ft 3 Tiers Market Umbrella is designed to provide superior shade and comfort for your outdoor living space. Featuring a unique three-tier design for enhanced ventilation and stability, this umbrella utilizes 100% solution-dyed acrylic fabric, ensuring exceptional fade resistance and durability against water and oil. Its robust alloy steel frame and convenient crank open system make it a reliable and user-friendly addition to any patio or outdoor area.



Image: The EliteShade 9ft 3-Tier Market Umbrella in Heather Beige, showcasing its multi-tiered canopy and sturdy central pole.

## Setup Instructions

Follow these steps to properly set up your EliteShade patio umbrella:

1. **Unpack Components:** Carefully remove all parts from the packaging. Verify that all components are present: umbrella canopy with frame, and the two-piece alloy steel pole.
2. **Assemble the Pole:** Connect the two sections of the alloy steel pole. Ensure they are securely fastened.
3. **Insert Pole into Base:** Place the assembled pole into a suitable umbrella base (*base not included*). For optimal stability, it is highly recommended to use a base that can be filled with sand or water. Ensure the base is adequately weighted to prevent the umbrella from tipping, especially in windy conditions.
4. **Attach Canopy to Pole:** Carefully lift the umbrella canopy and slide it onto the top of the pole. Ensure the canopy is centered and aligned.
5. **Secure the Umbrella:** Tighten any securing screws or knobs on the umbrella base to firmly hold the pole in place.



Image: An illustrative diagram detailing the components of the umbrella, including the 100% solution-dyed acrylic fabric, sturdy frame, easy-to-tilt mechanism, and crank open system.

## Operating Instructions

---

Operating your EliteShade umbrella is simple and efficient:

1. **Opening the Umbrella:** Locate the crank handle on the pole. Turn the crank handle clockwise to smoothly open the umbrella canopy. Continue cranking until the canopy is fully extended and taut.
2. **Securing the Open Position:** Once fully open, insert the provided pin into the designated hole near the top of the lower pole section to secure the umbrella in the open position. This prevents accidental closing and reduces strain on the crank mechanism.
3. **Tilting the Umbrella:** To adjust the angle of the umbrella for optimal shade, locate the push button on the pole, typically above the crank handle. Press and hold this button while gently tilting the canopy to your desired angle. Release the button to lock the tilt in place. This feature allows you to track the sun's movement throughout the day.
4. **Closing the Umbrella:** Remove the securing pin. Turn the crank handle counter-clockwise to retract the canopy.

Continue cranking until the umbrella is fully closed. For long-term storage or during high winds, it is recommended to secure the closed canopy with a tie strap (if available) to keep it compact and prevent damage.



Image: A detailed view of the umbrella's crank open system and the push-button tilt mechanism, highlighting their ease of use.

## Maintenance

Proper maintenance will extend the life and appearance of your umbrella:

- **Cleaning the Fabric:** The 100% solution-dyed acrylic fabric is water and oil resistant. For general cleaning, brush off loose dirt. Spot clean with a mild soap and lukewarm water solution. Rinse thoroughly and allow to air dry completely before closing or storing. Avoid harsh chemicals or abrasive cleaners.
- **Frame Care:** The alloy steel frame is rust-free powder coated. Wipe down the frame periodically with a damp cloth to remove dust and debris. Inspect all joints and moving parts for any signs of wear or looseness and tighten as necessary.
- **Weather Protection:** Always close the umbrella during strong winds, heavy rain, or other severe weather conditions to prevent damage. While the three-tier design offers enhanced wind stability, extreme weather can still cause harm.

- **Winter Storage:** During off-season or prolonged periods of non-use, clean the umbrella thoroughly, ensure it is completely dry, and store it in a cool, dry place, preferably in a protective cover.



Image: The umbrella in its closed position, secured with a tie strap, demonstrating compact storage.

## Troubleshooting

Problem	Possible Cause	Solution
Umbrella not opening/closing smoothly.	Crank mechanism obstruction or dirt.	Inspect the crank mechanism for any debris. Clean and apply a silicone-based lubricant if necessary. Ensure the securing pin is removed before attempting to close.

Problem	Possible Cause	Solution
Umbrella is unstable or tips over.	Insufficiently weighted base or loose pole.	Ensure the umbrella base is filled with sand or water to its maximum capacity. Tighten all securing screws on the base and pole connection points. Do not use in high winds.
Canopy appears faded or stained.	Accumulated dirt or prolonged exposure to harsh elements without cleaning.	Clean the fabric as per maintenance instructions. While the fabric is 10-year non-fading, regular cleaning helps maintain its appearance.

## Specifications

Feature	Detail
Product Dimensions	108 x 108 x 105.6 inches
Item Weight	17 pounds
Manufacturer	EliteShade
Item Model Number	WUMB_J
Brand	EliteShade
Color	Heather Beige
Specific Uses For Product	Sun protection
Recommended Uses For Product	Patio
Special Feature	Fade Resistant
Shape	Round
Shaft Material	Steel
Handle Material	Aluminum
Frame Material	Alloy Steel




Image: A technical diagram illustrating the key dimensions of the 9ft umbrella, including height and canopy diameter.

## Warranty and Support

---

For specific warranty details and customer support, please refer to the documentation included with your purchase or contact EliteShade directly through their official website or customer service channels. Keep your proof of purchase for any warranty claims.