

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Chicco](#) /

› [Chicco Polly Progress 5-in-1 High Chair Instruction Manual](#)

Chicco 08079408020070

Chicco Polly Progress 5-in-1 High Chair Instruction Manual

Model: Polly Progress 5-in-1 | Brand: Chicco

INTRODUCTION

The Chicco Polly Progress 5-in-1 High Chair is a versatile seating solution designed to adapt to your child's growth from newborn to youth. It offers five distinct configurations: Newborn Recliner, Infant High Chair, Toddler Booster, Big Kid Booster, and Youth Stool. This multi-functional design allows for continuous use as your child develops, and can even accommodate two children simultaneously in booster and stool modes.

SAFETY INFORMATION

Always prioritize your child's safety. Read all instructions before assembly and use. Keep this manual for future reference.

- Never leave your child unattended in the high chair.
- Always secure your child with the five-point harness.
- Ensure the high chair is fully assembled and all locking mechanisms are engaged before placing your child in it.
- Do not use the high chair if any parts are broken, torn, or missing.
- Keep children away from moving parts during adjustment.
- Do not place the high chair near open flames, heaters, or other heat sources.
- Maximum weight recommendation: 60 Pounds.

PRODUCT FEATURES

The Chicco Polly Progress 5-in-1 High Chair is engineered with features to enhance comfort, convenience, and adaptability:

- **5-in-1 Configurations:** Seamlessly transitions from Newborn Recliner, Infant High Chair, Toddler Booster, Big Kid Booster, to Youth Stool.
- **Adjustable Recline:** Features four recline positions for optimal comfort, including a fully reclined position suitable for newborns.
- **Height Adjustment:** Offers eight height positions to easily align with various table heights or for standalone use.
- **Five-Point Harness:** Provides secure restraint for your child.
- **Removable Tray:** A large, removable tray with a removable liner for easy cleaning. It can be stored on the rear legs when not in use.

- **Portability:** Equipped with non-marking front wheels and rear locking swivels for easy movement.
- **Compact Fold:** Folds to a space-saving 11.5-inch depth for convenient storage.
- **Durable Materials:** Constructed from steel, plastic, and polyester with a faux leather seat pad.

SETUP AND ASSEMBLY

The Chicco Polly Progress 5-in-1 High Chair is designed for straightforward assembly. While specific step-by-step instructions are typically provided in the included physical manual, the general process involves attaching the seat unit to the frame and securing the tray. Ensure all components click into place securely.



Image: The Chicco Polly Progress 5-in-1 High Chair fully assembled in its upright high chair configuration, with the tray attached and a separate booster seat component visible on the floor.

OPERATING INSTRUCTIONS

Adjusting Recline Positions

The high chair offers four recline positions. Locate the recline adjustment mechanism, typically on the sides of the seat, and press the buttons to adjust the seat back to your desired angle. The fully reclined position is ideal for newborns.

Adjusting Height Positions

There are eight height positions available. To adjust the height, locate the height adjustment buttons on the legs of the high chair. Press and hold these buttons while simultaneously raising or lowering the seat to the desired height. Release the buttons to lock the position.



Image: A close-up rear view of the high chair's leg, clearly showing the numbered height adjustment indicators (1 through 8) for precise positioning.

Converting Configurations

The Polly Progress 5-in-1 is designed for easy conversion between its various modes:

- **Newborn Recliner:** Utilize the fully reclined seat position for comfortable bottle feedings for infants.
- **Infant High Chair:** Use the full high chair setup with the tray for feeding and playtime.
- **Toddler Booster:** Detach the high chair seat from its frame to create a high-back booster. This booster secures to a

dining chair, allowing your toddler to eat at the table with or without the tray.

- **Big Kid Booster:** For older toddlers, a unique zip-off extension panel and fold-away armrests convert the high-back booster into a more streamlined, portable seat.
- **Youth Stool:** The high chair frame can be used independently as a height-adjustable stool. A snap-on seat and fold-away footrest are included for this configuration.



Image: The high chair's seat unit detached from its frame and securely fastened as a booster seat onto a standard dining chair, demonstrating its versatility.



Image: The high chair's main frame transformed into a height-adjustable youth stool, positioned next to a dining table, showcasing its long-term usability.

Tray Usage and Storage

The tray easily snaps onto the armrests for mealtime. It includes a removable liner for convenience. When not in use, the tray can be slid onto the rear legs of the high chair for compact storage.

Folding for Storage

To fold the high chair for compact storage, follow the instructions in your detailed manual. The design allows for a space-saving 11.5-inch fold.



Image: The Chicco Polly Progress high chair in its fully folded, compact state, illustrating its space-saving design for convenient storage.



Image: A side profile of the high chair in its folded position, highlighting its slim design for easy storage against a wall or in a closet.

MAINTENANCE AND CLEANING

Regular cleaning will ensure the longevity and hygiene of your high chair.

- **Seat Pad:** The seat pad is wipeable. For deeper cleaning, the material is Faux Leather and should be spot cleaned only.
- **Tray and Liner:** The removable tray and its liner are designed for easy cleaning. Wipe down after each use.
- **Frame:** Wipe the frame with a damp cloth and mild soap as needed.
- **Harness:** Clean the five-point harness straps with a damp cloth and mild soap. Allow to air dry completely.

Periodically check all parts for wear and tear, and ensure all fasteners are tight.

TROUBLESHOOTING

If you encounter any issues with your Chicco Polly Progress 5-in-1 High Chair, please refer to the following common

solutions:

- **Difficulty Adjusting Height/Recline:** Ensure that the adjustment buttons are fully depressed and that there is no obstruction preventing movement.
- **Tray Not Attaching Securely:** Verify that the tray is correctly aligned with the armrests and pushed in until it clicks into place. Check for any food debris or obstructions in the attachment points.
- **High Chair Not Folding:** Ensure the seat is in the correct position for folding (usually upright) and that all locking mechanisms are disengaged as per the detailed manual.
- **Wheels Not Rolling Smoothly:** Check for debris caught in the wheels. Clean the wheels and ensure the rear locking swivels are disengaged if you intend to roll the chair.

For persistent issues or concerns not addressed here, please contact Chicco customer support.

SPECIFICATIONS

Feature	Detail
Product Dimensions	32 x 23.5 x 41 inches (unfolded)
Item Weight	25.5 pounds
Item Model Number	08079408020070
Maximum Weight Recommendation	60 Pounds
Material Composition	33.90% Steel, 59.20% Plastic, 6.90% Polyester
Care Instructions	Spot clean only
Additional Features	Converts to Booster Seat, Converts to Youth Seat, Reclining Seat, Safety Harness, Wheels
Style	Polly Progress 5-in-1
Color	Minerale

WARRANTY AND SUPPORT

For detailed warranty information and customer support, please refer to the official Chicco website or the user manual provided with your product. A digital version of the user manual can often be found on the product's Amazon listing or the manufacturer's support page.

You can also visit the [Chicco Store on Amazon](#) for more products and information.

For a comprehensive user guide, please refer to the official PDF manual:[Chicco Polly Progress 5-in-1 High Chair User Manual \(PDF\)](#).

 <p>Stack 1-2-3 3-Stage Multichair Owner's Manual</p>	<p><u>Chicco Stack 1-2-3 3-Stage Multichair Owner's Manual</u></p> <p>Comprehensive owner's manual for the Chicco Stack 1-2-3 3-Stage Multichair, detailing assembly, usage in High Chair, Booster, Low-Back Booster, and Youth Stool modes, safety instructions, harness adjustment, tray use, and cleaning/maintenance.</p>
 <p>Polly Easy</p>	<p><u>Chicco Polly Easy High Chair: User Manual & Safety Guide</u></p> <p>Comprehensive user manual for the Chicco Polly Easy high chair. Includes detailed instructions for assembly, safe usage, maintenance, and cleaning. Available in multiple languages.</p>
 <p>Meraviglia</p>	<p><u>Chicco Meraviglia: Manuale d'Uso e Guida Completa</u></p> <p>Scopri il seggiolone multifunzione Chicco Meraviglia. Istruzioni dettagliate per l'uso, la sicurezza e le diverse configurazioni: da sdraieta a sedia per adulti. Perfetto per ogni fase della crescita.</p>
 <p>Polly Magic Relax</p>	<p><u>Chicco Polly Magic Relax High Chair User Manual</u></p> <p>Comprehensive instructions for the Chicco Polly Magic Relax high chair, covering assembly, usage, safety, cleaning, and maintenance for both the high chair and recliner modes.</p>
 <p>BABY HUG AIR</p>	<p><u>Chicco Baby Hug 4 in 1 Air User Manual</u></p> <p>Comprehensive instructions and safety guidelines for the Chicco Baby Hug 4 in 1 Air, covering its use as a bassinet, recliner, high chair, and table chair.</p>
 <p>Hoopla</p>	<p><u>Chicco Hoopla Baby Bouncer: User Manual & Safety Guide</u></p> <p>Comprehensive user manual for the Chicco Hoopla baby bouncer. Learn about safe assembly, usage modes (reclined cradle and chair), adjustable features, and maintenance for this versatile baby product.</p>

