UGREEN 50748

UGREEN Tablet Stand Holder

User Manual

1. Introduction

This manual provides comprehensive instructions for the UGREEN Tablet Stand Holder, Model 50748. Designed for versatility and convenience, this adjustable and portable desktop stand is engineered to securely hold your tablets, smartphones, and e-readers, enhancing your viewing experience in various settings. Please read this manual thoroughly to ensure proper setup and operation.



Figure 1: UGREEN Tablet Stand Holder (Black)

2. Product Features

- **Wide Compatibility:** This stand accommodates devices from 4 to 11 inches, including various iPad models (Pro, Air, Mini), iPhones (17, 16, 15, 14, 13, 12, 11, XR, X, XS, 8 Plus, 6, 7, 6S), Samsung Galaxy phones (Note20, S20 Ultra, S10, S9, S8, Note 10, 9, 8), and other Android devices, with a maximum thickness of 0.55 inches (including case).



Figure 2: Wide device compatibility

- **Easy to Carry:** With compact dimensions of 4.7" x 4.2" when folded, the stand is designed for portability, easily fitting into a pocket or bag for travel.



Figure 3: Foldable and portable design

- **Multi-Angle Adjustable:** The stand offers multiple viewing angles, adjustable from 15° to 100°, allowing users to find an optimal position for activities such as watching videos, reading, recording, browsing, or video calls.



Figure 4: Multi-angle adjustment capability

- **Sturdy and Stable:** Constructed from premium ABS material, the stand ensures durability. Silicone pads on the bottom and device cradle prevent sliding and protect your device from scratches. It features a stable triangular structure and an aluminum alloy hinge for secure positioning.



Figure 5: Detail of sturdy design elements

3. Setup Instructions

1. **Unpack:** Carefully remove the UGREEN Tablet Stand Holder from its packaging.
2. **Unfold:** Gently unfold the stand to its open position. The hinge allows for smooth movement.
3. **Position:** Place the stand on a flat, stable surface. Ensure the silicone pads on the bottom are making full contact

with the surface to prevent slipping.



Figure 6: Stand ready for desktop use

4. Operating Instructions

1. **Place Your Device:** Carefully place your tablet, smartphone, or e-reader into the cradle of the stand. Ensure it rests securely against the silicone-lined lip.

2. **Adjust Viewing Angle:** Hold the base of the stand firmly and gently push or pull the back support to adjust the viewing angle. The stand can be set between 15° and 100° to suit your preference.
3. **Optimal Use:** The stand is ideal for hands-free viewing, video calls, reading, and gaming. For charging, ensure the charging port of your device is accessible when placed on the stand.




Figure 7: Hands-free device usage

5. Compatibility

The UGREEN Tablet Stand Holder is designed for broad compatibility with devices ranging from 4 to 11 inches in screen size, with a maximum thickness of 0.55 inches (including protective cases). This includes, but is not limited to:

- **Tablets:** Apple iPad (9.7 inch, 10.2 inch 2019), iPad Pro (11-inch 2020), iPad mini (2, 3, 4, 5 Wi-Fi), iPad Air 2, Lenovo Tab M8 (4th Gen).
- **Smartphones:** iPhone (17, 16, 15, 14, 13, 12, 11 Pro Max, 12 mini, SE 2020, XR, X, XS, 8 Plus, 6, 7, 6S), Samsung Galaxy (Note20, S20 Ultra, S10, S9, S8, Note 10, 9, 8), and other Android phones.
- **E-readers:** Various models of e-readers.
- **Gaming Devices:** Nintendo Switch.



Figure 8: Nintendo Switch compatibility

6. Specifications

Attribute	Detail

Attribute	Detail
Brand	UGREEN
Model Number	50748
Color	Black
Item Weight	4.2 ounces
Product Dimensions (LxWxH)	4.72 x 0.79 x 4.21 inches
Max Screen Resolution	15 inches (referring to maximum supported device size)
Form Factor	Black Tablet Stand Holder
Compatible Devices	For 4 to 11 inch Tablet, Lenovo Tab M8 (4th Gen), Cell Phone and E-reader.
Compatible Phone Models	Compatible for iPhone 17 16 15 14 13 12 11 Pro Max, XR XS, iPhone 8Plus 6 7 6S, etc.




Figure 9: Dimensional Information

7. Maintenance

To ensure the longevity and optimal performance of your UGREEN Tablet Stand Holder, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the stand with a soft, dry, or slightly damp cloth. Avoid using abrasive cleaners, solvents, or harsh chemicals, as these may damage the finish or materials.
- **Storage:** When not in use, fold the stand flat for compact storage. Store it in a cool, dry place away from direct sunlight and extreme temperatures.
- **Inspection:** Periodically check the hinge and silicone pads for any signs of wear or damage. Ensure the hinge operates smoothly and the pads remain securely attached.

8. Troubleshooting

If you encounter any issues with your UGREEN Tablet Stand Holder, consider the following:

- **Stand is unstable:** Ensure the stand is placed on a flat, level surface. Verify that the silicone pads on the bottom are clean and making full contact. Avoid placing excessively heavy devices beyond the recommended size/weight.
- **Device does not fit:** Check that your device's screen size is between 4 and 11 inches and its thickness (including case) does not exceed 0.55 inches.
- **Hinge feels stiff or loose:** The hinge is designed for a balance of stability and adjustability. If it feels unusually stiff or loose, ensure no debris is obstructing the mechanism. Avoid forcing the hinge beyond its intended range (15° to 100°).

9. What's in the Box

The package for your UGREEN Tablet Stand Holder includes:

- 1 x Multi Angle Desk Tablet Stand

10. Warranty and Support

UGREEN products are designed with quality and reliability in mind. For warranty information, technical support, or any inquiries regarding your UGREEN Tablet Stand Holder, please refer to the official UGREEN website or contact UGREEN customer service directly. Keep your purchase receipt for warranty claims.

For further assistance, you may visit the UGREEN Store on Amazon.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question