

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

> [Motorola](#) /

> [Motorola Moto G6 Plus User Manual](#)

Motorola XT1926-7

Motorola Moto G6 Plus User Manual

Model: XT1926-7

INTRODUCTION

This manual provides essential information for the safe and efficient operation of your Motorola Moto G6 Plus smartphone. The Moto G6 Plus is an international model, factory unlocked, featuring a 5.9-inch Full HD+ display, 64GB of internal storage, 4GB of RAM, and dual SIM capability. It is designed for use with GSM carriers.

SETUP

1. Unboxing and Initial Inspection

Carefully remove all components from the packaging. Ensure the following items are present:

- Motorola Moto G6 Plus Smartphone
- Adapter
- Documentation (this manual)

Inspect the device for any physical damage before proceeding.

2. Inserting SIM and microSD Cards

The Moto G6 Plus supports dual Nano-SIM cards and a microSD card for expandable storage up to 256 GB. Locate the SIM/microSD card tray on the side of the device.

1. Power off the device before inserting or removing cards.
2. Use the provided SIM ejector tool to open the tray.
3. Place the Nano-SIM card(s) and microSD card into their respective slots on the tray, ensuring correct orientation.
4. Gently push the tray back into the device until it clicks into place.



Image: Side view of the Moto G6 Plus, illustrating the slim profile and the location of the SIM/microSD card tray on the right side.

3. Charging the Battery

Your device comes with a non-removable Li-Ion 3200 mAh battery. For optimal performance, fully charge the battery before first use.

- Connect the adapter to the charging port at the bottom of the phone.
- Plug the adapter into a power outlet.
- The charging indicator will appear on the screen.

Use only Motorola-approved chargers and cables to prevent damage to the device.

OPERATING YOUR DEVICE

1. Power On/Off

- To power on: Press and hold the Power button until the Motorola logo appears.

- To power off: Press and hold the Power button, then select "Power off" from the options.

2. Screen Navigation

The Moto G6 Plus features a 5.9-inch Full HD+ IPS display with Corning Gorilla Glass for protection. Navigation is primarily touch-based.



Image: Front view of the Moto G6 Plus, showcasing its large display and the Android home screen interface.

- **Tap:** Select an item or open an application.
- **Swipe:** Move between home screens, scroll through lists, or dismiss notifications.
- **Pinch:** Zoom in or out on photos and web pages.

- **Long Press:** Access contextual menus or move icons.

3. Camera Operation

The device is equipped with a dual rear camera system (12 MP + 5 MP) and a front camera.



Image: Front and back view of the Moto G6 Plus, highlighting the circular dual camera module on the rear.

1. Open the Camera application from the home screen or app drawer.
2. Tap the screen to focus on a subject.
3. Tap the Shutter button to capture a photo.
4. Switch between photo and video modes as needed.
5. Utilize features like portrait mode (bokeh effect) and slow-motion video recording.

4. Connectivity

The Moto G6 Plus supports Wi-Fi, Bluetooth, and GPS.

- **Wi-Fi:** Access Wi-Fi settings via **Settings > Network & internet > Wi-Fi** to connect to available networks.
- **Bluetooth:** Pair with Bluetooth devices via **Settings > Connected devices > Bluetooth**.
- **Mobile Data:** Ensure mobile data is enabled for internet access via your SIM card. This device is compatible with GSM carriers like AT&T and T-Mobile, but not CDMA carriers such as Verizon and Sprint.

MAINTENANCE

1. Cleaning Your Device

To maintain the appearance and functionality of your Moto G6 Plus:

- Use a soft, lint-free cloth to wipe the screen and body.
- Avoid using harsh chemicals, cleaning sprays, or abrasive materials.
- While the device is splash resistant, avoid submerging it in water.

2. Battery Care

To prolong battery life:

- Avoid extreme temperatures.
- Do not allow the battery to fully discharge frequently.
- Unplug the charger once the battery is fully charged.

TROUBLESHOOTING

Common Issues and Solutions

Issue	Possible Solution
Device not powering on	Ensure the battery is charged. Press and hold the Power button for at least 10-15 seconds.
Apps crashing or freezing	Close background apps. Clear app cache. Restart the device.
Poor call quality	Check network signal strength. Ensure microphone and speaker are not obstructed.
Cannot connect to Wi-Fi	Restart your Wi-Fi router. Forget the network on your phone and reconnect.
Battery draining quickly	Reduce screen brightness. Disable unnecessary features like GPS or Bluetooth when not in use. Limit background app activity.

SPECIFICATIONS

Feature	Detail
Model Name	Moto G6 Plus (XT1926-7)
Display	5.9 Inches, Full HD+ (1080 x 2160 pixels) IPS, Corning Gorilla Glass
Processor	Octa-core 2.2 GHz
RAM	4 GB
Internal Storage	64 GB
Expandable Storage	microSD, up to 256 GB
Rear Camera	Dual: 12 MP (f/1.7) + 5 MP
Front Camera	(Information not explicitly provided for front MP, but implied by "Other camera features: Rear, Front")
Battery	Non-removable Li-Ion 3200 mAh
Operating System	Android
SIM Type	Dual Nano-SIM, dual stand-by
Connectivity	Wi-Fi, Bluetooth, GPS, Cellular (GSM, 3G HSDPA, 4G LTE)
Dimensions	9.84 x 6.69 x 5.91 inches (Product Dimensions)

Feature	Detail
Weight	8 ounces (0.5 Pounds)
Splash Resistant	Yes (p2i coating)

WARRANTY AND SUPPORT

As an international model, the Motorola Moto G6 Plus (XT1926-7) typically does not carry a US warranty. For warranty information specific to your region of purchase, please refer to the documentation provided with your device or contact your local Motorola support.

For further assistance, visit the official Motorola support website or contact their customer service. You can find more information and support resources by visiting the [Motorola Store on Amazon](#).