

## GP GP ReCyko

# GP ReCyko+ AAA Rechargeable Batteries User Manual

Model: GP ReCyko

<a href="#">Introduction</a>	<a href="#">Setup</a>	<a href="#">Operating Instructions</a>	<a href="#">Maintenance</a>	<a href="#">Troubleshooting</a>	<a href="#">Specifications</a>
		<a href="#">Warranty</a>	<a href="#">Support</a>		

## 1. INTRODUCTION

This manual provides essential information for the safe and effective use of your GP ReCyko+ AAA Rechargeable Batteries. These batteries are designed for repeated use, offering a reliable power source for a wide range of electronic devices.



Figure 1: GP ReCyko+ AAA Rechargeable Batteries (12-pack)

This image displays a set of twelve GP ReCyko+ AAA rechargeable batteries. Each battery is primarily white with a green and yellow label, featuring the 'GP' logo at the bottom and 'ReCyko+' with 'RECHARGEABLE • ALWAYS READY' text vertically along the side. The batteries are shown standing upright in a single line.

## 2. SETUP

Before first use, it is recommended to fully charge your GP ReCyko+ AAA rechargeable batteries. Use a compatible NiMH battery charger. Ensure the charger is designed for AAA size batteries and can handle the battery's capacity.

### 2.1 Initial Charging

1. Insert the GP ReCyko+ AAA batteries into the appropriate slots of your NiMH battery charger, observing the correct polarity (+ and - terminals).

2. Connect the charger to a power source according to the charger's instructions.
3. Allow the batteries to charge until the charger indicates a full charge. Charging times vary depending on the charger model and battery discharge level.

## 3. OPERATING INSTRUCTIONS

---

### 3.1 Battery Insertion

When inserting batteries into a device, always match the positive (+) and negative (-) terminals of the battery with the corresponding markings in the device's battery compartment. Incorrect insertion can damage both the battery and the device.

### 3.2 Recharging

When the performance of your device diminishes, it indicates that the batteries require recharging. Follow the charging instructions provided with your NiMH battery charger. Avoid mixing fully charged batteries with partially discharged ones in a device, as this can lead to uneven discharge and reduced overall performance.

## 4. MAINTENANCE

---

Proper maintenance extends the lifespan of your rechargeable batteries.

- **Storage:** Store batteries in a cool, dry place away from direct sunlight and extreme temperatures. For long-term storage, it is advisable to store them at approximately 50% charge.
- **Cleaning:** If battery terminals become dirty, gently wipe them with a clean, dry cloth to ensure good electrical contact.
- **Avoid Over-Discharging:** Do not completely drain the batteries. Recharge them when device performance starts to decline.
- **Avoid Over-Charging:** Use a smart charger that automatically stops charging once batteries are full to prevent over-charging, which can reduce battery life.
- **Disposal:** Do not dispose of batteries in household waste. Recycle them at designated collection points for rechargeable batteries.

## 5. TROUBLESHOOTING

---

Problem	Possible Cause	Solution
Batteries not charging.	Incorrectly inserted in charger; faulty charger; battery too old.	Check polarity; try a different charger; replace old batteries.
Device not powering on.	Batteries not charged; incorrect battery insertion; device malfunction.	Ensure batteries are fully charged; verify correct polarity; test device with known good batteries.
Reduced operating time.	Batteries not fully charged; aging batteries; high power consumption of device.	Ensure full charge cycle; consider replacing batteries if they are old; check device's power requirements.

## 6. SPECIFICATIONS

---

**Brand:** GP

**Model Number:** GP ReCyko

**Battery Type:** Rechargeable AAA (NiMH)

**Battery Capacity:** 800 Milliampere Hour (mAh)

**Number of Batteries:** 12

**Package Dimensions:** 9 x 4.6 x 1.5 inches

**Package Weight:** 7.2 ounces

**Manufacturer:** GP

**ASIN:** B07CHXMHPH

**Date First Available:** April 17, 2018

*Note: Specifications are subject to change without notice.*

## 7. WARRANTY INFORMATION

---

Specific warranty terms for GP ReCyko+ AAA Rechargeable Batteries are provided by the manufacturer, GP. Please refer to the packaging or the official GP website for detailed warranty coverage, duration, and claim procedures. Keep your proof of purchase for warranty claims.

## 8. CUSTOMER SUPPORT

---

For technical assistance, product inquiries, or support regarding your GP ReCyko+ AAA Rechargeable Batteries, please contact GP customer service directly. Contact information can typically be found on the product packaging or on the official GP website.

You may also contact the seller from whom you purchased the product for assistance.

© 2024 GP. All rights reserved.

This manual is for informational purposes only.