

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Mr. Coffee](#) /

› [Mr. Coffee BVMC-EM6701SS Programmable Espresso & Cappuccino Machine Instruction Manual](#)

## Mr. Coffee BVMC-EM6701SS

# Mr. Coffee BVMC-EM6701SS Programmable Espresso & Cappuccino Machine

Model: BVMC-EM6701SS | Brand: Mr. Coffee

## INTRODUCTION

This manual provides essential information for the safe and efficient operation of your Mr. Coffee Programmable Espresso & Cappuccino Machine. Please read all instructions carefully before first use and retain for future reference.

Experience exceptional brewing with the Mr. Coffee Espresso and Cappuccino Machine. With a stunning stainless steel finish and smart design, you can effortlessly create luxuriously frothy cappuccinos, smooth espressos, and creamy lattes from the comfort of your home. Boosted by a 19-bar pump for barista-quality drinks, it also features a thermocouple heating system ensuring even heat distribution. The automatic milk frother adds a creamy froth for that perfect café-style beverage with just a press of a button!

## KEY FEATURES

- **Advanced Functionality:** User-friendly interface for easy operation.
- **Efficient Heating:** Thermocouple heating system evenly heats water for optimal brewing temperature.
- **Flexible Cup Tray:** Adjusts to conveniently fit both tall and short mugs.
- **Creamy Froth:** Automatic milk frother whips any milk into a light, creamy froth.
- **One-touch Operation:** Creates espressos, cappuccinos, and lattes with a single touch.
- **High-quality Brewing:** 19-bar Italian pump delivers barista-quality drinks.
- **Low Maintenance:** Descaling is required when brewing time increases or excessive steaming is noticed.

## SETUP

### 1. Unboxing and Initial Cleaning

Carefully remove all components from the packaging. Wash the water reservoir, milk reservoir, portafilter, and

filter baskets with warm, soapy water. Rinse thoroughly and dry all parts before assembly.



Image: All components of the Mr. Coffee Espresso and Cappuccino Machine laid out, including the main unit, portafilter, single and double shot filters, and milk reservoir.

## 2. Filling the Water Reservoir

Locate the water reservoir at the back of the machine. Lift the lid or remove the reservoir completely to fill it with fresh, cold water. Ensure the reservoir is securely placed back into the machine.

Video: Unboxing and Setup of the Mr. Coffee One Touch Espresso Machine, demonstrating how to fill the water reservoir and assemble components.

## 3. Attaching the Milk Reservoir

The automatic milk frother includes a detachable milk reservoir. Fill it with your desired milk (whole milk is recommended for best frothing results) up to the 'MAX FILL' line. Securely attach it to the side of the machine.



Image: Close-up of the Mr. Coffee Espresso Machine's automatic milk frother, showing the milk reservoir filled to the MAX line and the frothing dial.

#### 4. Inserting the Portafilter

Place either the single or double shot filter basket into the portafilter. Fill with espresso ground coffee and tamp firmly. Insert the portafilter into the brew head and twist to lock it into place.

### OPERATING INSTRUCTIONS

#### 1. Power On

Plug the machine into a power outlet. Flip the power switch located on the side of the machine. The indicator lights will illuminate as the machine heats up.

#### 2. Selecting Your Drink

Once the machine is ready, select your desired beverage from the control panel: Espresso (single/double), Cappuccino (single/double), or Latte (single/double). The machine will automatically brew the coffee and froth the milk according to your selection.



Image: Close-up of the Mr. Coffee Espresso Machine's control panel, showing buttons for Espresso, Cappuccino, Latte, Froth, and Clean, with options for single or double shots.

### 3. Adjusting Froth Level

Use the dial on the milk reservoir to adjust the froth level for your cappuccino or latte. Turn the dial towards 'Latte' for less froth or towards 'Froth/Cappuccino' for more froth.

### 4. Manual Frothing

To manually froth milk, press and hold the 'Froth' button on the control panel. This will activate the frother without brewing coffee.

Video: Demonstration of how the one-touch espresso machine works, including frothing milk and brewing coffee.

### 5. Cup Placement

The cup tray can be adjusted or removed to accommodate various cup sizes. For taller mugs, simply remove the drip tray.



Image: Mr. Coffee Espresso Machine brewing a latte into a tall glass mug, demonstrating the adjustable cup tray.

## MAINTENANCE

### 1. Cleaning the Milk Frother

After each use, turn the milk frother dial to the 'Clean' position to flush out any residual milk. The milk reservoir can be detached and stored in the refrigerator or washed by hand.

### 2. Cleaning the Drip Tray

The drip tray should be emptied and cleaned regularly to prevent overflow and maintain hygiene. It is easily removable for cleaning.

### 3. Descaling

Descaling is required when the time to brew increases or when excessive steaming is noticed. Refer to the full product manual for detailed descaling instructions using a descaling solution.

### 4. Cleaning Portafilter and Filter Baskets

Remove the portafilter and discard used coffee grounds. Wash the portafilter and filter baskets with warm,

soapy water after each use. Rinse thoroughly.

## TROUBLESHOOTING

- **No Coffee Dispensed:** Ensure the water reservoir is filled and correctly seated. Check if the portafilter is securely locked.
- **No Milk Froth:** Verify the milk reservoir is filled with fresh, cold milk. Ensure the frothing dial is set correctly and the frother spout is clean.
- **Leaking:** Check that all removable parts (water reservoir, milk reservoir, portafilter) are correctly installed and sealed.
- **Machine Not Turning On:** Ensure the power cord is securely plugged into a working outlet and the power switch is flipped to 'On'.

## SPECIFICATIONS

Attribute	Value
Brand	Mr. Coffee
Model Name	One-Touch CoffeeHouse
Item Model Number	BVMC-EM6701SS
Color	Stainless Steel
Product Dimensions	10.6"D x 13"W x 14.3"H
Item Weight	14.2 pounds
Voltage	110 Volts
Capacity	1000 Milliliters (Water Reservoir)
Coffee Maker Type	Espresso Machine
Operation Mode	Fully Automatic
Coffee Input Type	Grounds
Special Feature	Milk Frother, Programmable, Removable Tank
Care Instructions	Hand Wash (Not Dishwasher Safe)

## WARRANTY AND SUPPORT

For warranty information, product registration, or customer support, please refer to the official Mr. Coffee website or contact their customer service department. Keep your purchase receipt as proof of purchase for any warranty claims.

