

BXROIU ESY-3DL-5M

BXROIU ESY-3DL-5M 50LEDs Fairy Lights Instruction Manual

Model: ESY-3DL-5M

INTRODUCTION

Thank you for choosing the BXROIU 50LEDs Fairy Lights. These battery-operated string lights feature a flexible silver wire and warm white LEDs, designed to add a decorative touch to various indoor settings. This manual provides essential information for the safe and effective use of your new fairy lights.

PRODUCT OVERVIEW

Features

- **Dual String Lights:** Two sets of 16.4 feet (5 meters) silver wire fairy lights, each with 50 micro LEDs and a battery case.
- **Multiple Lighting Modes:** Easily switch between constant illumination and flashing lights to suit different moods or occasions.
- **Flexible Decorative Possibilities:** The slim silver wire is highly flexible, allowing for easy shaping and discreet placement around objects, plants, and furniture.
- **Safety and Energy Efficiency:** Designed for low power consumption and cool operation, preventing overheating even during prolonged use.
- **Indoor Elegance:** Ideal for enhancing the ambiance of courtyards, gardens, hallways, bedrooms, weddings, parties, and festive occasions.

Package Contents

- 2 x 50LEDs Fairy Light Strings with Battery Cases



Image: Two sets of BXROIU 50LEDs Fairy Lights, coiled with their battery packs.

SETUP

Battery Installation

1. Locate the battery compartment on the clear plastic case.
2. Slide open the battery compartment cover.
3. Insert three (3) AA batteries (not included) into the compartment, ensuring correct polarity (+/-).

4. Close the battery compartment cover securely.



Image: Close-up of the battery pack, illustrating battery placement.

OPERATING INSTRUCTIONS

Selecting Lighting Modes

The battery case features a switch to control the lighting modes:

- Slide the switch to the 'ON' position for **Constant Illumination**.
- Slide the switch to the 'FLASH' position for **Flashing Lights**.
- Slide the switch to the 'OFF' position to turn the lights off.



Image: Fairy lights used decoratively in a glass jar.

MAINTENANCE

Care and Storage

- Keep the battery case dry. These lights are designed for indoor use.
- When not in use for extended periods, remove the batteries to prevent leakage and corrosion.
- Handle the silver wire gently to avoid bending or breaking the delicate strands.
- Clean the lights with a soft, dry cloth if necessary. Do not use harsh chemicals or abrasive cleaners.

TROUBLESHOOTING

Common Issues and Solutions

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Lights do not turn on.	Batteries are dead or incorrectly inserted. Switch is in 'OFF' position.	Check battery polarity and replace with fresh AA batteries. Ensure the switch is set to 'ON' or 'FLASH'.
Lights are dim.	Batteries are low.	Replace all three AA batteries with new ones.
Some LEDs are not lighting up.	Damaged LED or wire.	Inspect the wire for any visible damage. If a section is damaged, the entire string may need replacement.

SPECIFICATIONS

Attribute	Detail
Brand	BXROIU
Model Number	ESY-3DL-5M
Color	Warm White
Indoor/Outdoor Usage	Indoor
Special Feature	Flashing lights
Light Source Type	LED
Power Source	Battery Powered (3 AA batteries required)
Number of Light Sources	50 per string
Item Length	5 Meters (16.4 Feet) per string
Number of Items	2 (two strings included)
Material	Plastic
Voltage	4.5 Volts (DC)
Wattage	3.5 watts
Control Method	Touch (via switch on battery case)
UPC	686560836596

WARRANTY AND CUSTOMER SUPPORT

For any questions, concerns, or support regarding your BXROIU 50LEDs Fairy Lights, please contact the manufacturer directly. Refer to the product packaging or the retailer's website for specific warranty information and contact details.

