

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [SONGMICS](#) /

› [SONGMICS GKR31WT Kids Toy Storage Organizer Instruction Manual](#)

## SONGMICS GKR31WT

# SONGMICS GKR31WT Kids Toy Storage Organizer Instruction Manual

Model: GKR31WT

## 1. INTRODUCTION

Thank you for choosing the SONGMICS GKR31WT Kids Toy Storage Organizer. This manual provides essential information for the safe assembly, operation, and maintenance of your new product. Please read these instructions carefully before assembly and retain them for future reference.

### Safety Information

- Always assemble the product on a soft, clean surface to prevent scratches.
- Ensure all parts are present and undamaged before beginning assembly.
- Do not overtighten screws during assembly to avoid damaging the wood.
- For safety, it is mandatory to secure the organizer to the wall using the provided anti-tipping device. This prevents accidental tipping and potential injury.
- Keep small parts and packaging materials away from children during assembly.

## 2. COMPONENTS LIST

Before assembly, verify that all components listed below are included in your package. If any parts are missing or damaged, please contact customer support.

- Wooden Frame Panels (Side panels, back panel, top shelf, support rods)
- 9 Removable Fabric Bins (6 standard, 3 large, multi-colored)
- Assembly Hardware (Screws, dowels, anti-tipping device)



Image: Overall dimensions of the toy organizer (82.5 x 26.5 x 78 cm) and the two sizes of removable bins.

### 3. SETUP AND ASSEMBLY


Follow these steps to assemble your toy storage organizer. A Phillips head screwdriver is required (not included).

1. **Prepare the Workspace:** Lay out all components on a soft, clean surface to prevent damage during assembly.
2. **Assemble the Side Panels:** Attach the horizontal support rods to the pre-drilled holes on the inner side of the wooden side panels. Ensure they are securely fastened.
3. **Attach the Top Shelf:** Secure the top shelf to the assembled side panels using the provided screws.
4. **Install the Back Panel:** Fasten the back panel to the rear of the frame.
5. **Insert Fabric Bins:** Place the multi-colored fabric bins onto the support rods. The 6 standard bins fit on the upper two rows, and the 3 larger bins fit on the bottom row.
6. **Install Anti-Tipping Device:** For safety, attach the anti-tipping device to the top rear of the organizer and secure it to a solid wall stud using appropriate wall anchors and screws. This step

is crucial to prevent the unit from tipping over, especially in households with children.



*Image: Detailed view of the anti-tipping device installation, showing how it secures the organizer to the wall.*



*Image: Close-up of the side panel with a cutout handle, indicating ease of handling during assembly or repositioning.*

#### 4. OPERATING INSTRUCTIONS

The SONGMICS GKR31WT organizer is designed for easy and accessible storage of children's toys and books.

- **Toy Placement:** Utilize the 9 removable fabric bins to sort and store toys, books, and other items. The multi-colored bins can aid in teaching children organization and color recognition.
- **Removable Bins:** The bins are designed to be easily removed and carried, allowing children to take their toys to play areas and return them when finished.
- **Top Shelf Usage:** The top shelf provides additional space for displaying items, storing larger books, or placing decorative objects.



*Image: A hand demonstrating the easy removal of a fabric storage bin from the organizer.*



*Image: The top shelf of the organizer, showing its capacity for books and other items.*

## 5. MAINTENANCE

Proper care will ensure the longevity of your toy storage organizer.

- **Cleaning the Frame:** Wipe the wooden frame with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, which can damage the finish.
- **Cleaning the Bins:** The non-woven fabric bins can be spot cleaned with a mild detergent and a damp cloth. Allow them to air dry completely before returning them to the organizer. Do not machine wash or tumble dry.
- **Regular Checks:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.

## 6. TROUBLESHOOTING

If you encounter any issues with your toy organizer, refer to the following common solutions:

- **Unit is Unstable:** Ensure all screws are tightened. Verify that the anti-tipping device is correctly installed and securely fastened to the wall. Uneven flooring can also cause instability; consider placing shims under the feet if needed.
- **Bins Do Not Fit Properly:** Check that the support rods are installed correctly and are not bent. Ensure the bins are inserted straight onto the rods.
- **Product Does Not Sit Flush Against Wall:** Due to the design of the bins, the organizer may not sit completely flush against the wall. This is normal and does not affect stability if the anti-tipping device is properly installed.

## 7. SPECIFICATIONS

| Feature                        | Detail   |
|--------------------------------|--|
| Brand                          | SONGMICS   |
| Model Number                   | GKR31WT  |
| Color                          | White frame, Yellow, Blue, Green bins                    |
| Overall Dimensions (L x W x H) | 82.5 x 26.5 x 78 cm (32.5 x 10.4 x 30.7 inches)          |
| Weight                         | 9.1 kg (20.1 lbs)  |
| Maximum Weight Capacity        | 45 kg (99 lbs)   |
| Material                       | Engineered Wood (MDF), Non-woven Fabric                  |
| Number of Shelves/Bins         | 9 (6 standard, 3 large)                                  |
| Special Feature                | Lightweight, Rounded Edges, Anti-tipping device included |

## 8. WARRANTY INFORMATION

SONGMICS products are manufactured to high-quality standards. For specific warranty details, please refer to the warranty card included with your purchase or visit the official SONGMICS website. Please retain your proof of purchase for any warranty claims.

## 9. CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact SONGMICS customer service. You can usually find contact information on the packaging, the official SONGMICS website, or through your retailer.

We are committed to providing you with a satisfactory experience.

© 2024 SONGMICS. All rights reserved.