ZdalaMit XRT122

ZdalaMit XRT122 Replacement Remote Control User Manual

For Vizio LED HDTV Televisions

Introduction

This manual provides essential instructions for the setup, operation, and maintenance of your ZdalaMit XRT122 replacement remote control. Designed for seamless compatibility with various Vizio LED HDTV models, this remote offers a direct replacement experience without the need for complex programming.





Front view of the ZdalaMit XRT122 Replacement Remote Control, showcasing its button layout.

Setup

Battery Installation

The ZdalaMit XRT122 remote control requires two (2) AAA alkaline batteries for operation. Batteries are not included with the remote.

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards to open it.
3. Insert two new AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals align correctly with the indicators inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.





Back view of the remote control, illustrating the battery compartment location.

Initial Use

This replacement remote control is pre-programmed and ready for immediate use with compatible Vizio LED HDTV models. No additional programming or pairing steps are required. Simply install the batteries, and the remote will function directly with your television.

Operating Instructions

The XRT122 remote features a standard layout for intuitive control of your Vizio TV. Below are the primary functions of the buttons:

- **POWER ( )**: Turns the TV on or off.
- **INPUT**: Cycles through available input sources (HDMI, AV, etc.).
- **AMAZON** / **NETFLIX** / **iHeartRadio**: Direct access buttons for these streaming services.
- **CC (Closed Caption)**: Toggles closed captions on or off.
- **Playback Controls (Rewind, Play/Pause, Fast Forward, Stop)**: Controls media playback.
- **MENU**: Opens the TV's main menu.
- **INFO**: Displays information about the current program or input.
- **EXIT**: Exits the current menu or screen.
- **Navigation Pad (Up, Down, Left, Right)**: Navigates through menus and options.
- **OK**: Confirms selections.
- **BACK**: Returns to the previous screen or menu.
- **GUIDE**: Accesses the electronic program guide (if available).
- **VOL (+/-)**: Adjusts the volume level.
- **CH (Channel Up/Down)**: Changes TV channels.
- **MUTE ( )**: Mutes or unmutes the TV audio.
- **PIC (Picture Mode)**: Cycles through picture modes.
- **Vizio Logo Button**: Typically opens the Vizio SmartCast or app launcher.
- **Number Pad (0-9)**: Directly enters channel numbers.
- **ENTER**: Confirms channel selection or other inputs.
- **DASH (-)**: Used for entering sub-channels (e.g., 7-1).

Troubleshooting

- **Remote not responding:**
  - Ensure fresh AAA alkaline batteries are correctly installed.
  - Check for any obstructions between the remote and the TV's infrared sensor.

- Point the remote directly at the TV.

- **Buttons are sticky or unresponsive:**
  - Clean the remote's surface with a soft, dry cloth. Avoid liquids.
  - Replace batteries, as low power can sometimes affect button responsiveness.

- **Remote works intermittently:**
  - Verify battery charge.
  - Ensure no strong light sources (like direct sunlight or bright fluorescent lights) are interfering with the IR signal.

Specifications

Brand	ZdalaMit
Model Number	XRT122
Connectivity Technology	Infrared (IR)
Compatible Devices	Vizio LED HDTV Televisions
Power Supply	2 x AAA Alkaline Batteries (not included)
Maximum Range	33 Feet (10 meters)
Dimensions (L x W x H)	6.5" x 2" x 0.55" (16.5 cm x 5.1 cm x 1.4 cm)
Item Weight	69 Grams

Maintenance

- **Cleaning:** Use a soft, dry, lint-free cloth to clean the remote's surface. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries promptly when the remote's performance degrades. Always replace both batteries at the same time with new AAA alkaline batteries. Do not mix old and new batteries or different types of batteries.
- **Storage:** If the remote will not be used for an extended period, remove the batteries to prevent leakage and potential damage.

Warranty and Support

This ZdalaMit XRT122 replacement remote control comes with a **1-year warranty** from the date of purchase, covering manufacturing defects. For warranty claims or technical support, please refer to the contact information provided by your retailer or the ZdalaMit manufacturer.
Please retain your purchase receipt as proof of purchase for warranty purposes.