

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Arcelik](#) /

› [Arcelik K 3400 Turkish Coffee Machine User Manual](#)

## Arcelik K 3400

# Arcelik K 3400 Turkish Coffee Machine User Manual

Model: K 3400

## INTRODUCTION

---

Welcome to the user manual for your new Arcelik K 3400 Turkish Coffee Machine. This appliance is designed to prepare authentic Turkish coffee with ease and convenience. Please read this manual thoroughly before first use to ensure safe operation and optimal performance of your machine.

## SAFETY INSTRUCTIONS

---

To prevent injury or damage, always observe basic safety precautions when using electrical appliances. Keep this manual for future reference.

- Read all instructions carefully before operating the appliance.
- Do not immerse the appliance, power cord, or plug in water or any other liquid.
- Keep the appliance out of reach of children and individuals with reduced physical, sensory, or mental capabilities.
- Unplug the machine from the electrical outlet when not in use and before cleaning.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Use the appliance only on a stable, flat, and heat-resistant surface.
- Do not use the appliance outdoors. It is intended for indoor household use only.
- Avoid contact with hot surfaces. Use handles or knobs.
- Do not place the appliance on or near a hot gas or electric burner, or in a heated oven.

## PACKAGE CONTENTS

---

Please check the contents of your package upon unpacking:

- Arcelik K 3400 Turkish Coffee Machine Main Unit

- Coffee Pot (Cezve)
- User Manual (this document)

## PRODUCT OVERVIEW

---

The Arcelik K 3400 is a compact and efficient Turkish coffee machine designed for ease of use. It features a wireless coffee pot for convenient serving and a fully automatic brewing process.



This image displays the Arcelik K 3400 Turkish Coffee Machine in its white finish. The machine features a sleek, modern design with a prominent coffee pot slot and the Arcelik logo.



This image illustrates the dimensions of the Arcelik K 3400 Turkish Coffee Machine. It measures approximately 15 cm in width, 15 cm in depth, and 27 cm in height.

## SETUP

---

Follow these steps to set up your coffee machine for the first time:

1. Unpack all components and remove any packaging materials, including protective films or stickers.
2. Place the machine on a dry, stable, and heat-resistant surface, away from water sources.
3. Wipe the exterior of the machine with a damp cloth to remove any dust.
4. Wash the coffee pot (cezve) with warm soapy water and rinse thoroughly. Dry completely before use.
5. Ensure the power cord is easily accessible and plug the machine into a suitable grounded power outlet (230 VAC).

## OPERATING INSTRUCTIONS

---

## Preparing Turkish Coffee

Follow these steps to brew authentic Turkish coffee:

1. Fill the coffee pot with cold water according to the desired number of servings. A general guideline is one cup of water per serving.
2. Add one heaped teaspoon of finely ground Turkish coffee per cup of water into the pot.
3. Add sugar to taste, if desired.
4. Stir the mixture gently until the coffee and sugar are dissolved. Avoid over-stirring, as this can affect the foam.
5. Place the coffee pot securely into the machine's brewing slot.
6. Press the start button. The machine will begin the brewing process, indicated by a light or sound.
7. The machine will automatically stop when the coffee is ready, typically indicated by a light or sound signal.
8. Carefully remove the coffee pot from the machine.
9. Pour the coffee into small Turkish coffee cups, distributing the foam evenly among the cups.
10. Allow the coffee grounds to settle for a minute or two before drinking.

## MAINTENANCE AND CLEANING

---

Regular cleaning and maintenance will ensure the longevity and optimal performance of your Arcelik K 3400.

### Daily Cleaning

1. After each use, unplug the machine from the power outlet and allow it to cool down completely.
2. Remove the coffee pot and discard any remaining coffee grounds.
3. Wash the coffee pot with warm soapy water and rinse thoroughly. Dry completely before storing or next use.
4. Wipe the exterior of the main unit with a soft, damp cloth. Do not use abrasive cleaners, scouring pads, or harsh chemicals.
5. Never immerse the main unit of the machine in water or any other liquid.

### Descaling (Monthly or as needed)

Mineral deposits can build up over time, affecting performance. Descale your machine regularly:

1. Fill the coffee pot with a mixture of water and white vinegar (e.g., 1 part vinegar to 2 parts water) or a commercial descaling solution suitable for coffee makers.
2. Place the pot in the machine and run a brewing cycle without coffee.
3. Discard the descaling solution and rinse the coffee pot thoroughly.
4. Run two more cycles with clean water to remove any residual descaling agent taste or odor.

## TROUBLESHOOTING

---

If you encounter any issues with your Arcelik K 3400, please refer to the table below for common problems and their solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Machine does not turn on	Not plugged in; Power outage; Faulty outlet	Check power connection; Check circuit breaker; Try a different electrical outlet
Coffee overflows during brewing	Too much water/coffee in the pot; Coffee pot not seated correctly	Ensure correct measurements for water and coffee; Re-seat the coffee pot firmly in the brewing slot
Coffee is not hot enough	Insufficient brewing time; Machine needs descaling	Ensure the coffee pot is correctly placed and the cycle completes; Perform descaling procedure
No foam on coffee	Coffee grounds too coarse; Incorrect water/coffee ratio; Over-stirring	Use finely ground Turkish coffee; Adjust water and coffee ratio; Stir gently only to mix ingredients

## TECHNICAL SPECIFICATIONS

Detailed specifications for the Arcelik K 3400 Turkish Coffee Machine:

Feature	Specification
Brand	Arcelik
Model Number	K 3400
Color	White
Product Dimensions (L x W x H)	15 x 15 x 27 cm
Capacity	1000 Milliliters
Power/Wattage	1000 watts
Voltage	230 VAC
Material	Plastic
Special Features	Wireless
Type of Coffee Maker	Turkish Coffee Maker
Operating Mode	Fully Automatic

## WARRANTY AND SUPPORT

Your Arcelik K 3400 Turkish Coffee Machine comes with a standard manufacturer's warranty. Please refer to the warranty card included in your original packaging for specific terms and conditions, including the warranty period and coverage details.

For technical support, spare parts, or service inquiries, please contact Arcelik customer service. You can typically find contact information on the official Arcelik website or in your product packaging. Please keep your proof of purchase (receipt or invoice) as it will be required for any warranty claims.

