

[Manuals.plus](#) /

› [Baxton Studio](#) /

› Baxton Studio Essone Chair User Manual

Baxton Studio 146-424-8325-AMZ

Essone Chair User Manual

Model: 146-424-8325-AMZ | Brand: Baxton Studio

INTRODUCTION

Thank you for choosing the Baxton Studio Essone Chair. This lounge chair is designed to provide comfort and style, featuring a square silhouette, foam padding, and navy velvet upholstery complemented by glossy, gold-finished legs. Its design includes button-tufting and edge piping for a sophisticated appearance. This manual provides essential information for the safe assembly, operation, and maintenance of your new chair.



Figure 1: The Baxton Studio Essone Chair in Blue Velvet.

SAFETY INFORMATION

WARNING:

- This chair requires assembly. Use appropriate tools and follow the instructions carefully to avoid injury.
- Keep the chair away from open flames and high heat sources to prevent fire hazards.
- Do not exceed the maximum weight capacity of 300 lbs.

PACKAGE CONTENTS

Before beginning assembly, ensure all parts are present and accounted for. If any parts are missing or damaged, please contact customer support.

- Essone Chair Frame (1)
- Seat Cushion (1)
- Back Cushion (1)
- Gold-Finished Legs (4)
- Assembly Hardware Kit (bolts, washers, Allen wrench)
- Assembly Instructions Manual (this document)

SETUP AND ASSEMBLY

Assembly is required for the Essone Chair. It is recommended to have two people for easier assembly. Please follow these steps carefully:

1. **Unpack Components:** Carefully remove all parts from the packaging. Place them on a soft, clean surface to prevent scratches.
2. **Identify Parts:** Refer to the parts list in the Package Contents section and the included hardware diagram to identify each component.
3. **Attach Legs:** Locate the pre-drilled holes on the underside of the chair frame. Align each gold-finished leg with the corresponding holes. Insert the provided bolts with washers and tighten them securely using the Allen wrench. Do not overtighten.



Figure 2: Detail of the gold-finished leg attachment point.

4. **Place Cushions:** Position the seat cushion and back cushion firmly into the chair frame. Ensure they are properly aligned and seated.
5. **Final Check:** Once assembled, gently rock the chair to ensure stability. If it wobbles, check that all bolts are tightened evenly.



Figure 3: The Essone Chair with its dimensions: 33.07"D x 34.25"W x 29.13"H.

OPERATING INSTRUCTIONS

The Essone Chair is designed for comfortable lounging and seating in various indoor settings such as living rooms, reception areas, or entryways.

- **Placement:** Position the chair on a flat, stable surface. Avoid placing it in direct sunlight for prolonged periods to prevent fabric fading.
- **Usage:** Use the chair for sitting and relaxation. Do not stand on the chair or use it as a step stool.
- **Weight Limit:** Adhere to the maximum weight capacity of 300 lbs to ensure safety and longevity of the chair.



Figure 4: The Essone Chair positioned in a living room environment.

MAINTENANCE AND CARE

Proper care will help maintain the appearance and extend the life of your Essone Chair.

- **Velvet Upholstery:**

- Regularly vacuum the upholstery using a soft brush attachment to remove dust and debris.
- For spills, blot immediately with a clean, dry cloth. Do not rub, as this can spread the stain and damage the velvet pile.
- For stubborn stains, consult a professional upholstery cleaner or use a velvet-safe cleaning product following its instructions. Test on an inconspicuous area first.
- Avoid using harsh chemicals or abrasive cleaners.

- **Gold-Finished Legs:**

- Wipe clean with a soft, damp cloth.
- Avoid using abrasive cleaners or polishes that could scratch or dull the finish.
- Dry immediately with a clean, soft cloth to prevent water spots.

- **General Maintenance:**

- Periodically check and tighten all assembly bolts to ensure the chair remains stable.
- Keep the chair away from direct heat sources and prolonged direct sunlight to prevent material degradation and fading.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Chair wobbles after assembly.	Legs not tightened evenly or fully.	Ensure all bolts securing the legs are tightened securely and evenly.
Fabric appears flattened or matted.	Normal wear or pressure on velvet pile.	Gently brush the velvet pile with a soft brush in the direction of the nap. Light steaming can also help restore the pile.
Minor scratches on gold-finished legs.	Accidental contact with abrasive surfaces.	For minor scratches, a gold-colored touch-up pen may be used. For deeper scratches, professional repair may be needed.

SPECIFICATIONS

Attribute	Detail
Brand	Baxton Studio
Model Name	Essone
Model Number	146-424-8325-AMZ
Color	Blue
Product Dimensions (D x W x H)	33.07" x 34.25" x 29.13"
Item Weight	44.1 pounds
Fill Material	Foam
Back Style	Tufted Back
Special Feature	Arm Rest
Recommended Uses	Lounge
Country of Origin	China
UPC	842507180805

WARRANTY AND SUPPORT

Baxton Studio products are manufactured with quality and care. For information regarding warranty coverage, please refer to the warranty card included with your purchase or visit the official Baxton Studio website.

If you encounter any issues or have questions not covered in this manual, please contact Baxton Studio customer support for assistance.

Online Support: www.baxtonstudio.com/support

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07CNV4RVJ>

More documents and user manuals: <https://manuals.plus/>