Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Bud Light /
- > Bud Light Beer Bluetooth Bottle Speaker BL-BBS-002 User Manual

Bud Light BL-BBS-002

Bud Light Beer Bluetooth Bottle Speaker BL-BBS-002 User Manual

1. Introduction

This manual provides comprehensive instructions for the Bud Light Beer Bluetooth Bottle Speaker, Model BL-BBS-002. Designed for portable audio playback, this wireless speaker connects to Bluetooth-enabled devices, offering a unique design and clear sound for various indoor and outdoor activities.

Please read this manual thoroughly before using the product to ensure proper operation and to maximize its lifespan.



Image 1.1: Front view of the Bud Light Beer Bluetooth Bottle Speaker.

2. PACKAGE CONTENTS

Verify that all items listed below are present in your product packaging:

- Bud Light Bluetooth Speaker Bottle
- Charging Cable (Micro USB)
- User Manual (this document)

3. PRODUCT OVERVIEW

Familiarize yourself with the various components and controls of your Bud Light Bluetooth Bottle Speaker.




Image 3.1: Side view of the speaker highlighting the control buttons and ports.

- 1. On/Off Button: Powers the speaker on or off.
- 2. Aux 3.5mm Port: For wired audio connection using a 3.5mm audio cable (not included).

3. Micro USB Charging Port: Connects the speaker to a power source for charging.

4. SETUP

4.1. Charging the Speaker

Before initial use, fully charge the speaker. Use the provided Micro USB charging cable.

- 1. Connect the Micro USB end of the charging cable to the Micro USB Charging Port on the speaker.
- 2. Connect the USB-A end of the charging cable to a USB power adapter (e.g., smartphone charger, computer USB port) or a power bank.
- 3. The charging indicator light (if present, refer to product for exact location) will illuminate during charging and turn off or change color when fully charged.
- 4. A full charge typically takes approximately 2-3 hours.

Note: Do not use damaged charging cables or adapters. Ensure the charging port is dry before connecting the cable.

4.2. Powering On/Off

- **To Power On:** Press and hold the On/Off Button for approximately 3 seconds. You will hear an audible tone, and an indicator light will flash, indicating it is ready for pairing.
- To Power Off: Press and hold the On/Off Button for approximately 3 seconds. You will hear an audible tone, and the indicator light will turn off.

5. OPERATING INSTRUCTIONS

5.1. Bluetooth Pairing

To connect the speaker to your Bluetooth-enabled device (smartphone, tablet, laptop):

- 1. Ensure the speaker is powered on and in pairing mode (indicator light flashing).
- 2. On your device, navigate to the Bluetooth settings.
- 3. Enable Bluetooth and search for available devices.
- 4. Select "Bud Light Speaker" (or similar name) from the list of found devices.
- 5. Once paired, you will hear a confirmation tone, and the indicator light on the speaker will stop flashing and remain solid.
- 6. The speaker will automatically attempt to reconnect to the last paired device when powered on.

Note: The effective Bluetooth range is approximately 30 feet (9 meters). Obstacles may reduce this range.

5.2. Audio Playback

- · After successful Bluetooth pairing, play audio from your connected device.
- Adjust the volume directly from your connected device. The speaker does not have independent volume controls.
- For wired connection, insert a 3.5mm audio cable into the Aux 3.5mm Port on the speaker and the other end into your audio source. Bluetooth will be disabled when the Aux cable is connected.



Image 5.1: The portable speaker in an outdoor setting, demonstrating its use for entertainment.

6. MAINTENANCE

- Cleaning: Wipe the speaker with a soft, dry cloth. Do not use abrasive cleaners, alcohol, or solvents.
- Storage: Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- Water Exposure: This speaker is NOT waterproof. Avoid exposing it to water, rain, or excessive moisture.
- Battery Care: To preserve battery life, charge the speaker at least once every three months if not in regular use.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not power on.	Battery is depleted.	Charge the speaker using the provided USB cable.
Cannot pair with Bluetooth device.	Bluetooth is off on your device; speaker is not in pairing mode; speaker is already paired to another device; device is out of range.	Ensure Bluetooth is enabled on your device. Power cycle the speaker to enter pairing mode. Disconnect from other devices. Move device closer to speaker (within 30 ft).

Problem	Possible Cause	Solution
No sound during playback.	Volume on device is too low; speaker is not connected; audio source issue.	Increase volume on your connected device. Re-pair the Bluetooth connection. Check if the audio source is playing correctly.
Sound quality is poor or distorted.	Device is out of Bluetooth range; interference; low battery.	Move device closer to the speaker. Avoid sources of strong electromagnetic interference. Charge the speaker.

8. SPECIFICATIONS

Model Name	BL-BBS-002
Brand	Bud Light
Connectivity Technology	Bluetooth 5.0
Wireless Range	Up to 30 feet (9 meters)
Power Source	Battery Powered (1 Lithium Polymer battery, included)
Speaker Output Power	3 Watts
Audio Output Mode	Stereo
Product Dimensions (L x W x H)	2.5"D x 2.5"W x 9"H (6.35 cm x 6.35 cm x 22.86 cm)
Item Weight	1 pound (0.45 kg)
Waterproof	No
Compatible Devices	Smartphones, Tablets, Laptops, Personal Computers

9. WARRANTY AND SUPPORT

This Bud Light Bluetooth Speaker comes with a **1-year limited warranty** from the date of purchase. Please retain your proof of purchase for warranty claims.

The manufacturer is M&S Accessory Network. For support or warranty inquiries, please contact the retailer or manufacturer directly with your proof of purchase and product model number (BL-BBS-002).

Note: Warranty does not cover damage caused by misuse, accidents, unauthorized modifications, or exposure to water.

© 2024 Bud Light. All rights reserved. Model BL-BBS-002.

Related Documents - BL-BBS-002



Bud Light Amp Speaker TWG22125 User Manual

User manual for the Bud Light Amp Speaker, Model TWG22125, providing safety instructions, operating procedures, troubleshooting, and specifications.



Panasonic Network Camera BL-VT164/BL-VP100 Series Operating Instructions

B. From B. S. From B.

Detailed operating instructions for Panasonic BL-VT164 Series and BL-VP100 Series network cameras. Covers setup, configuration, monitoring, and maintenance.



Coca-Cola Bluetooth Bottle Speaker User Manual

User manual for the Coca-Cola Bluetooth Bottle Speaker, covering introduction, package contents, product diagram, usage instructions, pairing, charging, FAQs, specifications, and support.



HIOS Brushless Driver BL Series Operation Manual

Comprehensive operation manual for HIOS BL Series Brushless Drivers, covering specifications, parts identification, accessories, operating procedures, torque adjustment, and troubleshooting for models like BL-2000, BL-3000, BL-5000, and BL-7000.



VEVOR Drum Set Installation Guide and Parts List

DRUM SET MODEL: SH 004 8K, SH 400-8L-A, SH 002 8L-A, SH 402-RD, SH 402-SY A comprehensive guide for assembling and installing your VEVOR Drum Set, including a detailed parts list and step-by-step instructions for models SH-004-BK, SH-004-BL-A, SH-002-BL-A, SH-002-RD, and SH-002-SY.



R100 Hotel St. ST.000

HIOS Brushless Driver BL Series Operation Manual

This operation manual provides detailed information on the HIOS Brushless Driver BL Series, including models BL-2000, BL-3000, BL-5000, and BL-7000. It covers parts identification, specifications, accessories, power supplies, operating procedures, torque adjustment, and troubleshooting.